

**LS-DYNA<sup>®</sup>**  
**KEYWORD USER'S MANUAL**

**VOLUME III**

**Multi-Physics Solvers**

**LS-DYNA R8.0**  
**03/16/15 (r:6294)**

**LIVERMORE SOFTWARE TECHNOLOGY CORPORATION (LSTC)**

### **Corporate Address**

Livermore Software Technology Corporation  
P. O. Box 712  
Livermore, California 94551-0712

### **Support Addresses**

Livermore Software Technology Corporation  
7374 Las Positas Road  
Livermore, California 94551  
Tel: 925-449-2500 Fax: 925-449-2507

**Email:** [sales@lstc.com](mailto:sales@lstc.com)

**Website:** [www.lstc.com](http://www.lstc.com)

Livermore Software Technology  
Corporation  
1740 West Big Beaver Road  
Suite 100  
Troy, Michigan 48084  
Tel: 248-649-4728 Fax: 248-649-6328

### **Disclaimer**

Copyright © 1992-2015 Livermore Software Technology Corporation. All Rights Reserved.  
LS-DYNA®, LS-OPT® and LS-PrePost® are registered trademarks of Livermore Software  
Technology Corporation in the United States. All other trademarks, product names and  
brand names belong to their respective owners.

LSTC reserves the right to modify the material contained within this manual without prior  
notice.

The information and examples included herein are for illustrative purposes only and are  
not intended to be exhaustive or all-inclusive. LSTC assumes no liability or responsibility  
whatsoever for any direct or indirect damages or inaccuracies of any type or nature that  
could be deemed to have resulted from the use of this manual.

Any reproduction, in whole or in part, of this manual is prohibited without the prior  
written approval of LSTC. All requests to reproduce the contents hereof should be sent to  
[sales@lstc.com](mailto:sales@lstc.com).

# TABLE OF CONTENTS

---

## TABLE OF CONTENTS

TABLE OF CONTENTS.....	0-3
INTRODUCTION.....	1-1
*CESE.....	2-1
*CESE_BOUNDARY_AXISYMMETRIC_OPTION.....	2-3
*CESE_BOUNDARY_BLAST_LOAD.....	2-5
*CESE_BOUNDARY_CYCLIC.....	2-7
*CESE_BOUNDARY_FSI.....	2-11
*CESE_BOUNDARY_NON_REFLECTIVE.....	2-14
*CESE_BOUNDARY_PRESCRIBED.....	2-17
*CESE_BOUNDARY_REFLECTIVE.....	2-21
*CESE_BOUNDARY_SLIDING.....	2-23
*CESE_BOUNDARY_SOLID_WALL.....	2-25
*CESE_CHEMISTRY_D3PLOT.....	2-29
*CESE_CONTROL_LIMITER.....	2-30
*CESE_CONTROL_MESH_MOV.....	2-31
*CESE_CONTROL_SOLVER.....	2-32
*CESE_CONTROL_TIMESTEP.....	2-34
*CESE_DATABASE_ELOUT.....	2-35
*CESE_DATABASE_FLUXAVG.....	2-36
*CESE_DATABASE_FSIDRAG.....	2-37
*CESE_DATABASE_POINTOUT.....	2-38
*CESE_DATABASE_SSETDRAG.....	2-40
*CESE_DEFINE_NONINERTIAL.....	2-42
*CESE_DEFINE_POINT.....	2-44
*CESE_DRAG.....	2-45
*CESE_EOS_CAV_HOMOG_EQUILIB.....	2-46
*CESE_EOS_IDEAL_GAS.....	2-47
*CESE_INITIAL.....	2-48
*CESE_INITIAL.....	2-49
*CESE_INITIAL_CHEMISTRY.....	2-50
*CESE_INITIAL_CHEMISTRY_ELEMENT.....	2-52
*CESE_INITIAL_CHEMISTRY_PART.....	2-54
*CESE_INITIAL_CHEMISTRY_SET.....	2-56

# TABLE OF CONTENTS

---

*CESE_MAT_000 .....	2-58
*CESE_MAT_001( _GAS) .....	2-59
*CESE_MAT_002 .....	2-60
*CESE_PART .....	2-62
*CHEMISTRY .....	3-1
*CHEMISTRY_COMPOSITION .....	3-3
*CHEMISTRY_CONTROL_0D .....	3-4
*CHEMISTRY_CONTROL_1D .....	3-6
*CHEMISTRY_CONTROL_CSP .....	3-8
*CHEMISTRY_CONTROL_FULL .....	3-9
*CHEMISTRY_CONTROL_PYROTECHNIC .....	3-10
*CHEMISTRY_CONTROL_TBX .....	3-13
*CHEMISTRY_CONTROL_ZND .....	3-14
*CHEMISTRY_DET_INITIATION .....	3-15
*CHEMISTRY_MODEL .....	3-17
*CHEMISTRY_PATH .....	3-19
*CHEMISTRY_PROPELLANT_PROPERTIES .....	3-20
*EM .....	4-1
*EM_2DAXI .....	4-3
*EM_BOUNDARY .....	4-5
*EM_CIRCUIT .....	4-6
*EM_CIRCUIT_ROGO .....	4-10
*EM_CONTACT .....	4-11
*EM_CONTACT_RESISTANCE .....	4-13
*EM_CONTROL .....	4-19
*EM_CONTROL_CONTACT .....	4-20
*EM_CONTROL_SWITCH .....	4-21
*EM_CONTROL_TIMESTEP .....	4-22
*EM_DATABASE_CIRCUIT .....	4-24
*EM_DATABASE_CIRCUIT0D .....	4-26
*EM_DATABASE_ELOUT .....	4-27
*EM_DATABASE_FIELDLINE .....	4-28
*EM_DATABASE_GLOBALENERGY .....	4-31
*EM_DATABASE_NODOUT .....	4-32
*EM_DATABASE_PARTDATA .....	4-33
*EM_DATABASE_POINTOUT .....	4-34

# TABLE OF CONTENTS

---

*EM_DATABASE_ROGO .....	4-35
*EM_DATABASE_TIMESTEP .....	4-36
*EM_EOS_BURGESS .....	4-37
*EM_EOS_MEADON .....	4-41
*EM_EOS_PERMEABILITY .....	4-44
*EM_EOS_TABULATED1 .....	4-45
*EM_EOS_TABULATED2 .....	4-46
*EM_EXTERNAL_FIELD .....	4-47
*EM_MAT_001 .....	4-48
*EM_MAT_002 .....	4-49
*EM_MAT_003 .....	4-50
*EM_MAT_004 .....	4-53
*EM_OUTPUT .....	4-54
*EM_POINT_SET .....	4-56
*EM_ROTATION_AXIS .....	4-57
*EM_SOLVER_BEM .....	4-58
*EM_SOLVER_BEMMAT .....	4-60
*EM_SOLVER_FEM .....	4-61
*EM_SOLVER_FEMBEM .....	4-63
*ICFD .....	5-1
*ICFD_BOUNDARY_CONJ_HEAT .....	5-4
*ICFD_BOUNDARY_FLUX_TEMP .....	5-5
*ICFD_BOUNDARY_FREESLIP .....	5-6
*ICFD_BOUNDARY_FSI .....	5-7
*ICFD_BOUNDARY_NONSLIP .....	5-8
*ICFD_BOUNDARY_PRESCRIBED_MOVEMESH .....	5-9
*ICFD_BOUNDARY_PRESCRIBED_PRE .....	5-10
*ICFD_BOUNDARY_PRESCRIBED_TEMP .....	5-11
*ICFD_BOUNDARY_PRESCRIBED_VEL .....	5-12
*ICFD_CONTROL_ADAPT .....	5-14
*ICFD_CONTROL_ADAPT_SIZE .....	5-15
*ICFD_CONTROL_FSI .....	5-16
*ICFD_CONTROL_IMPOSED_MOVE .....	5-18
*ICFD_CONTROL_LOAD .....	5-19
*ICFD_CONTROL_MESH .....	5-20
*ICFD_CONTROL_MESH_MOV .....	5-21

# TABLE OF CONTENTS

---

*ICFD_CONTROL_OUTPUT .....	5-22
*ICFD_CONTROL_OUTPUT_SUBDOM .....	5-23
*ICFD_CONTROL_PARTITION .....	5-25
*ICFD_CONTROL_SURFMESH.....	5-26
*ICFD_CONTROL_TAVERAGE.....	5-27
*ICFD_CONTROL_TIME .....	5-28
*ICFD_CONTROL_TURBULENCE.....	5-29
*ICFD_CONTROL_TURB_SYNTHESIS .....	5-31
*ICFD_DATABASE_AVERAGE.....	5-32
*ICFD_DATABASE_DRAG .....	5-33
*ICFD_DATABASE_FLUX .....	5-34
*ICFD_DATABASE_HTC.....	5-35
*ICFD_DATABASE_NODEAVG .....	5-37
*ICFD_DATABASE_NODOUT.....	5-38
*ICFD_DATABASE_POINTAVG .....	5-39
*ICFD_DATABASE_POINTOUT .....	5-40
*ICFD_DATABASE_RESIDUALS .....	5-42
*ICFD_DATABASE_TEMP .....	5-43
*ICFD_DATABASE_TIMESTEP .....	5-44
*ICFD_DATABASE_UINDEX.....	5-45
*ICFD_DEFINE_POINT.....	5-46
*ICFD_DEFINE_NONINERTIAL.....	5-47
*ICFD_INITIAL.....	5-49
*ICFD_MAT .....	5-50
*ICFD_PART .....	5-54
*ICFD_PART_VOL.....	5-55
*ICFD_SECTION .....	5-57
*ICFD_SET_NODE_LIST .....	5-58
*ICFD_SOLVER_SPLIT .....	5-59
*ICFD_SOLVER_TOL_MMOV .....	5-60
*ICFD_SOLVER_TOL_MOM .....	5-61
*ICFD_SOLVER_TOL_PRE .....	5-62
*ICFD_SOLVER_TOL_TEMP .....	5-63
*MESH .....	6-1
*MESH_BL.....	6-2
*MESH_BL_SYM .....	6-3

# TABLE OF CONTENTS

---

*MESH_EMBEDSHELL.....	6-4
*MESH_INTERF .....	6-5
*MESH_NODE .....	6-6
*MESH_SIZE.....	6-7
*MESH_SIZE_SHAPE .....	6-8
*MESH_SURFACE_ELEMENT.....	6-10
*MESH_SURFACE_NODE .....	6-11
*MESH_VOLUME.....	6-12
*MESH_VOLUME_ELEMENT .....	6-13
*MESH_VOLUME_NODE.....	6-14
*MESH_VOLUME_PART.....	6-15
*STOCHASTIC .....	7-1
*STOCHASTIC_SPRAY_PARTICLES .....	7-2
*STOCHASTIC_TBX_PARTICLES .....	7-5
*LSO.....	8-1
*LSO_DOMAIN .....	8-2
*LSO_ID_SET .....	8-6
*LSO_POINT_SET.....	8-8
*LSO_TIME_SEQUENCE .....	8-10
*LSO_VARIABLE_GROUP .....	8-13





---

**LS-DYNA MULTIPHYSICS USER'S MANUAL****INTRODUCTION**

In this manual, there are three main solvers: a compressible flow solver, an incompressible flow solver, and an electromagnetism solver. Each of them implements coupling with the structural solver in LS-DYNA.

The keywords covered in this manual fit into one of three categories. In the first category are the keyword cards that provide input to each of the multiphysics solvers that in turn couple with the structural solver. In the second category are keyword cards involving extensions to the basic solvers. Presently, the chemistry and stochastic particle solvers are the two solvers in this category, and they are used in conjunction with the compressible flow solver discussed below. In the third category are keyword cards for support facilities. A volume mesher that creates volume tetrahedral element meshes from bounding surface meshes is one of these tools. Another is a new data output mechanism for a limited set of variables from the solvers in this manual. This mechanism is accessed through \*LSO keyword cards.

The CESE solver is a compressible flow solver based upon the Conservation Element/Solution Element (CE/SE) method, originally proposed by Chang of the NASA Glenn Research Center. This method is a novel numerical framework for conservation laws. It has many non-traditional features, including a unified treatment of space and time, the introduction of separate conservation elements (CE) and solution elements (SE), and a novel shock capturing strategy without using a Riemann solver. This method has been used to solve many types of flow problems, such as detonation waves, shock/acoustic wave interaction, cavitating flows, supersonic liquid jets, and chemically reacting flows. In LS-DYNA, it has been extended to also solve fluid-structure interaction (FSI) problems. It does this with two approaches. The first approach solves the compressible flow equations on an Eulerian mesh while the structural mechanics is solved on a moving mesh that moves through the fixed CE/SE mesh. In the second approach (new with this version), the CE/SE mesh moves in a fashion such that its FSI boundary surface matches the corresponding FSI boundary surface of the moving structural mechanics mesh. This second approach is more accurate for FSI problems, especially with boundary layers flows. Another new feature with the CESE moving mesh solver is conjugate heat transfer coupling with the solid thermal solver. The chemistry and stochastic particle solvers are two add-on solvers that extend the CESE solver.

The second solver is the incompressible flow solver (ICFD) that is fully coupled with the solid mechanics solver. This coupling permits robust FSI analysis via either an explicit technique when the FSI is weak, or using an implicit coupling when the FSI coupling is

strong. In addition to being able to handle free surface flows, there is also a bi-phasic flow capability that involves modeling using a conservative Lagrangian interface tracking technique. Basic turbulence models are also supported. This solver is the first in LS-DYNA to make use of a new volume mesher that takes surface meshes bounding the fluid domain as input (\*MESH keywords). In addition, during the time advancement of the incompressible flow, the solution is adaptively re-meshed as an automatic feature of the solver. Another important feature of the mesher is the ability to create boundary layer meshes. These anisotropic meshes become a crucial part of the model when shear stresses are to be calculated near fluid walls. The ICFD solver is also coupled to the solid thermal solver using a monolithic approach for conjugate heat transfer problems.

The third solver is an electromagnetics (EM) solver. This module solves the Maxwell equations in the Eddy current (induction-diffusion) approximation. This is suitable for cases where the propagation of electromagnetic waves in air (or vacuum) can be considered as instantaneous. Therefore, the wave propagation is not solved. The main applications are Magnetic Metal Forming, bending or welding, induced heating, ring expansions and so forth. The EM module allows the introduction of a source of electrical current into solid conductors and the computation of the associated magnetic field, electric field, as well as induced currents. The EM solver is coupled with the structural mechanics solver (the Lorentz forces are added to the mechanics equations of motion), and with the structural thermal solver (the ohmic heating is added to the thermal solver as an extra source of heat). The EM fields are solved using a Finite Element Method (FEM) for the conductors and a Boundary Element Method (BEM) for the surrounding air/insulators. Thus no air mesh is necessary.

As stated above, the \*CHEMISTRY and \*STOCHASTIC cards are only used in the CESE solver at this time.

# \*CESE

The keyword \*CESE provides input data for the Conservation Element/Solution Element (CESE) compressible fluid solver:

- \*CESE\_BOUNDARY\_AXISYMMETRIC\_{OPTION}
- \*CESE\_BOUNDARY\_CYCLIC\_{OPTION}
- \*CESE\_BOUNDARY\_FSI\_{OPTION}
- \*CESE\_BOUNDARY\_NON\_REFLECTIVE\_{OPTION}
- \*CESE\_BOUNDARY\_PRESCRIBED\_{OPTION}
- \*CESE\_BOUNDARY\_REFLECTIVE\_{OPTION}
- \*CESE\_BOUNDARY\_SLIDING\_{OPTION}
- \*CESE\_BOUNDARY\_SOLID\_WALL\_{OPTION1}\_{OPTION2}
- \*CESE\_CHEMISTRY\_D3PLOT
- \*CESE\_CONTROL\_LIMITER
- \*CESE\_CONTROL\_MESH\_MOV
- \*CESE\_CONTROL\_SOLVER
- \*CESE\_CONTROL\_TIMESTEP
- \*CESE\_DATABASE\_ELOUT
- \*CESE\_DATABASE\_FLUXAVG
- \*CESE\_DATABASE\_FSIDRAG
- \*CESE\_DATABASE\_POINTOUT
- \*CESE\_DATABASE\_SSETDRAG
- \*CESE\_DEFINE\_NONINERTIAL
- \*CESE\_DEFINE\_POINT
- \*CESE\_DRAG
- \*CESE\_EOS\_CAV\_HOMOGENEOUS\_EQUILIB\_

\*CESE\_EOS\_IDEAL\_GAS  
\*CESE\_INITIAL  
\*CESE\_INITIAL\_{*OPTION*}  
\*CESE\_INITIAL\_CHEMISTRY  
\*CESE\_INITIAL\_CHEMISTRY\_ELEMENT  
\*CESE\_INITIAL\_CHEMISTRY\_PART  
\*CESE\_INITIAL\_CHEMISTRY\_SET  
\*CESE\_MAT\_000  
\*CESE\_MAT\_001 (\*CESE\_MAT\_GAS)  
\*CESE\_MAT\_002  
\*CESE\_PART

Note that when performing a chemistry calculation with the CESE solver, initialization should only be done with the \*CESE\_INITIAL\_CHEMISTRY\_... cards, not the \*CESE\_INITIAL\_... cards.

**\*CESE\_BOUNDARY\_AXISYMMETRIC\_OPTION**

Available options are

MSURF

MSURF\_SET

SET

SEGMENT

Purpose: Define an axisymmetric boundary condition on the axisymmetric axis for the 2D axisymmetric CESE compressible flow solver.

The MSURF and MSURF\_SET options are used when the CESE mesh has been created using \*MESH cards. The SET and SEGMENT cards are used when \*ELEMENT\_SOLID cards are used to define the CESE mesh.

**Surface Part Card.** Card 1 format used when the MSURF keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1a	1	2	3	4	5	6	7	8
Variable	MSURFID							
Type	I							
Default	none							

**Surface Part Set Card.** Card 1 format used when the MSURF\_SET keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1b	1	2	3	4	5	6	7	8
Variable	MSURF_S							
Type	I							
Default	none							

**Set Card.** Card 1 format used when the SET keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1c	1	2	3	4	5	6	7	8
Variable	SSID							
Type	I							
Default	none							

**Segment Cards.** Card 1 format used when SEGMENT keyword option is active. Include an additional card for each corresponding pair of segments. This input ends at the next keyword ("\*") card.

Card 1d	1	2	3	4	5	6	7	8
Variable	N1	N2	N3	N4				
Type	I	I	I	I				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

MSURFID	Mesh surface part ID referenced in *MESH_SURFACE_ELEMENT cards.
MSURF_S	Identifier of a set of mesh surface part IDs created with a *LSO_ID_SET card, where each mesh surface part ID in the set is referenced in *MESH_SURFACE_ELEMENT cards.
SSID	Segment set ID
N1, N2, ...	Node IDs defining a segment

**Remarks:**

1. This boundary condition can only be used on the axisymmetric axis for the 2D axisymmetric CESE fluid solver.

**\*CESE\_BOUNDARY\_BLAST\_LOAD\_OPTION**

Available options include:

MSURF

MSURF\_SET

SET

SEGMENT

Purpose: For the CESE compressible flow solver, set boundary values for velocity, density, and pressure from a blast wave defined by a \*LOAD\_BLAST\_ENHANCED card. Boundary values are applied at the centroid of elements connected with this boundary. OPTION = SET and OPTION = SEGMENT are for user defined meshes whereas OPTION = MSURF or MSURF\_SET are associated with the automatic volume mesher (See \*MESH keywords).

That is, the MSURF and MSURF\_SET options are used when the CESE mesh has been created using \*MESH cards. The SET and SEGMENT cards are used when \*ELEMENT\_SOLID cards are used to define the CESE mesh.

**Surface Part Card.** Card 1 format used when the MSURF keyword option is active.

Card 1a	1	2	3	4	5	6	7	8
Variable	BID	MSURFID						
Type	I	I						
Default	none	none						

**Surface Part Set Card.** Card 1 format used when the MSURF\_SET keyword option is active.

Card 1b	1	2	3	4	5	6	7	8
Variable	BID	MSURF_S						
Type	I	I						
Default	none	none						

**Set Card.** Card 1 format used when the SET keyword option is active.

Card 1c	1	2	3	4	5	6	7	8
Variable	BID	SSID						
Type	I	I						
Default	none	none						

**Segment Card.** Card 1 for SEGMENT keyword option is active.

Card 1d	1	2	3	4	5	6	7	8
Variable	BID	N1	N2	N3	N4			
Type	I	I	I	I	I			
Default	none	none	none	none	none			

**VARIABLE****DESCRIPTION**

BID	Blast source ID (see *LOAD_BLAST_ENHANCED).
MSURFID	A mesh surface part ID referenced in *MESH_SURFACE_ELEMENT cards
MSURF_S	Identifier of a set of mesh surface part IDs created with a *LSO_ID_SET card, where each mesh surface part ID in the set is referenced in *MESH_SURFACE_ELEMENT cards.
SSID	Segment set ID
N1, N2, ...	Node ID's defining a segment



\*CESE\_BOUNDARY\_CYCLIC\_OPTION

Available options are:

MSURF

MSURF\_SET

SET

SEGMENT

Purpose: Define a cyclic (periodic) boundary condition for CESE compressible flows. This cyclic boundary condition (CBC) can be used on periodic boundary surfaces.

The MSURF and MSURF\_SET options are used when the CESE mesh has been created using \*MESH cards. The SET and SEGMENT cards are used when \*ELEMENT\_SOLID cards are used to define the CESE mesh.

**Card Sets.** The following sequence of cards comprises a *single set*. LS-DYNA will continue reading \*CESE\_BOUNDARY\_SOLID\_WALL card sets until the next keyword (“\*”) card is encountered.

**Surface Part Card.** Card 1 format used when the MSURF keyword option is active.

Card 1a	1	2	3	4	5	6	7	8
Variable	MSURFID1	MSURFID2	CYCTYP					
Type	I	I	I					
Default	none	none	0					
Remarks			1, 2					

**Surface Part Set Card.** Card 1 format used when the MSURF\_SET keyword option is active.

Card 1b	1	2	3	4	5	6	7	8
Variable	MSRF_S1	MSRF_S2	CYCTYP					
Type	I	I	I					
Default	none	none	0					
Remarks			1, 3					

**Set Card.** Card 1 format used when the SET keyword option is active.

Card 1c	1	2	3	4	5	6	7	8
Variable	SSID1	SSID2	CYCTYP					
Type	I	I	I					
Default	none	none	0					
Remarks			1, 4					

**Segment Card.** Card 1 format used when SEGMENT keyword option is active. Include an additional card for each corresponding pair of segments. This input ends at the next keyword ("\*") card.

Card 1d	1	2	3	4	5	6	7	8
Variable	ND1	ND2	ND3	ND4	NP1	NP2	NP3	NP4
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**Rotation Case Card.** Additional card for the MSURF, MSURF\_SET, and SET options when CYCTYP = 1.

Card 2a	1	2	3	4	5	6	7	8
Variable	AXISX1	AXISY1	AXISZ1	DIRX	DIRY	DIRZ	ROTANG	
Type	F	F	F	F	F	F	F	
Default	0.0	0.0	0.0	none	none	none	none	

**Translation Case Card.** Additional card for the MSURF, MSURF\_SET, and SET options when CYCTYP = 2.

Card 2b	1	2	3	4	5	6	7	8
Variable	TRANSX	TRANSY	TRANSZ					
Type	F	F	F					
Default	none	none	none					

VARIABLE	DESCRIPTION
MSURFID1, MSURFID2	Mesh surface part numbers referenced in *MESH_SURFACE_ELEMENT cards.
MSRF_S1, MSRF_S2	Identifiers of two sets of mesh surface part IDs, each created with a *LSO_ID_SET card, where each mesh surface part ID in each set is referenced in *MESH_SURFACE_ELEMENT cards.
CYCTYP	Relationship between the two cyclic boundary condition surfaces: EQ.0: none assumed (default) EQ.1: The first surface is rotated about an axis to match the second surface. EQ.2: The faces of the first surface are translated in a given direction to obtain the corresponding faces on the second surface.
SSID1 & SSID2	A pair of segment set IDs

$ND_i, NP_i$	Node IDs defining a pair of segments: ND1, ND2, ND3, ND4 define the first segment, while NP1, NP2, NP3, NP4 define the second segment. This pair of segments must match either through a geometric translation or rotation.
AXIS[Z,Y,Z]1	A point on the axis of rotation for CYCTYP.EQ.1.
DIR[X,Y,Z]	The direction which together with AXIS[X,Y,Z]1 defines the axis of rotation for CYCTYP.EQ.1.
ROTANG	The angle of rotation (in degrees) that transforms the centroid of each face on the first surface to the centroid of the corresponding face on the second surface (for CYCTYP.EQ.1).
TRANS[X,Y,Z]	The translation direction that enables the identification of the segment in the second surface that matches a segment in the first surface (for CYCTYP.EQ.2).

**Remarks:**

1. For the MSURF, MSURF\_SET, or SET options with CYCTYP.EQ.0, the code examines the geometry of two faces of the two surfaces in order to determine if the surfaces are approximately parallel (CYCTYP.EQ.2), or related through a rotation (CYCTYP.EQ.1). The geometric parameters required are then computed.
2. For the MSURF option, there must be the same number of mesh surface elements in each mesh surface part, and the mesh surface elements in each mesh surface part are then internally ordered in order to match pairwise between the two mesh surface parts.
3. For the MSURF\_SET option, there must be the same number of mesh surface elements in each mesh surface part set, and the mesh surface elements in each mesh surface part set are then internally ordered in order to match pairwise between the two mesh surface part sets.
4. For the SET option, there must be the same number of segments in each set, and the segments in each set are then internally ordered in order to match pairwise between the two sets.

\*CESE\_BOUNDARY\_FSI\_OPTION

Available options are:

MSURF

MSURF\_SET

SET

SEGMENT

Purpose: Define an FSI boundary condition for the moving mesh CESE compressible flow solver. This card must not be combined with the immersed-boundary method CESE solver, and doing so will result in an error termination condition.

This boundary condition must be applied on a surface of the CESE computational domain that is co-located with surfaces of the outside boundary of the structural mechanics solver. The nodes of the two meshes will generally not be shared.

The MSURF and MSURF\_SET options are used when the CESE mesh has been created using \*MESH cards. The SET and SEGMENT cards are used when \*ELEMENT\_SOLID cards are used to define the CESE mesh.

**Surface Part Card.** Card 1 format used when the MSURF keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1a	1	2	3	4	5	6	7	8
Variable	MSURFID							
Type	I							
Default	none							

**Surface Part Set Card.** Card 1 format used when the MSURF\_SET keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*\*") card.

Card 1b	1	2	3	4	5	6	7	8
Variable	MSURF_S							
Type	I							
Default	none							

**Set Card.** Card 1 format used when the SET keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*\*") card.

Card 1c	1	2	3	4	5	6	7	8
Variable	SSID							
Type	I							
Default	none							

**Segment Cards.** Card 1 format used when SEGMENT keyword option is active. Include an additional card for each corresponding pair of segments. This input ends at the next keyword ("\*\*") card.

Card 1d	1	2	3	4	5	6	7	8
Variable	N1	N2	N3	N4				
Type	I	I	I	I				
Default	none	none	none	none				

**VARIABLE**

**DESCRIPTION**

MSURFID

Mesh surface part ID referenced in \*MESH\_SURFACE\_ELEMENT cards.

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
MSURF_S	Identifier of a set of mesh surface part IDs created with a *LSO_ID_SET card, where each mesh surface part ID in the set is referenced in *MESH_SURFACE_ELEMENT cards.
SSID	Segment set ID.
N1, ...	Node IDs defining a segment

**Remarks:**

1. This boundary condition card is also needed for conjugate heat transfer problems with the moving mesh CESE solver.

**\*CESE\_BOUNDARY\_NON\_REFLECTIVE\_OPTION**

Available options are:

MSURF

MSURF\_SET

SET

SEGMENT

Purpose: Define a passive boundary condition for CESE compressible flows. This non-reflective boundary condition (NBC) provides an artificial computational boundary for an open boundary that is passive.

The MSURF and MSURF\_SET options are used when the CESE mesh has been created using \*MESH cards. The SET and SEGMENT cards are used when \*ELEMENT\_SOLID cards are used to define the CESE mesh.

**Surface Part Card.** Card 1 used when the MSURF keyword option is active. Include as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1a	1	2	3	4	5	6	7	8
Variable	MSURFID							
Type	I							
Default	none							

**Surface Part Set Card.** Card 1 used when the MSURF\_SET keyword option is active. Include as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1b	1	2	3	4	5	6	7	8
Variable	MSURF_S							
Type	I							
Default	none							



**Set Card.** Card 1 used when the SET keyword option is active. Include as many cards as necessary. This input ends at the next keyword ("\*\*") card.

Card 1c	1	2	3	4	5	6	7	8
Variable	SSID							
Type	I							
Default	none							

**Segment Cards.** Card 1 used when SEGMENT keyword option is active. Include an additional card for each corresponding pair of segments. This input ends at the next keyword ("\*\*") card.

Card 1d	1	2	3	4	5	6	7	8
Variable	N1	N2	N3	N4				
Type	I	I	I	I				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

MSURFID	Mesh surface part ID referenced in *MESH_SURFACE_ELEMENT cards.
MSURF_S	Identifier of a set of mesh surface part IDs created with an *LSO_ID_SET card, where each mesh surface part ID in the set is referenced in *MESH_SURFACE_ELEMENT cards.
SSID	Segment set ID
N1, N2, ...	Node IDs defining a segment

**Remarks:**

1. This boundary condition is usually imposed on an open surface that is far from the main disturbed flow (the further away, the better), i.e., the flow on that boundary surface should be almost uniform.

2. If any boundary segment has not been assigned a boundary condition by any of the \*CESE\_BOUNDARY\_... cards, then it will automatically be assigned this non-reflective boundary condition.

**\*CESE\_BOUNDARY\_PRESCRIBED\_OPTION**

Available options include:

MSURF

MSURF\_SET

SET

SEGMENT

Purpose: For the CESE compressible flow solver, set boundary values for velocity, density, pressure and temperature. Boundary values are applied at the centroid of elements connected with this boundary. OPTION = SET and OPTION = SEGMENT are for user defined meshes whereas OPTION = MSURF or MSURF\_SET are associated with the automatic volume mesher (See \*MESH keywords).

That is, the MSURF and MSURF\_SET options are used when the CESE mesh has been created using \*MESH cards. The SET and SEGMENT cards are used when \*ELEMENT\_SOLID cards are used to define the CESE mesh.

**Card Sets:**

A set of data cards for this keyword consists of 3 of the following cards:

1. Card 1 specifies the object to which the boundary condition is applied. Its format depends on the keyword option.
2. Card 2 reads in load curve IDs.
3. Card 3 reads in scale factors.

For each boundary condition to be specified include one set of cards. This input ends at the next keyword ("\*") card.

**Surface Part Card.** Card 1 format used when the MSURF keyword option is active.

Card 1a	1	2	3	4	5	6	7	8
Variable	MSURFID	IDCOMP						
Type	I	I						
Default	none	none						

**Surface Part Set Card.** Card 1 format used when the MSURF\_SET keyword option is active.

Card 1b	1	2	3	4	5	6	7	8
Variable	MSURF_S	IDCOMP						
Type	I	I						
Default	none	none						

**Set Card.** Card 1 format used when the SET keyword option is active.

Card 1c	1	2	3	4	5	6	7	8
Variable	SSID	IDCOMP						
Type	I	I						
Default	none	none						

**Segment Card.** Card 1 for SEGMENT keyword option is active.

Card 1d	1	2	3	4	5	6	7	8
Variable	N1	N1	N3	N4	IDCOMP			
Type	I	I	I	I	I			
Default	none	none	none	none	none			

**Load Curve Card.**

Card 2	1	2	3	4	5	6	7	8
Variable	LC_U	LC_V	LC_W	LC_RHO	LC_P	LC_T		
Type	I	I	I	I	I	I		
Remarks	1,2,3	1,2,3	1,2,3	1,2,3	1,2,3	1,2,3		

**Scale Factor Card.**

Card 3	1	2	3	4	5	6	7	8
Variable	SF_U	SF_V	SF_W	SF_RHO	SF_P	SF_T		
Type	F	F	F	F	F	F		
Default	1.0	1.0	1.0	1.0	1.0	1.0		
Remarks	2	2	2	2	2	2		

**VARIABLE****DESCRIPTION**

MSURFID	A mesh surface part ID referenced in *MESH_SURFACE_ELEMENT cards
MSURF_S	Identifier of a set of mesh surface part IDs created with a *LSO_ID_SET card, where each mesh surface part ID in the set is referenced in *MESH_SURFACE_ELEMENT cards.
SSID	Segment set ID
N1, N2, ...	Node ID's defining a segment
IDCOMP	For inflow boundaries in problems involving chemical reacting flows, the chemical mixture of the fluid entering the domain is defined with a *CHEMISTRY_COMPOSITION card with this ID.
LC_U	Load curve ID to describe the x-component of the velocity versus time; see *DEFINE_CURVE.

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
LC_V	Load curve ID to describe the y-component of the velocity versus time.
LC_W	Load curve ID to describe the z-component of the velocity versus time.
LC_RHO	Load curve ID to describe the density versus time.
LC_P	Load curve ID to describe the pressure versus time.
LC_T	Load curve ID to describe the temperature versus time.
SF_U	Scale factor for LC_U (default = 1.0).
SF_V	Scale factor for LC_V (default = 1.0).
SF_W	Scale factor for LC_W (default = 1.0).
SF_RHO	Scale factor for LC_RHO (default = 1.0).
SF_P	Scale factor for LC_P (default = 1.0).
SF_T	Scale factor for LC_T (default = 1.0).

**Remarks:**

1. On each centroid or set of centroids, the variables ( $v_x, v_y, v_z, \rho, P, T$ ) that are given values must be consistent and make the model well-posed (i.e., be such that the solution of the model exists, is unique and physical).
2. If any of the load curves are 0, the corresponding variable will take the constant value of the corresponding scale factor. For instance, if  $LC\_RHO = 0$ , then the constant value of the density for this boundary condition will be  $SF\_RHO$ .
3. If a load ID is -1 for a given variable, then the boundary value for that variable is computed by the solver, and not specified by the user.

\*CESE\_BOUNDARY\_REFLECTIVE\_OPTION

Available options are:

MSURF

MSURF\_SET

SET

SEGMENT

Purpose: Define a reflective boundary condition (RBC) for the CESE compressible flow solver. This boundary condition can be applied on a symmetrical surface or a solid wall of the computational domain.

The MSURF and MSURF\_SET options are used when the CESE mesh has been created using \*MESH cards. The SET and SEGMENT cards are used when \*ELEMENT\_SOLID cards are used to define the CESE mesh.

**Surface Part Card.** Card 1 format used when the MSURF keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1a	1	2	3	4	5	6	7	8
Variable	MSURFID							
Type	I							
Default	none							

**Surface Part Set Card.** Card 1 format used when the MSURF\_SET keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1b	1	2	3	4	5	6	7	8
Variable	MSURF_S							
Type	I							
Default	none							

**Set Card.** Card 1 format used when the SET keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1c	1	2	3	4	5	6	7	8
Variable	SSID							
Type	I							
Default	none							

**Segment Cards.** Card 1 format used when SEGMENT keyword option is active. Include an additional card for each corresponding pair of segments. This input ends at the next keyword ("\*") card.

Card 1d	1	2	3	4	5	6	7	8
Variable	N1	N2	N3	N4				
Type	I	I	I	I				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

MSURFID	Mesh surface part ID referenced in *MESH_SURFACE_ELEMENT cards.
MSURF_S	Identifier of a set of mesh surface part IDs created with a *LSO_ID_SET card, where each mesh surface part ID in the set is referenced in *MESH_SURFACE_ELEMENT cards.
SSID	Segment set ID.
N1, N2, ...	Node IDs defining a segment

**Remarks:**

1. This boundary condition has the same effect as a solid-wall boundary condition for inviscid flows.



\*CESE\_BOUNDARY\_SLIDING\_OPTION

Available options are:

MSURF

MSURF\_SET

SET

SEGMENT

Purpose: Allows nodes of a fluid surface to translate in the main direction of mesh movement. This is useful in piston type applications.

The MSURF and MSURF\_SET options are used when the CESE mesh has been created using \*MESH cards. The SET and SEGMENT cards are used when \*ELEMENT\_SOLID cards are used to define the CESE mesh.

**Surface Part Card.** Card 1 format used when the MSURF keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1a	1	2	3	4	5	6	7	8
Variable	MSURFID							
Type	I							
Default	none							

**Surface Part Set Card.** Card 1 format used when the MSURF\_SET keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1b	1	2	3	4	5	6	7	8
Variable	MSURF_S							
Type	I							
Default	none							

**Set Card.** Card 1 format used when the SET keyword option is active. Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 1c	1	2	3	4	5	6	7	8
Variable	SSID							
Type	I							
Default	none							

**Segment Cards.** Card 1 format used when SEGMENT keyword option is active. Include an additional card for each corresponding pair of segments. This input ends at the next keyword ("\*") card.

Card 1d	1	2	3	4	5	6	7	8
Variable	N1	N2	N3	N4				
Type	I	I	I	I				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

MSURFID	Mesh surface part ID referenced in *MESH_SURFACE_ELEMENT cards.
MSURF_S	Identifier of a set of mesh surface part IDs created with a *LSO_ID_SET card, where each mesh surface part ID in the set is referenced in *MESH_SURFACE_ELEMENT cards.
SSID	Segment set ID
N1, N2, ...	Node IDs defining a segment

\*CESE\_BOUNDARY\_SOLID\_WALL\_OPTION1\_OPTION2

For *OPTION1* the choices are:

- MSURF
- MSURF\_SET
- SET
- SEGMENT

For *OPTION2* the choices are:

- <BLANK>
- ROTAT

Purpose: Define a solid wall boundary condition (SBC) for this CESE compressible flow solver. This boundary condition can be applied at a solid boundary that is the physical boundary for the flow field. For inviscid flow, this will be a slip boundary condition; while for viscous flows, it is a no-slip boundary condition.

The MSURF and MSURF\_SET options are used when the CESE mesh has been created using \*MESH cards. The SET and SEGMENT cards are used when \*ELEMENT\_SOLID cards are used to define the CESE mesh.

**Card Sets.** The following sequence of cards comprises a *single set*. LS-DYNA will continue reading \*CESE\_BOUNDARY\_SOLID\_WALL card sets until the next keyword (“\*”) card is encountered.

**Surface Part Card.** Card 1 format used when the MSURF keyword option is active.

Card 1a	1	2	3	4	5	6	7	8
Variable	MSURFID	LCID	Vx	Vy	Vz	Nx	Ny	Nz
Type	I	I	F	F	F	F	F	F
Default	none	0	0.0	0.0	0.0	0.0	0.0	0.0
Remarks		2, 3	2	2	2	3	3	3

**Surface Part Set Card.** Card 1 format used when the MSURF\_SET keyword option is active.

Card 1b	1	2	3	4	5	6	7	8
Variable	MSURF_S	LCID	Vx	Vy	Vz	Nx	Ny	Nz
Type	I	I	F	F	F	F	F	F
Default	none	0	0.0	0.0	0.0	0.0	0.0	0.0
Remarks		2, 3	2	2	2	3	3	3

**Set Card.** Card 1 format used when the SET keyword option is active.

Card 1c	1	2	3	4	5	6	7	8
Variable	SSID	LCID	Vx	Vy	Vz	Nx	Ny	Nz
Type	I	I	F	F	F	F	F	F
Default	none	0	0.0	0.0	0.0	0.0	0.0	0.0
Remarks		2, 3	2	2	2	3	3	3

**Segment Card.** Card 1 format used when SEGMENT keyword option is active.

Card 1d	1	2	3	4	5	6	7	8
Variable	N1	N2	N3	N4	LCID	Vx	Vy	Vz
Type	I	I	I	I	I	F	F	F
Default	none	none	none	none	0	0.0	0.0	0.0
Remarks					2, 3	2	2	2

**Rotating Axis Card.** Additional card read when the ROTAT keyword option is set.

Card 2	1	2	3	4	5	6	7	8
Variable	Nx	Ny	Nz					
Type	F	F	F					
Default	0.0	0.0	0.0					
Remarks	3	3	3					

**VARIABLE****DESCRIPTION**

MSURFID	Mesh surface part ID referenced in *MESH_SURFACE_ELEMENT cards.
MSURF_S	Identifier of a set of mesh surface part IDs created with a *LSO_ID_SET card, where each mesh surface part ID in the set is referenced in *MESH_SURFACE_ELEMENT cards.
SSID	Segment set ID
N1, N2, ...	Node ID's defining a segment
LCID	Load curve ID to define this solid wall boundary movement

If **OPTION2 = <BLANK>**:

$V_x, V_y, V_z$	velocity vector of the solid wall: LCID.EQ.0: it is defined by $(V_x, V_y, V_z)$ itself; LCID.NE.0: it will be defined by both of the load curve and $(V_x, V_y, V_z)$ ; $N_x, N_y, N_z$ are not used in this case.
-----------------	---

If **OPTION2 = ROTAT**:

$V_x, V_y, V_z$	x-,y- & z-coordinates of a point on the rotating axis
$N_x, N_y, N_z$	Unit vector of the rotating axis (for the 2D case, this is not used). The rotating frequency (Hz) is given by the load curve.

**Remarks:**

1. In this solid-wall condition (SBC), the boundary movement can only be in the tangential direction of the wall and should not affect the fluid domain size and mesh during the calculation, otherwise an FSI or moving mesh solver should be used. Also, this moving SBC only affects viscous flows (no-slip BC).
2. If  $LCID = 0$  and  $V_x = V_y = V_z = 0.0$  (default), this will be a regular solid wall BC.
3. For rotating SBC,  $LCID > 0$  must be used to define the rotating speed frequency (Hz). Also, in the 2D case,  $(N_x, N_y, N_z)$  does not need to be defined because it is not needed.

**\*CESE\_CHEMISTRY\_D3PLOT**

Purpose: Cause mass fractions of the listed chemical species to be added to the CESE d3plot output. This is only used when chemistry is being solved with the CESE solver.

Card 1	1	2	3	4	5	6	7	8
Variable	MODELID							
Type	I							
Default	none							

**Species Cards.** Include one card for each species to be included in the d3plot database. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	SPECIES							
Type	A							

**VARIABLE****DESCRIPTION**

MODELID

Identifier of a Chemkin-compatible chemistry model.

SPECIES

Name of a chemical species that is defined in the chemistry model identified by MODELID (see \*CHEMISTRY\_MODEL).

**\*CESE\_CONTROL\_LIMITER**

Purpose: Sets some stability parameters used in the CESE scheme for this CESE compressible flow solver.

Card 1	1	2	3	4	5	6	7	8
Variable	IDLMT	ALFA	BETA	EPSR				
Type	I	F	F	F				
Default	0	0.0	0.0	0.0				
Remarks		1	2	3				

**VARIABLE****DESCRIPTION**

IDLMT	Set the stability limiter option (See CESE theory manual): EQ.0: limiter format 1 (Re-weighting). EQ.1: limiter format 2 (Relaxing).
ALFA	Re-weighting coefficient (See CESE theory manual)
BETA	Numerical viscosity control coefficient (See CESE theory manual)
EPSR	Stability control coefficient (See CESE theory manual)

**Remarks:**

1.  $\alpha \geq 0$ ; larger values give more stability, but less accuracy. Usually  $\alpha = 2.0$  or  $4.0$  will be enough for normal shock problems.
2.  $0 \leq \beta \leq 1$ ; larger values give more stability. For problems with shock waves,  $\beta = 1.0$  is recommended.
3.  $\epsilon \geq 0$ ; larger values give more stability, but less accuracy.



**\*CESE\_CONTROL\_MESH\_MOV**

Purpose: For moving mesh CESE, this keyword is used to choose the type of algorithm to be used for calculating mesh movement.

Card 1	1	2	3	4	5	6	7	8
Variable	MMSH	LIM_ITER	RELTOL	ABSTOL				
Type	I	I	F	F				
Default	1	100	1.0e-3	1.0e-3				

**VARIABLE****DESCRIPTION**

MMSH

Mesh motion selector:

EQ.1: mesh moves using an implicit ball-vertex spring method.

EQ.9: the IDW scheme is used to move the mesh.

LIM\_ITER

Maximum number of linear solver iterations for the ball-vertex linear system.

RELTOL

Relative tolerance to use as a stopping criterion for the iterative linear solver (conjugate gradient solver with diagonal scaling preconditioner).

ABSTOL

Absolute tolerance measure for the size of mesh displacement changes to use as a stopping criterion for the iterative linear solver.

**\*CESE\_CONTROL\_SOLVER**

Purpose: Set general purpose control variables for the CESE compressible flow solver.

Card 1	1	2	3	4	5	6	7	8
Variable	ICESE	IFLOW	IGEOM	IFRAME	MIXID			
Type	I	I	I	I	I			
Default	0	0	none	0	none			
Remarks			1, 2					

**VARIABLE****DESCRIPTION**

ICESE

Sets the framework of the CESE solver.

EQ.0: Fixed Eulerian

EQ.100: Moving Mesh FSI

EQ.200: Immersed boundary FSI

IFLOW

Sets the compressible flow types:

EQ.0: Viscous flows (laminar)

EQ.1: Inviscid flows

IGEOM

Sets the geometric dimension:

EQ.2: Two-dimensional (2D) problem

EQ.3: Three-dimensional (3D) problem

EQ.101: 2D axisymmetric

IFRAME

Choose the frame of reference:

EQ.0: Usual non-moving reference frame (default).

EQ.1000: Non-inertial rotating reference frame.

MIXID

Chemistry model ID that defines the chemical species to include in the mixing model (see \*CHEMISTRY\_MODEL). The species information is given through the model's card specifying the Chemkin-compatible input.

**Remarks:**

1. If the user wants to use the 2D (IGEOM = 2) or 2D axisymmetric (IGEOM = 101) solver, the mesh should only be distributed in the  $x$ - $y$  plane (one layer) with the boundary conditions given only at the  $x$ - $y$  domain boundaries. Otherwise, a warning message will be given and the 3D solver will be triggered instead.
2. The 2D axisymmetric case will work only if the 2D mesh and corresponding boundary conditions are properly defined, with the  $x$  and  $y$  coordinates corresponding to the axial and radial directions respectively.

**\*CESE\_CONTROL\_TIMESTEP**

Purpose: Sets the time-step control parameters for the CESE compressible flow solver.

Card 1	1	2	3	4	5	6	7	8
Variable	IDDT	CFL	DTINT					
Type	I	F	F					
Default	0	0.9	1.0E-3					

**VARIABLE****DESCRIPTION**

IDDT

Sets the time step option:

EQ.0: Fixed time step size (DTINT, i.e., given initial time step size)

NE.0: the time step size will be calculated based on the given CFL-number and the flow solution at the previous time step.

CFL

CFL number (Courant–Friedrichs–Lewy condition)  
(  $0.0 < CFL \leq 1.0$  )

DTINT

Initial time step size

**\*CESE\_DATABASE\_ELOUT**

Purpose: This keyword enables the output of CESE data on elements. If more than one element set is defined, then several output files will be generated.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	0	0.						

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	ELSID							
Type	I							
Default	none							

**VARIABLE****DESCRIPTION**

OUTLV	Determines if the output file should be dumped. EQ.0: No output file is generated. EQ.1: The output file is generated.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the CESE timestep will be used.
ELSID	Solid Elements Set ID.

**Remarks:**

1. The file name for this database is cese\_elout.dat.

**\*CESE\_DATABASE\_FLUXAVG**

Purpose: This keyword enables the output of CESE data on segment sets. If more than one segment set is defined, then several output files will be generated.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	0	0.						

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	ELSID							
Type	I							
Default	none							

**VARIABLE****DESCRIPTION**

OUTLV	Determines if the output file should be dumped. EQ.0: No output file is generated. EQ.1: The output file giving the average fluxes is generated.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the CESE timestep will be used.
ELSID	Solid Elements Set ID.

**Remarks:**

1. The file names for this database is cese\_fluxavg.dat.

\*CESE\_DATABASE\_FSIDRAG

Purpose: This keyword enables the output of the total fluid pressure force applied on solid parts in FSI problems at every time step.

Output Options Card.

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV							
Type	I							
Default	0							

**VARIABLE**

**DESCRIPTION**

OUTLV

Determines if the output file should be dumped.

EQ.0: No output file is generated.

EQ.1: The output file giving the pressure forces is generated.

**Remarks:**

1. The file names for this database are cese\_dragsol.dat, cese\_dragshell.dat, cese\_dragsol2D.dat and cese\_dragbeam.dat .depending on what kind of solid is used.

**\*CESE\_DATABASE\_POINTOUT**

Purpose: This keyword enables the output of CESE data on points.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	PSID	DTOUT	PSTYPE	VX	VY	VZ		
Type	I	F	I	F	F	F		
Default	0	0.	0	0.	0.	0.		

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	PID	X	Y	Z				
Type	I	F	F	F				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

PSID	Point Set ID.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the CESE timestep will be used.
PSTYPE	Point Set type : EQ.0: Fixed points. EQ.1: Tracer points using prescribed velocity. EQ.2: Tracer points using fluid velocity.
VX, VY, VZ	Constant velocities to be used when PSTYPE = 1
PID	Point ID
X, Y, Z	Point initial coordinates



**Remarks:**

1. The file name for this database is ces\_e\_pointout.dat.

**\*CESE\_DATABASE\_SSETDRAG**

Purpose: This keyword enables the output of CESE drag forces on segment sets. If more than one segment set is defined, then several output files will be generated.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	0	0.						

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	ELSID							
Type	I							
Default	none							

**VARIABLE****DESCRIPTION**

OUTLV	Determines if the output file should be dumped. EQ.0: No output file is generated. EQ.1: The output file giving the average fluxes is generated.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the CESE timestep will be used.
ELSID	Solid Elements Set ID.

**Remarks:**

1. The file name for this database is *cese\_ssetdrag.dat*.

2. In order for the friction drag to give consistent results, special care must be given to the mesh close to the solid wall boundary (Good capturing of the boundary layer behavior). A very fine structured mesh is recommended.

**\*CESE\_DEFINE\_NONINERTIAL**

Purpose: Define the CESE problem domain as a non-inertial rotating frame that rotates at a constant rate. This is used in rotating problems such as spinning cylinders, wind turbines and turbo machinery.

Card 1	1	2	3	4	5	6	7	8
Variable	FREQ	LCID	PID	Nx	Ny	Nz		
Type	F	I	I	F	F	F		
Default	none	0	none	none	none	none		

Card 2	1	2	3	4	5	6	7	8
Variable	L	R	RELV					
Type	F	F	I					
Default	none	none	0					

**VARIABLE****DESCRIPTION**

FREQ	Frequency of rotation.
LCID	Load curve ID for scaling factor of FREQ.
PID	Starting point ID for the reference frame (See *CESE_DEFINE_-POINT).
Nx, Ny, Nz	Rotating axis direction.
L	Length of rotating frame.
R	Radius of rotating frame.

---

VARIABLE	DESCRIPTION
RELV	Velocity display mode: EQ.0: Relative velocity, only the non-rotating components of the velocity are output. EQ.1: Absolute velocity is output.

**\*CESE\_DEFINE\_POINT**

Purpose: Define points to be used by the CESE solver.

**Point Cards.** Include one card for each point. This input ends at the next keyword ("\*\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	NID	X	Y	Z				
Type	I	F	F	F				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

NID	Identifier for this point.
X, Y, Z	Coordinates of the point.

\*CESE\_DRAG

Purpose: Provide the far-field (or free-stream) fluid pressure.

Card 1	1	2	3	4	5	6	7	8
Variable	PRESS							
Type	F							

**VARIABLE**

**DESCRIPTION**

PRESS

Value of the free-stream fluid pressure (in units used by the current problem).

**\*CESE\_EOS\_CAV\_HOMOG\_EQUILIB**

Purpose: Define the coefficients in the equation of state (EOS) for the homogeneous equilibrium cavitation model.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	EOSID	$\rho_{\text{vap}}$	$\rho_{\text{liq}}$	$a_{\text{vap}}$	$a_{\text{liq}}$	$\mu_{\text{vap}}$	$\mu_{\text{liq}}$	$P_{\text{SatVap}}$
Type	I	F	F	F	F	F	F	F
Default	none	0.8	880.0	334.0	1386.0	1.435e-5	1.586e-4	1.2e+4

**VARIABLE****DESCRIPTION**

EOSID	Equation of state identifier
$\rho_{\text{vap}}$	density of the saturated vapor
$\rho_{\text{liq}}$	density of the saturated liquid
$a_{\text{vap}}$	sound speed of the saturated vapor
$a_{\text{liq}}$	sound speed of the saturated liquid
$\mu_{\text{vap}}$	dynamic viscosity of the vapor
$\mu_{\text{liq}}$	dynamic viscosity of the liquid
$P_{\text{SatVap}}$	pressure of the saturated vapor

**Remarks:**

1. Once a cavitation EOS is used, the cavitation flow solver will be triggered.
2. In this homogeneous equilibrium cavitation model, a barotropic equation of state is used. This model can be used in small scale & high speed cavitation flows, and it is not good for large-scale, low-speed cavitation calculations.



\*CESE\_EOS\_IDEAL\_GAS

Purpose: Define the coefficients Cv and Cp in the equation of state for an ideal gas in the CESE fluid solver.

Card 1	1	2	3	4	5	6	7	8
Variable	EOSID	Cv	Cp					
Type	I	F	F					
Default	none	717.5	1004.5					

<u>VARIABLE</u>	<u>DESCRIPTION</u>
EOSID	Equation of state identifier
Cv	Specific heat at constant volume
Cp	Specific heat at constant pressure

**Remarks:**

1. As with other solvers in LS-DYNA, the user is responsible for unit consistency. For example, if a user wants to use dimensionless variables, Cv & Cp above also should be replaced by the corresponding dimensionless ones.

**\*CESE\_INITIAL**

Purpose: Specify constant initial conditions (ICs) for flow variables at the centroid of each fluid element.

Card 1	1	2	3	4	5	6	7	8
Variable	U	V	W	RH	P	T		
Type	F	F	F	F	F	F		
Default	0	0.0	0.0	1.225	0.0	0.0		

**VARIABLE****DESCRIPTION**

U, V, W	x-, y-, z-velocity components respectively
RHO	density $\rho$
P	pressure P
T	temperature T

**Remarks:**

1. Usually, only two of  $\rho$ , P & T are needed to be specified (besides the velocity). If all three are given, only  $\rho$  and P will be used.
2. These initial condition will be applied in those elements that have not been assigned a value by \*CESE\_INITIAL\_OPTION cards for individual elements or sets of elements.

**\*CESE\_INITIAL\_OPTION**

Available options include:

SET

ELEMENT

Purpose: Specify initial conditions for the flow variables at the centroid of each element in a set of elements or at the centroid of a single element.

Include as many cards as needed. This input ends at the next keyword (“\*”) card.

Card 1	1	2	3	4	5	6	7	8
Variable	EID/ESID	U	V	W	RHO	P	T	
Type	I	F	F	F	F	F	F	
Default	none	0.0	0.0	0.0	1.225	0.0	0.0	
Remarks					1	1	1	

**VARIABLE****DESCRIPTION**

EID/ESID	Solid element ID ( <b>EID</b> ) or solid element set ID ( <b>ESID</b> )
U, V, W	x-, y-, z-velocity components respectively
RHO	density
P	pressure
T	temperature

**Remarks:**

1. Usually, only two of  $\rho$ , P & T are needed to be specified (besides the velocity). If all three are given, only  $\rho$  and P will be used.
2. The priority of this card is higher than \*CESE\_INITIAL, i.e., if an element is assigned an initial value by this card, \*CESE\_INITIAL will no longer apply to that element.

**\*CESE\_INITIAL\_CHEMISTRY**

Purpose: Initializes the chemistry and fluid state in every element of the CESE mesh that has not already been initialized by one of the other \*CESE\_INITIAL\_CHEMISTRY cards. This is only used when chemistry is being solved with the CESE solver.

Card 1	1	2	3	4	5	6	7	8
Variable	CHEMID	COMPID						
Type	I	I						
Default	none	none						

Card 2	1	2	3	4	5	6	7	8
Variable	UIC	VIC	WIC	RHOIC	PIC	TIC	HIC	
Type	F	F	F	F	F	F	F	
Default	none	none	none	none	none	none	none	

**VARIABLE****DESCRIPTION**

CHEMID	Identifier of chemistry control card to use.
COMPID	Identifier of chemical composition to use.
UIC	X-component of the fluid velocity.
VIC	Y-component of the fluid velocity.
WIC	Z-component of the fluid velocity.
RHOIC	Initial fluid density.
PIC	Initial fluid pressure.
TIC	Initial fluid temperature.

---

VARIABLE	DESCRIPTION
HIC	Initial fluid enthalpy. However, when CHEMID refers to a ZND 1-step reaction card, this is the progressive variable (degree of combustion).

**\*CESE\_INITIAL\_CHEMISTRY\_ELEMENT**

Purpose: Initializes the chemistry and fluid state in every element of the list of CESE elements. This is only used when chemistry is being solved with the CESE solver.

Card 1	1	2	3	4	5	6	7	8
Variable	CHEMID	COMPID						
Type	I	I						
Default	none	none						

Card 2	1	2	3	4	5	6	7	8
Variable	UIC	VIC	WIC	RHOIC	PIC	TIC	HIC	
Type	F	F	F	F	F	F	F	
Default	none	none	none	none	none	none	none	

**Element List Card.** Provide as many cards as necessary. This input ends at the next keyword ("\*\*") card.

Card 3	1	2	3	4	5	6	7	8
Variable	ELE1	ELE2	ELE3	ELE4	ELE5	ELE6	ELE7	ELE8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**VARIABLE****DESCRIPTION**

CHEMID Identifier of chemistry control card to use.

COMPID Identifier of chemical composition to use.

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
UIC	X-component of the fluid velocity.
VIC	Y-component of the fluid velocity.
WIC	Z-component of the fluid velocity.
RHOIC	Initial fluid density.
PIC	Initial fluid pressure.
TIC	Initial fluid temperature.
HIC	Initial fluid enthalpy. However, when CHEMID refers to a ZND 1-step reaction card, this is the progressive variable (degree of combustion).
ELE1, ...	User element numbers to initialize.

**\*CESE\_INITIAL\_CHEMISTRY\_PART**

Purpose: Initializes the chemistry and fluid state in every element of the specified CESE part that has not already been initialized by \*CESE\_INITIAL\_CHEMISTRY\_ELEMENT or \*CESE\_INITIAL\_CHEMISTRY\_SET cards. This is only used when chemistry is being solved with the CESE solver.

Card 1	1	2	3	4	5	6	7	8
Variable	PARTID	CHEMID	COMPID					
Type	I	I	I					
Default	none	none	none					

Card 2	1	2	3	4	5	6	7	8
Variable	UIC	VIC	WIC	RHOIC	PIC	TIC	HIC	
Type	F	F	F	F	F	F	F	
Default	none	none	none	none	none	none	none	

**VARIABLE****DESCRIPTION**

PARTID	Identifier of the CESE part on which to initialize.
CHEMID	Identifier of chemistry control card to use.
COMPID	Identifier of chemical composition to use.
UIC	X-component of the fluid velocity.
VIC	Y-component of the fluid velocity.
WIC	Z-component of the fluid velocity.
RHOIC	Initial fluid density.
PIC	Initial fluid pressure.
TIC	Initial fluid temperature.



---

VARIABLE	DESCRIPTION
HIC	Initial fluid enthalpy. However, when CHEMID refers to a ZND 1-step reaction card, this is the progressive variable (degree of combustion).

**\*CESE\_INITIAL\_CHEMISTRY\_SET**

Purpose: Initializes the chemistry and fluid state in every element of the specified element set in the CESE mesh that has not already been initialized by \*CESE\_INITIAL\_CHEMISTRY\_ELEMENT cards. This is only used when chemistry is being solved with the CESE solver.

Card 1	1	2	3	4	5	6	7	8
Variable	SETID	CHEMID	COMPID					
Type	I	I	I					
Default	none	none	none					

Card 2	1	2	3	4	5	6	7	8
Variable	UIC	VIC	WIC	RHOIC	PIC	TIC	HIC	
Type	F	F	F	F	F	F	F	
Default	none	none	none	none	none	none	none	

**VARIABLE****DESCRIPTION**

SETID Identifier of the CESE element set to initialize.

CHEMID Identifier of chemistry control card to use.

COMPID Identifier of chemical composition to use.

UIC X-component of the fluid velocity.

VIC Y-component of the fluid velocity.

WIC Z-component of the fluid velocity.

RHOIC Initial fluid density.

PIC Initial fluid pressure.

TIC Initial fluid temperature.

---

VARIABLE	DESCRIPTION
HIC	Initial fluid enthalpy. However, when CHEMID refers to a ZND 1-step reaction card, this is the progressive variable (degree of combustion).

**\*CESE\_MAT\_000**

Purpose: Define the fluid (gas) properties in a viscous flow for the CESE solver.

**Material Definition Cards.** Include one card for each instance of this material type. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	MID	MU	K					
Type	I	F	F					
Default	none	none	none					

**VARIABLE****DESCRIPTION**

MID	Material identifier
MU	Fluid dynamic viscosity. For Air at 15 °C, $MU = 1.81 \times 10^{-5} \text{ kg/ms}$
K	Thermal conductivity of the fluid

**Remarks:**

1. The viscosity is only used viscous flows, so for inviscid flows, it is not necessary to define it. The thermal conductivity is only used to calculate the heat transfer between the structure and the thermal solver when coupling is activated.
2. As with other solvers in LS-DYNA, the user is responsible for unit consistency. For example, if dimensionless variables are used, MU should be replaced by the corresponding dimensionless one.

**\*CESE\_MAT\_001( \_GAS)**

Purpose: Define the fluid (gas) properties in a viscous flow for the CESE solver.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	MID	C1	C2	PRND				
Type	I	F	F	F				
Default	none	1.458E-6	110.4	0.72				

**VARIABLE****DESCRIPTION**

MID	Material identifier
C1, C2	Two coefficients in the Sutherland's formula for viscosity, i.e., $\mu = \frac{C_1 T^{\frac{3}{2}}}{T + C_2}$ where $C_1$ and $C_2$ are constants for a given gas. For example, for air at moderate temperatures, $C_1 = 1.458 \times 10^{-6} \text{ kg/msK}^{1/2}, \quad C_2 = 110.4 \text{ K}$
PRND	The Prandtl Number (used to determine the coefficient of thermal conductivity). It is approximately constant for most gases. For air at standard conditions PRND = 0.72.

**Remarks:**

1. C1 and C2 are only used to calculate the viscosity in viscous flows, so for inviscid flows, this material card is not needed. The Prandtl number is used to extract the thermal conductivity, which is used when thermal coupling with the structure is activated.
2. As with other solvers in LS-DYNA, the user is responsible for unit consistency. For example, if dimensionless variables are used,  $C_1$  and  $C_2$  should be replaced by the corresponding dimensionless ones.

\*CESE\_MAT\_002

Purpose: Define the fluid (gas) properties in a viscous flow for the CESE solver.

**Material Definition Cards.** Include one card for each instance of this material type. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	MID	MU0	SMU	K0	SK			
Type	I	F	F	F	F			
Default	none	1.716E-5	111.	0.0241	194.0			

VARIABLE	DESCRIPTION
----------	-------------

MID	Material identifier
MU0 / SMU	<p>Two coefficients appearing in the equation derived by combining Sutherland’s formula with the Power law for dilute gases:</p> $\frac{\mu}{\mu_0} = \left(\frac{T}{T_0}\right)^{3/2} \frac{T_0 + S_\mu}{T + S_\mu}.$ <p>In the above, MU0 and SMU are parameters characterizing a particular gas. For example, for air at moderate temperatures,</p> $\mu_0 = 1.716 \times 10^{-5} \text{Ns/m}^2, \quad S_\mu = 111 \text{ K}$
K0/SK	<p>Two coefficients appearing in the equation derived by combining Sutherland’s formula with the Power law for dilute gases:</p> $\frac{k}{k_0} = \left(\frac{T}{T_0}\right)^{3/2} \frac{T_0 + S_k}{T + S_k}$ <p>In the above, K0 and SK are parameters characterizing a particular gas. For example, for air at moderate temperatures,</p> $k_0 = 0.0241 \text{ W/m}, \quad S_k = 194 \text{ K}$

**Remarks:**

1. The viscosity is only used viscous flows, so for inviscid flows, it is not necessary to define it. The thermal conductivity is only used to calculate the heat transfer between the structure and the thermal solver when coupling is activated.

2. As with other solvers in LS-DYNA, the user is responsible for unit consistency. For example, if dimensionless variables are used, MU should be replaced by the corresponding dimensionless one.

**\*CESE\_PART**

Purpose: Define CESE solver parts, i.e., connect CESE material and EOS information.

**Part Cards.** Include one card for each CESE part. This input ends at the next keyword ("\*\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	MID	EOSID					
Type	I	I	I					
Default	none	none	none					

**VARIABLE****DESCRIPTION**

PID	Part identifier (must be different from any PID on a *PART card)
MID	Material identifier defined by a *CESE_MAT... card
EOSID	Equation of state identifier defined by a *CESE_EOS... card

**Remarks:**

1. Since material coefficients are only used in viscous flows, the MID can be left blank for inviscid flows.



# \*CHEMISTRY

The keyword \*CHEMISTRY is used to access chemistry databases that include Chemkin-based descriptions of a chemical model, as well as to select a method of solving the model. The keyword cards in this section are defined in alphabetical order:

- \*CHEMISTRY\_COMPOSITION
- \*CHEMISTRY\_CONTROL\_0D
- \*CHEMISTRY\_CONTROL\_1D<sup>†</sup>
- \*CHEMISTRY\_CONTROL\_CSP
- \*CHEMISTRY\_CONTROL\_FULL
- \*CHEMISTRY\_CONTROL\_PYROTECHNIC<sup>†</sup>
- \*CHEMISTRY\_CONTROL\_TBX
- \*CHEMISTRY\_CONTROL\_ZND<sup>†</sup>
- \*CHEMISTRY\_DET\_INITIATION<sup>†</sup>
- \*CHEMISTRY\_MODEL
- \*CHEMISTRY\_PATH
- \*CHEMISTRY\_PROPELLANT\_PROPERTIES<sup>†</sup>

†: Card may be used only once in a given model

An additional option “\_TITLE” may be appended to all \*CHEMISTRY keywords. If this option is used, then an 80 character string is read as a title from the first card of that keyword's input. At present, LS-DYNA does not make use of the title. Inclusion of titles gives greater clarity to input decks.

In order to use one of the chemistry solvers, the input must include at least one \*CHEMISTRY\_MODEL card. For each spatial region containing a different chemical composition, at least one \*CHEMISTRY\_COMPOSITION card is required.

The \*CHEMISTRY\_CONTROL\_0D card is intended to be used in a standalone fashion to verify the validity of a given chemistry model. This model includes the total number of species and all elementary reactions with their Arrhenius rate parameters. For instance, this solver could be used to check the induction time of the model.

The \*CHEMISTRY\_CONTROL\_1D, \*CHEMISTRY\_DET\_INITIATION, and \*CHEMISTRY\_CONTROL\_ZND cards are intended to provide a one-dimensional initialization to a 2D or 3D chemically-reacting flow.

In order to perform a full, general purpose chemistry calculation in 2D or 3D, the \*CHEMISTRY\_CONTROL\_FULL card should be used.

The \*CHEMISTRY\_CONTROL\_CSP card is an option for reducing the number of species and reactions that are used in a general purpose chemistry calculation. Other reduction mechanisms are planned for the future.

An airbag inflator model is available with \*CHEMISTRY\_CONTROL\_PYROTECHNIC along with \*CHEMISTRY\_PROPELLANT\_PROPERTIES and a chemistry model that is referenced via three chemical compositions. This involves zero-dimensional modeling, with support only for the NaN<sub>3</sub>/Fe<sub>2</sub>O<sub>3</sub> granular explosive.

The \*CHEMISTRY\_CONTROL\_TBX card is intended for use only in a stochastic particle model, where the \*STOCHASTIC\_TBX\_PARTICLES card is used.

## \*CHEMISTRY\_COMPOSITION

Purpose: Provides a general way to specify a chemical composition via a list of species mole numbers in the context of a Chemkin database model.

Card 1	1	2	3	4	5	6	7	8
Variable	ID	MODELID						
Type	I	I						
Default	none	none						

**Species List Card.** Provide as many cards as necessary. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	MOLFR	SPECIES						
Type	F	A						
Default	none	none						

**VARIABLE****DESCRIPTION**

ID	A unique identifier among all chemistry compositions.
MODELID	Identifier of a Chemkin-compatible chemistry model.
MOLFR	The number of moles corresponding to the species named in the SPECIES field. But if used with a *STOCHASTIC_TBX_PARTICLES card, it is the molar concentration of the species (in units of moles/[length] <sup>3</sup> , where "[length]" is the user's length unit).
SPECIES	The Chemkin-compatible name of a chemical species that is defined in the chemistry model identified by MODELID (see *CHEMISTRY_MODEL).

**\*CHEMISTRY\_CONTROL\_0D**

Purpose: Performs a zero-dimensional isotropic chemistry calculation that operates standalone (does not call the CESE solver). This is for ISOBARIC or ISOCHORIC cases.

Card 1	1	2	3	4	5	6	7	8
Variable	ID	COMPID	SOLTYP	PLOTDT	CSP_SEL			
Type	I	I	I	F	I			
Default	none	none	none	1.0e-6	0			
Remarks					1			

Card 2	1	2	3	4	5	6	7	8
Variable	DT	TLIMIT	TIC	PIC	RIC	EIC		
Type	F	F	F	F	F	F		
Default	none	none	none	none	none	none		

**CSP Parameters Card.** Include cards for each chemical species in the following format when CSP\_SEL.GT.0. This input ends at the next keyword ("\*") card.

Card 3	1	2	3	4	5	6	7	8
Variable	AMPL	YCUT						
Type	F	F						
Default	none	none						

**VARIABLE****DESCRIPTION**

ID

Identifier for this 0D computation.

VARIABLE	DESCRIPTION
COMPID	Chemical composition identifier of composition to use.
SOLTYP	Type of 0D calculation: EQ.1: Isochoric EQ.2: Isobaric
PLOTDT	Simulation time interval for output both to the screen and to the isocom.csv file. This file can be loaded into LS-PREPOST for curve plotting using the x-y plot facility.
CSP_SEL	CSP solver option: EQ.0: Do not use the CSP solver, and ignore the AMPL and YCUT parameters (default). GT.0: Use the CSP solver, with the AMPL and YCUT parameters.
DT	Initial time step
TLIMIT	Time limit for the simulation
TIC	Initial temperature
PIC	Initial pressure
RIC	Initial density
EIC	Initial internal energy
AMPL	Relative accuracy for the mass fraction of a chemical species in the Chemkin input file.
YCUT	Absolute accuracy for the mass fraction of a chemical species in the Chemkin input file.

**Remarks:**

1. If CSP\_SEL.GT.0, then instead of using the full chemistry solver, the computational singular perturbation (CSP) method solver is used.

**\*CHEMISTRY\_CONTROL\_1D**

Purpose: Loads a previously-computed one-dimensional detonation. It is then available for use in the CESE solver for initializing a computation. In the product regions, this card overrides the initialization of the \*CESE\_INITIAL\_CHEMISTRY\_... cards.

Card 1	1	2	3	4	5	6	7	8
Variable	ID	XYZD	DETDIR	CSP_SEL				
Type	I	F	I	I				
Default	none	none	none	0				
Remarks				1				

**One-Dimensional Solution LSDA Input File Card.**

Card 2	1	2	3	4	5	6	7	8
Variable	FILE							
Type	A							

**CSP Parameters Card** Include cards for each chemical species in the following format when  $CSP\_SEL \geq 0$ . This input ends at the next keyword ("\*") card.

Card 3	1	2	3	4	5	6	7	8
Variable	AMPL	YCUT						
Type	F	F						
Default	none	none						

**VARIABLE****DESCRIPTION**

ID

Identifier for this one-dimensional detonation solution.

XYZD

Position of the detonation front in the DETDIR direction.

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
DETDIR	Detonation propagation direction (1 => X; 2 => Y; 3 => Z)
CSP_SEL	CSP solver option: EQ.0: Do not use the CSP solver, and ignore the AMPL and YCUT parameters (default). GT.0: Use the CSP solver, with the AMPL and YCUT parameters.
FILE	Name of the LSDA file containing the one-dimensional solution.
AMPL	Relative accuracy for the mass fraction of a chemical species in the Chemkin input file.
YCUT	Absolute accuracy for the mass fraction of a chemical species in the Chemkin input file.

**Remarks:**

1. If CSP\_SEL.GT.0, then instead of using the full chemistry solver, the computational singular perturbation (CSP) method solver is used.

**\*CHEMISTRY\_CONTROL\_CSP**

Purpose: Computes reduced chemistry for a specified Chemkin chemistry model using the Computational Singular Perturbation (CSP) method. This card can be used for general-purpose chemical reaction calculations.

Card 1	1	2	3	4	5	6	7	8
Variable	ID	IERROPT						
Type	I	I						
Default	none	none						

**CSP Parameters Card.** Include cards for each chemical species in the following format as indicated by the value of IERROPT. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	AMPL	YCUT						
Type	F	F						
Default	none	none						

**VARIABLE****DESCRIPTION**

ID	Identifier for this computational singular perturbation solver.
IERROPT	Selector: EQ.0: AMPL and YCUT values for all chemical species are required. EQ.1: One CSP Parameter Card should be provided, and it will be used for all species.
AMPL	Relative accuracy for the mass fraction of a chemical species in the Chemkin input file.
YCUT	Absolute accuracy for the mass fraction of a chemical species in the Chemkin input file.



**\*CHEMISTRY\_CONTROL\_FULL**

Purpose: Computes the full chemistry specified by a Chemkin chemistry model. This card can be used for general-purpose chemical reaction calculations.

Card 1	1	2	3	4	5	6	7	8
Variable	ID	ERRLIM						
Type	I	F						
Default	none	none						

**VARIABLE****DESCRIPTION**

ID	Identifier for this full chemistry calculation.
ERRLIM	Error tolerance for the full chemistry calculation.

**\*CHEMISTRY\_CONTROL\_PYROTECHNIC**

Purpose: Provide the required properties of a propellant deflagration model for airbag inflation.

**Inflator Chamber Parameter Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	COMP1ID	VOL1	AREA1	CD1	P1	T1	DELP1	TFLAME
Type	I	F	F	F	F	F	F	F
Default	none	none	none	none	none	none	none	none

**Inflator Plenum Parameter Card.**

Card 2	1	2	3	4	5	6	7	8
Variable	COMP2ID	VOL2	AREA2	CD2	P2	T2	DELP2	TRUNTIME
Type	I	F	F	F	F	F	F	F
Default	none	none	none	none	none	none	none	none

**Inflator Airbag Parameter Card.**

Card 3	1	2	3	4	5	6	7	8
Variable	COMP3ID	VOL3	P3	T3	PTIME			
Type	I	F	F	F	F			
Default	none	none	none	none	1.0e-4			

**Inflator Output File Card.**

Card 4	1	2	3	4	5	6	7	8
Variable	FILE							
Type	A							

<b>VARIABLE</b>	<b>DESCRIPTION</b>
COMP1ID	Chemical composition identifier of composition to use in the chamber.
VOL1	Volume of the chamber.
AREA1	Area of the chamber.
CD1	Discharge coefficient of the chamber.
P1	Pressure in the chamber.
T1	Temperature in the chamber.
DELP1	Rupture pressure in the chamber.
TFLAME	Adiabatic flame temperature.
COMP2ID	Chemical composition identifier of composition to use in the plenum.
VOL2	Volume of the plenum.
AREA2	Area of the plenum.
CD2	Discharge coefficient of the plenum.
P2	Pressure in the plenum.
T2	Temperature in the plenum.
DELP2	Rupture pressure in the plenum.
TRUNTIME	Total run time.
COMP3ID	Chemical composition identifier of composition to use in the airbag.
VOL3	Volume of the airbag.

<b>VARIABLE</b>	<b>DESCRIPTION</b>
P3	Pressure in the airbag.
T3	Temperature in the airbag.
PTIME	Time interval for output of time history data to FILE.
FILE	Name of the file in which to write the results of the inflator simulation. Two load curves are written out to this file: mass flow rate and total temperature as a function of time.

\*CHEMISTRY\_CONTROL\_TBX

Purpose: Specify a chemistry solver for use in conjunction with stochastic TBX particles. This is intended only for modeling the second phase of an explosion where the explosive has embedded metal (aluminum) particles that are too large to have burned in the first phase of the explosion.

This chemistry card points to a \*CHEMISTRY\_MODEL card (via IDCHEM) with its associated \*CHEMISTRY\_COMPOSITION cards to set up the initial conditions. That is, it establishes the spatial distribution of the species in the model.

It is assumed that there is no chemical reaction rate information in the chemistry model files. This is done since a special chemical reaction mechanism is implemented for TBX modeling. If particles other than solid aluminum particles are embedded in the explosive, then another burn model has to be implemented.

**Surface Part Card.** Card 1 format used when the PART keyword option is active.

Card 1	1	2	3	4	5	6	7	8
Variable	IDCHEM	USEPAR						
Type	I	I						
Default	none	1						

**VARIABLE**

**DESCRIPTION**

IDCHEM

Identifier for this chemistry solver.

USEPAR

Coupling flag indicating if a \*STOCHASTIC\_TBX\_PARTICLES card is provided for this model:

EQ.1: uses a \*STOCHASTIC\_TBX\_PARTICLES card (default).

EQ.0: does not use such a card.

**\*CHEMISTRY\_CONTROL\_ZND**

Purpose: Computes the one-dimensional reduced chemistry of a ZND model. It is then used in the initialization of the chemistry part of the CESE solver. When this card is used, the \*CESE\_INITIAL\_CHEMISTRY... cards must specify the progressive variable (degree of combustion) in the HIC field.

Card 1	1	2	3	4	5	6	7	8
Variable	ID							
Type	I							
Default	none							

Card 2	1	2	3	4	5	6	7	8
Variable	F	EPLUS	Q0	GAM	XYZD	DETDIR		
Type	F	F	F	F	F	I		
Default	none	none	none	none	none	none		

**VARIABLE****DESCRIPTION**

ID	Identifier for this full chemistry calculation.
F	Overdriven factor
EPLUS	EPLUS parameter of the ZND model.
Q0	Q0 parameter of the ZND model.
GAM	GAM parameter of the ZND model.
XYZD	Position of the detonation front in the DETDIR direction.
DETDIR	Detonation propagation direction (1 => X; 2 => Y; 3 => Z)

**\*CHEMISTRY\_DET\_INITIATION**

Purpose: Performs a one-dimensional detonation calculation based upon a chemical composition and initial conditions. It is then available for use immediately in the CESE solver for initializing a computation, or it can be subsequently used by the \*CHEMISTRY\_CONTROL\_1D card in a later run. In the product regions, this card overrides the initialization of the \*CESE\_INITIAL\_CHEMISTRY... cards.

Card 1	1	2	3	4	5	6	7	8
Variable	ID	COMPID	NMESH	DLEN	CFL	TLIMIT	XYZD	DETDIR
Type	I	I	I	F	F	F	F	I
Default	none	none	none	none	none	none	none	none

**LSDA Output File Card.**

Card 2	1	2	3	4	5	6	7	8
Variable	FILE							
Type	A							

**VARIABLE****DESCRIPTION**

ID	Identifier for this one-dimensional detonation computation.
COMPID	Chemical composition identifier of composition to use.
NMESH	Number of equal-width elements in the one-dimensional domain.
DLEN	Length of the one-dimensional domain.
CFL	Time-step limiting factor.
TLIMIT	Time limit for the simulation
XYZD	Position of the detonation front in the DETDIR direction.
DETDIR	Detonation propagation direction (1 => X; 2 => Y; 3 => Z)

**VARIABLE****DESCRIPTION**

---

FILE

Name of the LSDA file in which to write the one-dimensional solution.



\*CHEMISTRY\_MODEL

Purpose: Identifies the files that define a Chemkin chemistry model.

Card 1	1	2	3	4	5	6	7	8
Variable	MODELID	JACSEL	ERRLIM					
Type	I	I	F					
Default	none	1	1.0e-3					

**Chemkin Input File Card.**

Card 2	1	2	3	4	5	6	7	8
Variable	FILE1							
Type	A							

**Thermodynamics Database File Card.**

Card 3	1	2	3	4	5	6	7	8
Variable	FILE2							
Type	A							

**Transport Properties Database File Card.**

Card 4	1	2	3	4	5	6	7	8
Variable	FILE3							
Type	A							

**VARIABLE**

**DESCRIPTION**

MODELID

Identifier for this Chemkin-based chemistry model..

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
JACSEL	Selects the form of the Jacobian matrix for use in the source term. EQ.1: Fully implicit (default) EQ.2: Simplified implicit
ERRLIM	Allowed error in element balance in a chemical reaction.
FILE1	Name of the file containing the Chemkin-compatible input.
FILE2	Name of the file containing the chemistry thermodynamics database.
FILE3	Name of the file containing the chemistry transport properties database.

**\*CHEMISTRY\_PATH**

Purpose: To specify one or more search paths to look for chemistry database files.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	DIR							
Type	A							

**VARIABLE****DESCRIPTION**

DIR

Directory path to add to the search set.

**\*CHEMISTRY****\*CHEMISTRY\_PROPELLANT\_PROPERTIES****\*CHEMISTRY\_PROPELLANT\_PROPERTIES**

Purpose: Provide the required properties of a propellant deflagration model.

Card 1	1	2	3	4	5	6	7	8
Variable	PDIA	PHEIGHT	PMASS	TNOP				
Type	F	F	F	F				
Default	none	none	none	none				

Card 2	1	2	3	4	5	6	7	8
Variable	A0	TDELAY	TRISE	PINDEX				
Type	F	F	F	F				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

PDIA	Propellant diameter.
PHEIGHT	Propellant height.
PMASS	Individual cylinder propellant mass.
TNOP	Total number of propellant granules.
A0	Steady-state constant.
TDELAY	Ignition time delay.
TRISE	Rise time.
PINDEX	Power of the pressure in rate of burn model.

# \*EM

The \*EM keyword cards provide input for a new electromagnetism module for solving 3D eddy-current, inductive heating or resistive heating problems, coupled with mechanical and thermal solvers. Typical applications include magnetic metal forming and welding. A boundary element method in the air is coupled to finite elements in the conductor in order to avoid meshing the air.

\*EM\_2DAXI

\*EM\_BOUNDARY

\*EM\_CIRCUIT

\*EM\_CIRCUIT\_ROGO

\*EM\_CONTACT

\*EM\_CONTACT\_RESISTANCE

\*EM\_CONTROL

\*EM\_CONTROL\_CONTACT

\*EM\_CONTROL\_SWITCH

\*EM\_CONTROL\_TIMESTEP

\*EM\_DATABASE\_CIRCUIT

\*EM\_DATABASE\_CIRCUIT0D

\*EM\_DATABASE\_ELOUT

\*EM\_DATABASE\_FIELDLINE

\*EM\_DATABASE\_GLOBALENERGY

\*EM\_DATABASE\_NODOUT

\*EM\_DATABASE\_PARTDATA

\*EM\_DATABASE\_POINTOUT

\*EM\_DATABASE\_ROGO

\*EM\_DATABASE\_TIMESTEP

\*EM\_EOS\_BURGESS  
\*EM\_EOS\_MEADON  
\*EM\_EOS\_PERMEABILITY  
\*EM\_EOS\_TABULATED1  
\*EM\_EOS\_TABULATED2  
\*EM\_EXTERNAL\_FIELD  
\*EM\_MAT\_001  
\*EM\_MAT\_002  
\*EM\_MAT\_003  
\*EM\_MAT\_004  
\*EM\_OUTPUT  
\*EM\_POINT\_SET  
\*EM\_ROTATION\_AXIS  
\*EM\_SOLVER\_BEM  
\*EM\_SOLVER\_BEMMAT  
\*EM\_SOLVER\_FEM  
\*EM\_SOLVER\_FEMBEM

\*EM\_2DAXI

Purpose: Sets up the electromagnetism solver as 2D axisymmetric instead of 3D, on a given part, in order to save computational time as well as memory.

The electromagnetism is solved in 2D on a given cross section of the part (defined by a segment set), with a symmetry axis defined by its direction (at this time, it can be the x, y, or z axis). The EM forces and Joule heating are then computed over the full 3D part by rotations. The part needs to be compatible with the symmetry, i.e. each node in the part needs to be the child of a parent node on the segment set, by a rotation around the axis. Only the conductor parts (with a \*EM\_MAT... of type 2 or 4) should be defined as 2D axisymmetric.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	SSID	DIR	2DOPT	STARSSID	ENDSSID		
Type	I	I	I	I	I	I		
Default	none	none	none	none	none	none		

VARIABLE	DESCRIPTION
PID	Part ID of the part to be solved using 2D axisymmetry
SSID	Segment Set ID : Segment that will define the 2D cross section of the part where the EM field is solved
DIR	Defines the symmetry axis. At this time, only the z axis can be used : EQ.1: X axis EQ.2: Y axis EQ.3: Z axis
STARSSID, ENDSSID	Used by the 2D axisymmetric solver to make the connection between two corresponding boundaries on each side of a slice when the model is a slice of the full 360 circle.

**Remarks:**

1. At this time, either all or none of the conductor parts should be 2D axisymmetric. In the future, a mix between 2D axisymmetric and 3D parts will be allowed.



**\*EM\_BOUNDARY**

Purpose: Define some boundary conditions for the electromagnetism problems.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	SSID	BTYPE						
Type	I	I						
Default	none	none						

**VARIABLE**

**DESCRIPTION**

SSID

Segment Set Id

BTYPE

EQ.9: The faces of this segment set are eliminated from the BEM calculations (used for example for the rear or side faces of a workpiece).

**\*EM\_CIRCUIT\_{OPTION}**

Available options include

**SOURCE**

Purpose: Define an electrical circuit.

For the SOURCE option, the current will be considered uniform in the circuit. This can be useful in order to save computational time in cases with a low frequency current and where the diffusion of the EM fields is a very fast process. This option is in contrast with the general case where the current density in a circuit is completed in accordance with the solver type defined in EMSOL of \*EM\_CONTROL. For example, if an eddy current solver is selected, the diffusion of the current in the circuit is taken into account.

Card 1	1	2	3	4	5	6	7	8
Variable	CIRCID	CIRCTYP	LCID	R/F	L/A	C/to	V0	
Type	I	I	I	F	F	F	F	
Default	none	none	none	none	none	none	none	

Card 2	1	2	3	4	5	6	7	8
Variable	SIDCURR	SIDVIN	SIDVOUT	PARTID				
Type	I	I	I	I				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

CIRCID

Circuit ID

VARIABLE	DESCRIPTION
CIRCTYP	<p>Circuit type:</p> <p>EQ.1: Imposed current vs time defined by a load curve.</p> <p>EQ.2: Imposed voltage vs time defined by a load curve.</p> <p>EQ.3: R,L,C,V0 circuit.</p> <p>EQ.11: Imposed current defined by an amplitude A, frequency F and initial time <math>t_0</math>: <math>I = A\sin[2\pi F(t - t_0)]</math></p> <p>EQ.12: Imposed voltage defined by an amplitude A, frequency F and initial time <math>t_0</math>: <math>V = A\sin[2\pi F(t - t_0)]</math></p> <p>EQ.21: Imposed current defined by a load curve over one period and a frequency F</p> <p>EQ.22: Imposed voltage defined by a load curve over one period and a frequency F</p>
LCID	Load curve ID for CIRCTYP = 1, 2, 21 or 22
R/F	<p>Value of the circuit resistance for CIRCTYP = 3</p> <p>Value of the Frequency for CIRCTYP = 11, 12, 21 or 22</p>
L/A	<p>Value of the circuit inductance for CIRCTYP = 3</p> <p>Value of the Amplitude for CIRCTYP = 11 or 12</p>
C/t0	<p>Value of the circuit capacity for CIRCTYP = 3</p> <p>Value of the initial time t0 for CIRCTYP = 11 or 12</p>
V0	Value of the circuit initial voltage for CIRCTYP = 3.
SIDCURR	<p>Segment set ID for the current. It uses the orientation given by the normal of the segments. To use the opposite orientation, use a '-' (minus) sign in front of the segment set id.</p> <p>CIRCTYP.EQ.1/11/21: The current is imposed through this segment set</p> <p>CIRCTYP.EQ.3: The current needed by the circuit equations is measured through this segment set.</p>
SIDVIN	Segment set ID for input voltage or input current when CIRCTYP.EQ.2/3/12/22 and CIRCTYP.EQ.1/11/21 respectively. It is considered to be oriented as going into the structural mesh, irrespective of the orientation of the segment.

Variable	Circuit Type (CIRCTYP)				
	Imposed 2: Current	Imposed 3: Voltage	3: R, L, C	11: F, A, t0	12: F, A, t0
LCID	M	M	-	-	-
R/L/C/V0	-	-	M	-	-
F	-	-	-	M	M
A/t0	-	-	-	M	M
SIDCURR	M	O	M	M	O
SIDVIN	M*	M	M	M*	M
SIDVOUT	M*	M	M	M*	M
PARTID	M	M	M	M	M
Variable	21: LCID, F	22 : LCID, F			
LCID	M	M	-	-	-
R/L/C/V0	-	-	-	-	-
F	-	-	-	-	-
A/t0	-	-	-	-	-
SIDCURR	M	O	-	-	-
SIDVIN	M*	M	-	-	-
SIDVOUT	M*	M	-	-	-
PARTID	M	M	-	-	-

**Table 4-1.** Correspondence between circuit type and card entries. “M” indicates mandatory, “M\*” mandatory with exceptions (see Remark 1), “O” indicates optional, and “-” indicates ignored.

<b>VARIABLE</b>	<b>DESCRIPTION</b>
SIDVOUT	Segment set ID for output voltage or output current when CIRCTYP = 2/3/12/22 and CIRCTYP = 1/11/21 respectively. It is considered to be oriented as going out of the structural mesh, irrespective of the orientation of the segment.
PARTID	Part ID associated to the Source Circuit. It can be any part ID associated to the Source Circuit.

**Remarks:**

1. When defining a circuit with an imposed current (Type 1, 11 or 21) in cases of a closed loop geometry (torus), SIDVIN and SIDVOUT cannot be defined and thus, only SIDCURR is necessary.
2. When defining a circuit with an imposed tension (Type 2, 12, 22), it is possible to also define SIDCURR. This can be useful in circuits where various flow paths are possible for the current in order to force the entire current to go through SIDCURR.
3. Circuit types 21 and 22 are for cases where the periodic current/tension does not exactly follow a perfect sinusoidal. The user has to provide the shape of the current/tension over one period through a LCID as well as the frequency.

**\*EM\_CIRCUIT\_ROGO**

Purpose: Define Rogowsky coils to measure a global current vs time through a segment set or a node set.

Include as many cards as needed. This input ends at the next keyword (“\*”) card.

Card 1	1	2	3	4	5	6	7	8
Variable	ROGID	SETID	SETTYPE	CURTYP				
Type	I	I	I	I				
Default	0	0	0	0				

**VARIABLE****DESCRIPTION**

ROGID	Rogowsky coil ID
SETID	Segment or node set ID
SETTYPE	Type of set: EQ.1: Segment set EQ.2: Node set (not available yet)
CURTYP	Type of current measured: EQ.1: Volume current EQ.2: Surface current (not available yet) EQ.3: Magnetic field flow (B field times Area)

**Remarks:**

1. An ASCII file “em\_rog\_XXX”, with XXX representing the rogoID, is generated for each \*EM\_CIRCUIT\_ROGO card giving the value of the current or the magnetic field vs time.

**\*EM\_CONTACT**

Purpose: Optional card used for defining and specifying options on electromagnetic contacts between two sets of parts. Generally used with the \*EM\_CONTACT\_RESISTANCE card.

**Contact Definition Cards.** Include one card for each contact definition. This input ends at the next keyword (“\*”) card.

Card 1	1	2	3	4	5	6	7	8
Variable	CONTID	COTYPE	PSIDM	PSIDS	EPS1	EPS2	EPS3	D0
Type	I	I	I	I	F	F	F	F
Default	none	0	none	none	0.3	0.3	0.3	None

**VARIABLE****DESCRIPTION**

CONTID	Electromagnetic contact ID
COTYPE	Type of EM contact (See Remark 2) EQ.0: Contact type 0 (Default). EQ.1: Contact type 1.
PSIDM	Master part set ID
PSIDS	Slave part set ID
EPS <sub><i>i</i></sub>	Contact Coefficients for contact detection conditions. See discussion below.
D0	Contact condition 3 when COTYPE = 1.


**Remarks:**

Contact is detected when *all of the following three condition are satisfied:*

1. Contact condition 1:

$$n_1 \cdot n_2 \leq -1 + \varepsilon_1$$

2. Contact condition 2:



**Figure 4-2.** Contact detection conditions between two faces.

$$-\varepsilon_2 \leq \alpha_1 \leq 1 + \varepsilon_2$$

$$-\varepsilon_2 \leq \alpha_2 \leq 1 + \varepsilon_2$$

$$-\varepsilon_2 \leq \alpha_3 \leq 1 + \varepsilon_2$$

With  $n_1$  and  $n_2$  the normal vectors of faces  $f_1$  and  $f_2$  respectively and  $P$  the projection of point  $a_2$  on face  $f_1$  with  $(\alpha_1, \alpha_2, \alpha_3)$  its local coordinates (See [Figure 4-2](#)).

3. Contact condition 3 depends on the contact type.

a) For contact type 0:

$$d \leq \varepsilon_3 S_1$$

where  $d$  is the distance between  $P$  and  $a_2$  and where  $S_1$  the minimum side length:

$$S_1 = \min[d(a_1, b_1), d(b_1, c_1), d(c_1, a_1)]$$

b) For contact type 1 :

$$d \leq D_0$$



**\*EM\_CONTACT\_RESISTANCE**

Purpose: Calculate the contact resistance of a previously defined EM contact in \*EM\_CONTACT. Most contact resistance calculations are based on *Ragnar Holm's "Electric Contacts"*.

Card 1	1	2	3	4	5	6	7	8
Variable	CRID	CONTID	CTYPE	CIRCID	JHRTYPE			
Type	I	I	I	I	I			
Default	none	none	none	none	none			

**Card 2 if CTYPE = 1.**

Cards 2	1	2	3	4	5	6	7	8
Variable	LCID							
Type	I							
Default	none							

**Card 2 if CTYPE = 2.**

Cards 2	1	2	3	4	5	6	7	8
Variable	RHO	RAD						
Type	F	F						
Default	0.	0.						

**Card 2 if CTYPE = 3.**

Cards 2	1	2	3	4	5	6	7	8
Variable	RHO	RAD	D	CURLCID	EPS	HB		
Type	F	F	F	I	F	F		
Default	0.	0.	0.	0	0.	0.		

**Card 2 if CTYPE = 4.**

Cards 2	1	2	3	4	5	6	7	8
Variable	RHO	RAD	D	CURLCID	E	CURV		
Type	F	F	F	I	F	F		
Default	0.	0.	0.	0	0.	0.		

**Card 2 if CTYPE = 5.**

Cards 2	1	2	3	4	5	6	7	8
Variable	RHOPROB	RHOSUB	RHOOXY	FACTE	FACFILM			
Type	F	F	F	F	F			
Default	none	none	none	none	none			

**VARIABLE****DESCRIPTION**

CRID	Resistive contact ID
CONTID	EM contact ID defined in *EM_CONTACT

VARIABLE	DESCRIPTION
CTYPE	<p>Contact Resistance type :</p> <p>EQ.1: Contact resistance defined by user defined load curve.</p> <p>EQ.2: Classic Holm's formula for contact resistances (See <a href="#">Remark 1</a>).</p> <p>EQ.3: Modified contact resistance for cases with plastic deformation in the contact area (See <a href="#">Remarks 2</a> and <a href="#">3</a>).</p> <p>EQ.4: Modified contact resistance for cases with elastic deformation in the contact area (See <a href="#">Remarks 2</a> and <a href="#">3</a>).</p> <p>EQ.5: Basic contact resistance definition (See <a href="#">Remark 4</a>).</p>
CIRCID	Circuit ID: When defined, the contact resistance will be added to the corresponding circuit total resistance and taken into account in the circuit equations.
JHRTYPE	<p>Indicates how the Joule heating calculated by the contact resistance shall be taken into account:</p> <p>EQ.0: No addition: The Joule heating calculated by the contact resistance is not taken into account.</p> <p>EQ.1: The Joule heating coming from the contact resistance is divided and distributed evenly among all elements neighboring the contact surface.</p>
LCID	Load Curve ID defining the contact resistance versus time.
RHO	Material resistivity $\rho_{mat}$ . If not defined or EQ. 0.0, the solver will automatically calculate an average resistivity based on the conductivity of the elements that are in contact.
RAD	Radius of the contact sphere $a$ . If not defined or EQ. 0.0, the solver will automatically calculate an equivalent radius based on the contact area: $a = \sqrt{Area}/\pi$ .
D	Diameter of the Electrode.
CURLCID	Load Curve ID defining the current intensity of the electrode. If not defined or EQ. 0, the solver will automatically look for the circuit's current intensity using the circuit defined in CIRID.
EPS	Constant $\epsilon$ with values typically between 0.35 and 1.
HB	Brinell hardness, $H_b$ .

<b>VARIABLE</b>	<b>DESCRIPTION</b>
E	Material Young's modulus.
CURV	Radius of curvature of the contact surface, $r$ .
RHOPROB	Probe resistivity, $\rho_{\text{prob}}$
RHOSUB	Substrate resistivity, $\rho_{\text{sub}}$
RHOXY	Film resistivity, $\rho_{\text{oxi}}$
FACTE	Scale factor on the constriction area when calculating the constriction resistance. If negative, the factor is time-dependent and defined by the load curve absolute value (FACTE).
FACFILM	Scale factor on the constriction area when calculating the film resistance. If negative, the factor is time-dependent and defined by the load curve absolute value (FACFILM).

**Remarks:**

1. **Holm's formula for Contact Resistance.** A very good approximation of the electric contact resistance is given by Holm's formula :

$$R_{\text{contact}} = \frac{\rho_{\text{mat}}}{2a}$$

where  $\rho_{\text{mat}}$  is the material's resistivity and  $a$  is the radius of the contact surface assuming the contact surface area is close to that of a circle :  $\text{Area} = \pi a^2$ .


It is recommended to use this method (CTYPE = 2) in a first approach since most other contact resistance definitions are extensions of this formula.

2. **Contact Area formulations.** For certain types of applications such as resistance spot welding (RSW) it is advantageous to better approximate the area by taking into account the deformation and the heterogeneities of the materials that come into contact at a microscopic level. For a plastic deformation of the contact zone, the contact area, assumed to be circular, can be defined approximated as:

$$\text{Area} = \frac{F_c}{\varepsilon H_b}$$

where  $F_c$  is the contact force,  $\varepsilon$  a constant with values between 0.35 and 1, and  $H_b$  the Brinell hardness of the material.

For an elastic deformation in the contact area, the radius of the contact surface is now given by:



**Figure 4-3.** Electrode coming into contact with workpiece (RSW application).

$$a = \frac{rF_c^{1/3}}{E}$$

where  $r$  is the radius of curvature of the contact surface and  $E$  is Young's modulus. The Holm formula can then be modified in order to give:

$$R_{\text{contact}} = \frac{\rho_{\text{mat}}}{2} \times \sqrt{\frac{\pi \varepsilon H_b}{F_c}}$$

and

$$R_{\text{contact}} = \frac{\rho_{\text{mat}}}{2} \times \left( \frac{E}{rF_c} \right)^{1/3}$$

in the cases of plastic (CTYPE = 3) and elastic (CTYPE = 4) deformations respectively.

- Lorentz Force from a Spherical Electrode.** When a spherical electrode comes into contact with a work piece, the curvature of the current flowing from the electrode to the work piece induces a Lorentz force parallel to the normal of the contact surface thus forcing the electrode and the work piece away from each other. Its intensity can be written as:

$$F_c = \frac{\mu_0}{4\pi} I^2 \ln \left( \frac{D}{2a} \right)$$

where  $I$  is the current intensity and  $D$  the diameter of the electrode. See [Figure 4-3](#).

4. **Basic resistive contact formulation (CTYPE = 5).** In the case of a clean metal contact with no film the resistance calculation involves only the constriction term. If a film is present and both sides have different metals, the contact resistance,  $R_{\text{contact}}$ , is the sum of the constriction resistance  $R_{\text{constriction}}$  and the film resistance  $R_{\text{film}}$ . In the basic resistive model, the following expressions determine the resistance:

$$R_{\text{constriction}} = \frac{\rho_{\text{prob}} + \rho_{\text{sub}}}{\sqrt{\text{FACTE} \times \text{ContactArea}}}$$
$$R_{\text{film}} = \frac{\rho_{\text{oxy}}}{\sqrt{\text{FACFILM} \times \text{ContactArea}}}$$
$$R_{\text{contact}} = R_{\text{constriction}} + R_{\text{film}}$$

**\*EM\_CONTROL**

Purpose: Enable the EM solver and set its options.

Card 1	1	2	3	4	5	6	7	8
Variable	EMSOL	NUMLS	MACRODT					
Type	I	I	F					
Default	0	100	none					

<u>VARIABLE</u>	<u>DESCRIPTION</u>
EMSOL	Electromagnetism solver selector: EQ.1: Eddy current solver EQ.2: Induced heating solver EQ.3: Resistive heating solver
NUMLS	Number of local EM steps in a whole period for EMSOL = 2. Not used for EMSOL = 1
MACRODT	Macro time step when EMSOL = 2. Can be used as constant EM time step when EMSOL = 1. Obsolete: use *EM_CONTROL_-TIMESTEP.

**\*EM\_CONTROL\_CONTACT**

Purpose: This keyword activates the electromagnetism contact algorithms, which detects contact between conductors. Electromagnetic fields to flow from one conductor to another when detected as in contact.

Card 1	1	2	3	4	5	6	7	8
Variable	EMCT	CCONLY						
Type	I	I						
Default	0	0						

**VARIABLE****DESCRIPTION**

EMCT

EM contact activation flag:

EQ.0: No contact detection

EQ.1: Contact detection

CCONLY

Determines on which parts of the model the EM contact should be activated.

EQ.0: Contact detection between all active parts associated with a conducting material. (Default)

EQ.1: Only look for EM contact between parts associated through the EM\_CONTACT card. In some cases this option can reduce the calculation time.



**\*EM\_CONTROL\_SWITCH**

Purpose: It is possible to active a control “switch” that will shut down the solver based on a load curve information. LS-DYNA incorporates complex types of curves (See \*DEFINE\_FUNCTION) that allow the setting up of complex On/Off switches, for instance, by using a nodal temperature value.

Card 1	1	2	3	4	5	6	7	8
Variable	LCID	FEMCOMP	BEMCOMP					
Type	I	I	I					
Default	0	0	0					

<b>VARIABLE</b>	<b>DESCRIPTION</b>
LCID	Load Curve ID. Negative values switch the solver off, positive values switch it back on.
FEMCOMP	Determines if FEM matrices are recomputed each time the EM solver is turned back on : EQ.0 : FEM matrices are recomputed EQ.1 : FEM matrices are not recomputed
BEMCOMP	Determines if BEM matrices are recomputed each time the EM solver is turned back on : EQ.0 : BEM matrices are recomputed EQ.1 : BEM matrices are not recomputed

**\*EM\_CONTROL\_TIMESTEP**

Purpose: Controls the EM time step and its evolution

Card 1	1	2	3	4	5	6	7	8
Variable	TSTYPE	DTCONST	LCID	FACTOR				
Type	I	F	I	F				
Default	none	none	none	1.0				

**VARIABLE****DESCRIPTION**

TSTYPE	Time Step type EQ.1: constant time step given in DTCONST EQ.2: time step vs time given by a load curve specified in LCID EQ.3: automatic time step computation, depending on the solver type. This time step is then multiplied by FACTOR
DTCONST	Constant value for the time step for TSTYPE = 1
LCID	Load curve ID giving the time step vs time for TSTYPE = 2
FACTOR	Multiplicative factor applied to the time step for TSTYPE = 3

**Remarks:**

- For an eddy current solver, the time step is based on the diffusion equation for the magnetic field.

$$\sigma \frac{\partial \vec{A}}{\partial t} + \vec{\nabla} \times \frac{1}{\mu} \vec{\nabla} \times \vec{A} + \sigma \vec{\nabla} \varphi = \vec{j}_S$$

It is computed as the minimal elemental diffusion time step over the elements. For a given element, the elemental diffusion time step is given as  $dt_e = l_e^2 / 2D$ , where:

- D is the diffusion coefficient  $D = 1 / \mu_0 \sigma_e$
- $\sigma_e$  is the element electrical conductivity,

- $\mu_0$  is the permeability of free space,
- $l_e$  is the minimal edge length of the element (minimal size of the element).

**\*EM\_DATABASE\_CIRCUIT**

Purpose: This keyword enables the output of EM data for every circuit defined.

Output options card

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	1	0.						

**VARIABLE****DESCRIPTION**

OUTLV

Determines if the output file should be dumped.

EQ.0: No output file is generated.

EQ.1: The output file is generated.

DTOUT

Time interval to print the output. If DTOUT is equal to 0.0, then the EM timestep will be used.

**Remarks:**

1. The file name for this database is `em_circuit_XXX.dat` with `XXX` the circuit ID.
2. *Resistance<sub>D</sub>* is calculated in the following way:
  - a) A scalar potential difference of 1 is imposed at the circuit's boundaries `SIDVIN` and `SIDVOUT`.
  - b) The system to be solved at `SIDCURR` is then  $\nabla^2\varphi = 0$  with  $\varphi_{\text{SIDVIN}} = 1$  and  $\varphi_{\text{SIDVOUT}} = 0$ . No diffusive effects are taken into account meaning that the current density can be written as  $\mathbf{j} = \nabla\varphi$  and the total current as  $I = \mathbf{j} \cdot \mathbf{nd}A$ .
  - c) The resistance can then be estimated using  $R_D = U/I$ . The calculation of this  $R_D$  resistance is solely based on the circuit's geometry and conductivity. It is therefore equivalent to the resistance as commonly defined in the circuit equations:

$$R_D = L/\sigma S$$

where L is the length of the circuit and S its surface area.

3. *ResistanceJ* is calculated by using the data provided during the EM solve :  $R_j = J/I^2$  where J and I are, respectively, the joule heating and the current. Compared with *ResistanceD*, *ResistanceJ* is not so much a resistance calculation since it accounts for the resistive effects (when using the Eddy current solver). Rather, it corresponds to the resistance that the circuit would need in order to get the same Joule heating in the context of a circuit equation. If all EM fields are diffused or the RH solver is being used, *ResistanceJ* should be close to *ResistanceD*.
4. Only the mutual inductances between the first three circuits defined are output.

**\*EM\_DATABASE\_CIRCUIT0D**

Purpose: This keyword enables the output of EM data for every circuit defined.

Output options card

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	0	0.						

**VARIABLE****DESCRIPTION**

OUTLV	Determines if the output file should be dumped. EQ.0: No output file is generated. EQ.1: The output file is generated.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the EM timestep will be used.

**Remarks:**

1. The file name for this database is `em_circuit0D_XXX.dat` with `XXX` the circuit ID.
2. At the start of the run, based on the initial values of the meshes resistances and inductances, the solver will calculate the results for a so-called "0D" solution which does not take into account the current's diffusion, the part's displacements or the EM material property changes. It is therefore a crude approximation. This can be useful in some cases especially in R,L,C circuits if the users wishes to have an first idea of how the source current will behave.
3. Since the calculation of this 0D circuit can take time depending on the problems size, it should only be used in cases where the output results are useful to the comprehension of the analysis.
4. This card has no influence on the results of the EM run itself.

\*EM\_DATABASE\_ELOUT

Purpose: This keyword enables the output of EM data on elements.

Output Options Card.

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	0	0.						

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	ELSID							
Type	I							
Default	none							

VARIABLE	DESCRIPTION
OUTLV	Determines if the output file should be dumped. EQ.0: No output file is generated. EQ.1: The output file is generated.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the EM timestep will be used.
ELSID	Solid Elements Set ID.

Remarks:

1. The file name for this database is em\_elout.dat.

**\*EM\_DATABASE\_FIELDLINE**

Purpose: The EM solver uses a BEM method to calculate the EM fields between conductors. With this method, the magnetic field in the air or vacuum between conductors is therefore not explicitly computed. However, in some cases, it may be interesting to visualize some magnetic field lines for a better analysis. This keyword allows the output of field line data. It has no influence on the results of the EM solve.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	FLID	PSID	DTOUT	NPOINT				
Type	I	I	F	I				
Default	none	none	0.	100				

**Remaining cards are optional.†**

Card 2	1	2	3	4	5	6	7	8
Variable	INTEG	H	HMIN	HMAX	TOLABS	TOLREL		
Type	I	F	F	F	F	F		
Default	2	0.	0.	1E10	1E-3	1E-5		

Card 3	1	2	3	4	5	6	7	8
Variable	BTYPE							
Type	I							
Default	2							



VARIABLE	DESCRIPTION
FLID	Field line set ID
PSID	Point Set ID associated to the field line set (See *EM_POINT_SET). The coordinates given by the different points will be the starting points of the field lines.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the EM time step will be used.
NPOINT	Number of points per field line. The points are regularly spaced.
INTEG	Type of numerical integrator used to compute the field lines : EQ.1: RK4, Runge Kutta 4. See <a href="#">Remark 2</a> . EQ.2: DOP853, Dormand Prince 8(5,3). See <a href="#">Remark 2</a> .
H	Value of the step size. In case of an integrator with adaptive step size, it is the initial value of the step size.
HMIN	Minimal step size value. Only used in the case of an integrator with adaptive step size.
HMAX	Maximal step size value. Only used in the case of an integrator with adaptive step size.
TOLABS	Absolute tolerance of the integrator. Only used in the case of an integrator with adaptive step size.
TOLREL	Relative tolerance of the integrator. Only used in the case of an integrator with adaptive step size.
BTYPE	Method to compute the magnetic field : EQ.1: Direct method (every contribution is computed by the Biot Savart Law and summed up : very slow). EQ.2: Multipole method (approximation of the direct method using the multipole expansion). EQ.3: Multicenter method (approximation of the direct method using a weighted subset of points only in order to compute the magnetic field).

**Remarks:**

1. **File Names.** The file name for this database is em\_fieldLine\_XX\_YYY.dat where *XX* is the field line ID and *YYY* is the point set ID defined in \*EM\_POINT\_SET.
2. **Integrators.** The Runge Kutta 4 integrator is an explicit iterative method for solving ODEs. It is a fourth order method with a constant step size. The Dormand Prince 8(5,3) integrator is an explicit iterative method for solving IDEs. Particularly, this integrator is an embedded Runge Kutta integrator of order 8 with an adaptive step size. This integrator allows a step size control which is done through an error estimate at each step. The Dormand Prince 8(5,3) is a Dormand Prince 8(6) for which the 6<sup>th</sup> order error estimator has been replaced by a 5<sup>th</sup> order estimator with 3<sup>rd</sup> order correction in order to make the integrator more robust.

**\*EM\_DATABASE\_GLOBALENERGY**

Purpose: This keyword enables the output of global EM.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	0	0.						

**VARIABLE****DESCRIPTION**

OUTLV

Determines if the output file should be dumped.

EQ.0: No output file is generated.

EQ.1: The output file is generated.

DTOUT

Time interval to print the output. If DTOUT is equal to 0.0, then the EM timestep will be used.

**Remarks:**

1. The file name for this database is em\_globEnergy.dat.
2. Outputs the global EM energies of the mesh, the air and the source circuit. Also outputs the global kinetic energy and the global plastic work energy.

**\*EM\_DATABASE\_NODOUT**

Purpose: This keyword enables the output of EM data on nodes.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	0	0.						

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	NSID							
Type	I							
Default	none							

**VARIABLE****DESCRIPTION**

OUTLV	Determines if the output file should be dumped. EQ.0: No output file is generated. EQ.1: The output file is generated.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the EM timestep will be used.
NSID	Node Set ID.

**Remarks:**

1. The file name for this database is em\_nodout.dat.

\*EM\_DATABASE\_PARTDATA

Purpose: This keyword enables the output of EM data for every part defined. .

Output Options Card.

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	0	0.						

<u>VARIABLE</u>	<u>DESCRIPTION</u>
OUTLV	Determines if the output file should be dumped. EQ.0: No output file is generated. EQ.1: The output file is generated.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the EM timestep will be used.

Remarks:

1. The file name for this database is em\_partData\_XXX.dat with XXX the part ID.
2. Outputs the part EM energies of the part as well as the Lorentz force. Also outputs the part kinetic energy and the part plastic work energy.

**\*EM\_DATABASE\_POINTOUT**

Purpose: This keyword enables the output of EM data on points sets.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	0	0.						

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	PSID							
Type	I							
Default	none							

**VARIABLE****DESCRIPTION**

OUTLV	Determines if the output file should be dumped. EQ.0: No output file is generated. EQ.1: The output file is generated.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the ICFD timestep will be used.
PSID	Point Set ID (See *EM_POINT_SET card).

**Remarks:**

1. The file name for this database is em\_pointout.dat.

\*EM\_DATABASE\_ROGO

Purpose: This keyword enables the output of EM data for every circuit defined. .

Output Options Card.

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	1	0.						

<u>VARIABLE</u>	<u>DESCRIPTION</u>
OUTLV	Determines if the output file should be dumped. EQ.0: No output file is generated. EQ.1: The output file is generated.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the EM timestep will be used.

Remarks:

1. The file name for this database is em\_rogoCoil\_XXX.dat where XXX is the rogo Coil ID.

**\*EM\_DATABASE\_TIMESTEP**

Purpose: This keyword enables the output of EM data regarding the EM timestep.

Output options card.

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV							
Type	I							
Default	0							

**VARIABLE****DESCRIPTION**

OUTLV

Determines if the output file should be dumped.

EQ.0: No output file is generated.

EQ.1: The output file is generated.

**Remarks:**

1. The file name for this database is `em_timestep.dat`.
2. Outputs the run's EM tim estep versus the time step calculated using the EM CFL condition as criteria (autotimestep). This can be useful in cases with big deformations and/or material property changes and a fixed time step is being used in case that time step becomes to big compared to the stability time step.



**\*EM\_EOS\_BURGESS**

Purpose: Define the parameters for a Burgess model giving the electrical conductivity as a function of the temperature and the density, see:

*T.J. Burgess, "Electrical resistivity model of metals", 4th International Conference on Megagauss Magnetic-Field Generation and Related Topics, Santa Fe, NM, USA, 1986*

Card 1	1	2	3	4	5	6	7	8
Variable	EOSID	V0	GAMMA	THETA	LF	C1	C2	C3
Type	I	F	F	F	F	F	F	F
Default	none	none	none	none	none	none	none	none

Card 2	1	2	3	4	5	6	7	8
Variable	C4	K	EXPON	LGTUNIT	TIMUNIT	TEMUNI	ADJUST	
Type	F	F	I	F	F	I	I	
Default	none	none	none	none	none	none	none	

In the following, UUS stands for User Units System and BUS for Burgess Units

<b>VARIABLE</b>	<b>DESCRIPTION</b>
EOSID	ID of the EM_EOS (specified by an *EM_MAT card)
V0	Reference specific volume $V_0$ (UUS).
GAMMA0	Reference Gruneisen value $\gamma_0$ .(no units).
THETA	Reference melting temperature $\theta_{m,0}$ in eV (BUS).
LF	Latent heat of fusion $L_F$ in kJoule/mol (BUS).
C1	C1 constant (BUS)
C2	C2 constant (no units)

<b>VARIABLE</b>	<b>DESCRIPTION</b>
C3	C3 constant (no units)
C4	C4 constant (no units)
K	Parameter k (no units).
EXPON	Exponent in <a href="#">equations (2)</a> (see remarks)
LGTUNIT	Length units for UUS (relative to meter, i.e. = 1.e-3 if UUS in mm).
TIMUNIT	Time units for UUS (relative to seconds).
TEMUNIT	Temperature units EQ.1: temperature in Celsius EQ.2: temperature in Kelvins
ADJUST	Conductivity modification EQ.0: (default) The conductivity is given by the Burgess formula. EQ.1: The conductivity is adjusted so that it is equal to the conductivity defined in *EM_MAT card $\sigma_{mat}$ at room temperature:

$$\sigma(\theta) = \sigma_{Burgess}(\theta) \frac{\sigma_{mat}}{\sigma_{Burgess}(\theta_{room})}$$

**Remarks:**

1. The Burgess model gives the electrical resistivity vs temperature and density for the solid phase, liquid phase and vapor phase. At this time, only the solid and liquid phases are implemented. To check which elements are in the solid and in the liquid phase, a melting temperature is first computed by:

$$\theta_m = \theta_{m,0} \left( \frac{V}{V_0} \right)^{-\frac{1}{3}} e^{(2\gamma_0 - 1) \left( 1 - \frac{V}{V_0} \right)}$$

- a) If  $T < \theta_m$ : solid phase model applies.

The solid phase electrical resistivity corresponds to the Meadon model:

$$\eta_S = (C_1 + C_2 \theta^{C_3}) f_c \left( \frac{V}{V_0} \right), \quad (1)$$

where  $\theta$  is the temperature,  $V$  is the specific volume, and  $V_0$  is the reference specific volume (zero pressure, solid phase). In (1), the volume dependence is given by:

$$f_c \left( \frac{V}{V_0} \right) = \begin{cases} \left( \frac{V}{V_0} \right)^{2\gamma-1} & \text{EXPON.EQ. -1 (most materials)} \\ \left( \frac{V}{V_0} \right)^{2\gamma+1} & \text{EXPON.EQ. +1 (tungsten)} \\ \left( \frac{V}{V_0} \right)^{2\gamma} & \text{EXPON.EQ. 0 (stainless steel)} \end{cases} \quad (2)$$

with

$$\gamma = \gamma_0 - \left( \gamma_0 - \frac{1}{2} \right) \left( 1 - \frac{V}{V_0} \right) \quad (3)$$

b) If  $T > \theta_m$ : liquid phase model:

$$\eta_L = (\eta_L)_{\theta_m} \left( \frac{\theta}{\theta_m} \right)^{C_4} \quad (4)$$

with

$$(\eta_L)_{\theta_m} = \Delta\eta(\eta_S)_{\theta_m}$$

where

$$\Delta\eta = \begin{cases} ke^{0.69L_F/\theta_m} & k > 0 \\ 1 + 0.0772(2 - \theta_m) & k = -1 \\ 1 + 0.106(0.846 - \theta_m) & k = -2 \end{cases} \quad \begin{matrix} \\ \text{(tungsten)} \\ \text{(stainless steel SS-304)} \end{matrix} \quad (5)$$

The following table reports some sets of parameters given by Burgess in his paper:

Parameter	Cu	Ag	Au	W	Al(2024)	SS(304)
$V_0(\text{cm}^3/\text{gm})$	0.112	0.0953	0.0518	0.0518	0.370	0.1265
$\gamma_0$	2.00	2.55	3.29	1.55	2.13	2.00
$\theta_{m,0}(\text{BUS})$	0.117	0.106	0.115	0.315	0.0804	0.156
$L_F(\text{BUS})$	0.130	0.113	0.127	0.337	0.107	0.153
$C_1(\text{BUS})$	-4.12e-5	-3.37e-5	-4.95e-5	-9.73e-5	-5.35e-5	0
$C_2$	0.113	0.131	0.170	0.465	0.233	0.330
$C_3$	1.145	1.191	1.178	1.226	1.210	0.4133
EXPON	-1	-1	-1	+1	-1	0

---

Parameter	Cu	Ag	Au	W	Al(2024)	SS(304)
C <sub>4</sub>	0.700	0.672	0.673	0.670	0.638	0.089
k	0.964	0.910	1.08	-1.	0.878	-2.

\*EM\_EOS\_MEADON

Purpose: Define the parameters for a Meadon model, giving the electrical conductivity as a function of the temperature and the density; see:

*T.J. Burgess, "Electrical resistivity model of metals", 4th International Conference on Megagauss Magnetic-Field Generation and Related Topics, Santa Fe, NM, USA, 1986*

Card 1	1	2	3	4	5	6	7	8
Variable	EOSID	C1	C2	C3	TEMUNI	V0	GAMMA	EXPON
Type	I	F	F	F	I	F	F	I
Default	none	none	none	none	none	none	none	none

Card 2	1	2	3	4	5	6	7	8
Variable	LGTUNIT	TIMUNIT	ADJUST					
Type	F	F	I					
Default	none	none	none					

In the following, UUS stands for User Units System and BUS for Burgess Units.

<b>VARIABLE</b>	<b>DESCRIPTION</b>
EOSID	ID of the EM_EOS
C1	C1 constant (BUS)
C2	C2 constant (no units)
C3	C3 constant (no units)
TEMUNIT	Temperature units EQ.1: temperature in Celsius EQ.2: temperature in Kelvins

VARIABLE	DESCRIPTION
V0	Reference specific volume V0 (UUS).
GAMMA0	Reference Gruneisen value $\gamma_0$ .(no units).
EXPON	Exponent in <a href="#">equations (7)</a>
LGTUNIT	Length units for UUS (relative to meter, i.e. = 1.e-3 if UUS in mm).
TIMUNIT	Time units for UUS (relative to seconds).
ADJUST:	EQ.0: (default) the conductivity is given by the Burgess formula. EQ.1: The conductivity is adjusted so that it is equal to the conductivity defined in the *EM_MAT card $\sigma_{mat}$ at room temperature:

$$\sigma(\theta) = \sigma_{Burgess}(\theta) \frac{\sigma_{mat}}{\sigma_{Burgess}(\theta_{room})}$$

**Remarks:**

1. The Meadon model is a simplified Burgess model with the solid phase equations only.

The electrical resistivity is given by:

$$\eta_s = (C_1 + C_2\theta^{C_3})f_c \left( \frac{V}{V_0} \right) \tag{6}$$

where  $\theta$  is the temperature,  $V$  is the specific volume, and  $V_0$  is the reference specific volume (zero pressure, solid phase).

In (6), the volume dependence is given by:

$$f_c \left( \frac{V}{V_0} \right) = \begin{cases} \left( \frac{V}{V_0} \right)^{2\gamma-1} & \text{EXPON.EQ. -1} & \text{(most materials)} \\ \left( \frac{V}{V_0} \right)^{2\gamma+1} & \text{EXPON.EQ. +1} & \text{(tungsten)} \\ \left( \frac{V}{V_0} \right)^{2\gamma} & \text{EXPON.EQ.0} & \text{(stainless steel)} \\ 1 & \text{VO.EQ. 0} & \text{(default value for } V_0 \text{ is zero)} \end{cases} \tag{7}$$

(In this last case, only EOSID, C1, C2, C3, TEMUNIT, TIMUNIT and LGTUNIT need to be defined)

with,

$$\gamma = \gamma_0 - \left( \gamma_0 - \frac{1}{2} \right) \left( 1 - \frac{V}{V_0} \right) \quad (8)$$

The following table reports some sets of parameters given by Burgess in his paper:

<b>Parameter</b>	<b>Cu</b>	<b>Ag</b>	<b>Au</b>	<b>W</b>	<b>Al(2024)</b>	<b>SS(304)</b>
<b>V<sub>0</sub>(cm<sup>3</sup>/gm)</b>	0.112	0.0953	0.0518	0.0518	0.370	0.1265
<b>γ<sub>0</sub></b>	2.00	2.55	3.29	1.55	2.13	2.00
<b>C<sub>1</sub>(BUS)</b>	-4.12e-5	-3.37e-5	-4.95e-5	-9.73e-5	-5.35e-5	0
<b>C<sub>2</sub></b>	0.113	0.131	0.170	0.465	0.233	0.330
<b>C<sub>3</sub></b>	1.145	1.191	1.178	1.226	1.210	0.4133
<b>EXPON</b>	-1	-1	-1	+1	-1	0

**\*EM\_EOS\_PERMEABILITY**

Purpose: Define the parameters for the behavior of a material's permeability

Card 1	1	2	3	4	5	6	7	8
Variable	EOSID	EOSTYPE	LCID					
Type	I	I	I					
Default	none	none	none					

**VARIABLE****DESCRIPTION**

EOSID

ID of the EM\_EOS

EOSTYPE

Define the type of EOS:

EQ.1: Permeability defined by a B function of H curve ( $B = \mu H$ )EQ.2: Permeability defined by a H function of B curve ( $H = B/\mu$ )

LCID

Load curve ID



\*EM\_EOS\_TABULATED1

Purpose: Define the electrical conductivity as a function of temperature by using a load curve.

Card 1	1	2	3	4	5	6	7	8
Variable	EOSID	LCID						
Type	I	I						
Default	none	none						

<u>VARIABLE</u>	<u>DESCRIPTION</u>
EOSID	ID of the EM_EOS
LCID	Load curve ID.

**Remarks:**

1. The load curve describes the electrical conductivity (ordinate) vs the temperature (abscissa). The user needs to make sure the temperature and the electrical conductivity given by the load curve are in the correct units. Also, it is advised to give some bounds to the load curve (conductivities at very low and very high temperatures) to avoid bad extrapolations of the conductivity if the temperature gets out of the load curve bounds.

**\*EM\_EOS\_TABULATED2**

Purpose: Define the electrical conductivity as a function of time by using a load curve.

Card 1	1	2	3	4	5	6	7	8
Variable	EOSID	LCID						
Type	I	I						
Default	none	none						

**VARIABLE****DESCRIPTION**

EOSID	ID of the EM_EOS
LCID	Load curve ID.

**Remarks:**

1. The load curve describes the electrical conductivity (ordinate) vs the time (abscissa). The user needs to make sure the time and the electrical conductivity given by the load curve are in the correct units. Also, it is advised to give some bounds to the load curve (conductivities at  $t = 0$  at after a long time) to avoid bad extrapolations of the conductivity if the run time gets out of the load curve bounds.

\*EM\_EXTERNAL\_FIELD

Purpose: Define the components of a time dependent exterior field uniform in space applied on the conducting parts.

Card 1	1	2	3	4	5	6	7	8
Variable	FIELDID	FTYPE	FDEF	LCIDX	LCIDY	LCIDZ		
Type	I	I	F	I	I	I		
Default	0	0	0	0	0	0		

<u>VARIABLE</u>	<u>DESCRIPTION</u>
FIELDID	External Field ID
FTYPE	Field type: EQ.1: Magnetic field EQ.2: Electric field (not available yet)
FDEF	Field defined by : EQ.1: Load Curves
LCID[X,Y,Z]	Load curve ID defining the (X,Y,Z) component of the field function of time

**\*EM\_MAT\_001**

Purpose: Define the electromagnetic material type and properties for a material whose permeability equals the free space permeability.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	MID	MTYPE	SIGMA	EOSID				
Type	I	I	F	I				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

MID	Material ID: refers to MID in the *PART card.
MTYPE	Defines the electromagnetism type of the material: EQ.0: Air or vacuum EQ.1: Insulator material. these materials have the same electromagnetism behavior as EQ.0 EQ.2: Conductor carrying a source. In these conductors, the eddy current problem is solved, which gives the actual current density. Typically, this would correspond to the coil. EQ.4: Conductor not connected to any current or voltage source, where the Eddy current problem is solved. Typically, this would correspond to the workpiece
SIGMA	Initial electrical conductivity of the material
EOSID	ID of the EOS to be used for the electrical conductivity (see *EM_-EOS cards).

## \*EM\_MAT\_002

Purpose: Define an electromagnetic material type and properties whose permeability is different than the free space permeability.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	MID	MTYPE	SIGMA	EOSID	MUREL	EOSMU		
Type	I	I	F	I	F	I		
Default	none	none	none	none	none	none		

**VARIABLE****DESCRIPTION**

MID	Material ID: refers to MID in the *PART card.
MTYPE	Defines the electromagnetism type of the material: EQ.0: Air or vacuum EQ.1: Insulator material. These materials have the same electromagnetism behavior as EQ.0 EQ.2: Conductor carrying a source. In these conductors, the eddy current problem is solved, which gives the actual current density. Typically, this would correspond to the coil. EQ.4: Conductor not connected to any current or voltage source, where the Eddy current problem is solved. Typically, this would correspond to the workpiece
SIGMA	Initial electrical conductivity of the material
EOSID	ID of the EOS to be used for the electrical conductivity (see *EM_-EOS cards).
MUREL	Relative permeability: Is the ratio of the permeability of a specific medium to the permeability of free space ( $\mu_r = \mu/\mu_0$ )
EOSMU	ID of the EOS to be used to define the behavior of $\mu$ by an equation of state (Note: if EOSMU is defined, MUREL will be used for the initial value only).

**\*EM\_MAT\_003**

Purpose: Define an electromagnetic material type whose electromagnetic conductivity is defined by a (3\*3) tensor matrix. Applications include composite materials.

**Orthotropic Card 1.**

Card 1	1	2	3	4	5	6	7	8
Variable	MID	MTYPE	SIGMA11	SIGMA22	SIGMA33			
Type	I	I	F	F	F			

**Orthotropic Card 2.**

Card 2	1	2	3	4	5	6	7	8
Variable	SIGMA12	SIGMA13	SIGMA21	SIGMA23	SIGMA31	SIGMA32	AOPT	
Type	F	F	F	F	F	F	I	

**Orthotropic Card 3.**

Card 1	1	2	3	4	5	6	7	8
Variable	XP	YP	ZP	A1	A2	A3	MACF	
Type	F	F	F	F	F	F	I	

**Orthotropic Card 4.**

Card 2	1	2	3	4	5	6	7	8
Variable	V1	V2	V3	D1	D2	D3		
Type	F	F	F	F	F	F		

**VARIABLE****DESCRIPTION**

MID

Material ID: refers to MID in the \*PART card.

MTYPE	Defines the electromagnetism type of the material: EQ.0: Air or vacuum EQ.1: Insulator material: These materials have the same electromagnetism behavior as EQ.0 EQ.2: Conductor carrying a source. In these conductors, the eddy current problem is solved, which gives the actual current density. Typically, this would correspond to the coil. EQ.4: Conductor not connected to any current or voltage source, where the Eddy current problem is solved. Typically, this would correspond to the workpiece.
SIGMA11	The 1, 1 term in the $3 \times 3$ electromagnetic conductivity tensor matrix. Note that 1 corresponds to the $a$ material direction
SIGMA12	The 1, 2 term in the $3 \times 3$ electromagnetic conductivity tensor matrix. Note that 2 corresponds to the $b$ material direction
⋮	⋮
SIGMA33	The 3, 3 term in the $3 \times 3$ electromagnetic conductivity tensor matrix.

**Define AOPT for both options:**

AOPT	Material axes option, see the figure in *MAT_002. EQ.0.0: locally orthotropic with material axes determined by element nodes as shown in part (a) the figure in *MAT_002. The a-direction is from node 1 to node 2 of the element. The b-direction is orthogonal to the a-direction and is in the plane formed by nodes 1, 2, and 4. EQ.1.0: locally orthotropic with material axes determined by a point in space and the global location of the element center; this is the a-direction. EQ.2.0: globally orthotropic with material axes determined by vectors defined below, as with *DEFINE_COORDINATE_VECTOR. EQ.3.0: locally orthotropic material axes determined by rotating the material axes about the element normal by an angle, BETA, from a line in the plane of the element defined by the cross product of the vector $v$ with the element normal. The plane of a solid element is the midsurface between the inner surface and outer surface defined by the
------	---

first four nodes and the last four nodes of the connectivity of the element, respectively.

EQ.4.0: locally orthotropic in cylindrical coordinate system with the material axes determined by a vector  $\mathbf{v}$ , and an originating point,  $P$ , which define the centerline axis. This option is for solid elements only.

EQ.5.0: globally defined reference frame with  $(a,b,c)=(X0,Y0,Z0)$ .

XP, YP, ZP      Define coordinates of point  $\mathbf{p}$  for AOPT = 1 and 4.

A1, A2, A3      Define components of vector  $\mathbf{a}$  for AOPT = 2.

MACF      Material axes change flag for solid elements:

EQ.1: No change, default,

V1, V2, V3      Define components of vector  $\mathbf{v}$  for AOPT = 3 and 4.

D1, D2, D3      Define components of vector  $\mathbf{d}$  for AOPT = 2.

### Remarks:

This card works in a similar way to \*MAT\_002.

The procedure for describing the principle material directions is explained for solid elements for this material model. We will call the material direction the **a-b-c** coordinate system. The AOPT options illustrated in the AOPT figure of \*MAT\_002 can define the **a-b-c** system for all elements of the parts that use the material.



**\*EM\_MAT\_004**

Purpose: Define the electromagnetic material type and properties for conducting shells in a 3D problem.

Include as many cards as needed. This input ends at the next keyword (“\*”) card.

Card 1	1	2	3	4	5	6	7	8
Variable	MID	MTYPE	SIGMA	EOSID	NELE			
Type	I	I	F	I	I			
Default	none	none	none	none	1			

**VARIABLE****DESCRIPTION**

MID	Material ID: refers to MID in the *PART card.
MTYPE	Defines the electromagnetism type of the material: EQ.0: Air or vacuum EQ.1: Insulator material. these materials have the same electromagnetism behavior as EQ.0 EQ.2: Conductor carrying a source. In these conductors, the eddy current problem is solved, which gives the actual current density. Typically, this would correspond to the coil. EQ.4: Conductor not connected to any current or voltage source, where the Eddy current problem is solved. Typically, this would correspond to the workpiece
SIGMA	Initial electrical conductivity of the material
EOSID	ID of the EOS to be used for the electrical conductivity (see *EM_-EOS cards).
NELE	Number of elements in the thickness of the shell. It is up to the user to make sure his mesh is fine enough to correctly capture the inductive-diffusive effects (see skin depth definition).

**\*EM\_OUTPUT**

Purpose: Define the level of EM related output on the screen and in the messag file.

Card 1	1	2	3	4	5	6	7	8
Variable	MATS	MATF	SOLS	SOLF	MESH	MEM	TIMING	
Type	I	I	I	I	I	I	I	
Default	0	0	0	0	0	0	0	

**VARIABLE****DESCRIPTION**

MATS

Level of matrix assembly output to the screen:

EQ.0: No output

EQ.1: Basic assembly steps

EQ.2: Basic assembly steps+percentage completed+final statistics

EQ.3: Basic assembly steps+percentage completed+statistics at each percentage of completion

MATF

Level of matrix assembly output to the messag file:

EQ.0: No output

EQ.1: Basic assembly steps

EQ.2: Basic assembly steps+percentage completed+final statistics

EQ.3: Basic assembly steps+percentage completed+statistics at each percentage of completion

SOLS

Level of solver output on the screen:

EQ.0: No output

EQ.1: Global information at each FEM iteration

EQ.2: Detailed information at each FEM iteration

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
SOLF	Level of solver output to the messag file: EQ.0: No output EQ.1: Global information at each FEM iteration EQ.2: Detailed information at each FEM iteration
MESH	Controls the output of the mesh data to the d3hsp file EQ.0: No mesh output EQ.1: Mesh info is written to the d3hsp file
MEMORY	Controls the output of information about the memory used by the EM solve to the messag file: EQ.0: no memory information written. EQ.1: memory information written.
TIMING	Controls the output of information about the time spent in the different parts of the EM solver to the messag file EQ.0: no timing information written. EQ.1: timing information written.

**\*EM\_POINT\_SET**

Purpose: This keyword creates a set of points which can be used by the \*EM\_DATA-BASE\_POINTOUT keyword.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	PSID	PSTYPE	VX	VY	VZ			
Type	I	I	F	F	F			
Default	0	0	0.	0.	0.			

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	PID	X	Y	Z				
Type	I	F	F	F				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

PSID	Point Set ID.
PSTYPE	Point Set type : EQ.0: Fixed points. EQ.1: Tracer points using prescribed velocity.
VX, VY, VZ	Constant velocities to be used when PSTYPE = 1
PID	Point ID
X, Y, Z	Point initial coordinates

**\*EM\_ROTATION\_AXIS**

Purpose: Define a rotation axis for the EM solver. This is used with the 2D axisymmetric solver. The axis is defined by a point and a direction.

Card 1	1	2	3	4	5	6	7	8
Variable	XP	YP	ZP	XD	YD	ZD	NUMSEC	
Type	F	F	F	F	F	F	I	
Default	none	none	none	none	none	none	none	

**VARIABLE****DESCRIPTION**

XP, YP, ZP

X,Y,Z coordinate of the point

XD, YD, ZD

X,Y,Z coordinate of direction of the axis

NUMSEC

Number of sectors: ratio of the full circle to the angular extension of the mesh. This has to be a power of 2. For example NUMSEC = 4 means that the mesh represents one fourth of the full 360 degrees circle.

**\*EM\_SOLVER\_BEM**

Purpose: Define the type of linear solver and pre-conditioner as well as tolerance for the EM\_BEM solve.

Card 1	1	2	3	4	5	6	7	8
Variable	RELTOL	MAXITE	STYPE	PRECON	USELAS	NCYCLBEM		
Type	I	I	I	I	I	I		
Default	1E-6	1000	2	2	1	5000		

**VARIABLE****DESCRIPTION**

RELTOL

Relative tolerance for the iterative solvers (PCG or GMRES). The user should try to decrease this tolerance if the results are not accurate enough. More iterations will then be needed.

MAXITER

Maximal number of iterations.

STYPE

Solver type:

EQ.1: Direct solve – the matrices will then be considered as dense.

EQ.2: Pre-Conditioned Gradient method (PCG) - this allows to have block matrices with low rank blocks, and thus reduce memory used.

EQ.3: GMRES method - this allows to have block matrices with low rank blocks and thus reduce memory used. The GMRES option only works in Serial for now.

PRECON

Preconditioner type for PCG or GMRES iterative solves:

EQ.0: No preconditioner

EQ.1: Diagonal line

EQ.2: Diagonal block

EQ.3: Broad diagonal including all neighbor faces

EQ.4: LLT factorization. The LLT factorization option only works in serial for now.

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
USELAST	This is used only for iterative solvers (PCG or GMRES). EQ.-1: Start from 0 as initial guess for solution of the linear system. EQ.1: Starts from the previous solution normalized by the RHS change.
NCYLBEM	Number of electromagnetism cycles between the recalculation of BEM matrices.

**Remarks:**

1. Using USELAST = 1 can save many iterations in the subsequent solves if the vector solution of the present solve is assumed to be nearly parallel to the vector solution of the previous solve, as usually happens in time-domain eddy-current problems.
2. Since the BEM matrices depend on (and only on) the surface node coordinates of the conductors, it is important to recalculate them when the conductors are moving. The frequency with which they are updated is controlled by NCYLBEM. Note that very small values, for example NCYLBEM = 1, should, generally, be avoided since this calculation involves a high computational cost. However, when two conductors are moving and in contact with each other it is recommended to recalculate the matrices at *every* time step.

**\*EM\_SOLVER\_BEMMAT**

Purpose: Define the type of BEM matrices as well as the way they are assembled.

Card 1	1	2	3	4	5	6	7	8
Variable	MATID							RELTOL
Type	I							F
Default	none							1E-6

**VARIABLE****DESCRIPTION**

MATID

Defines which BEM matrix the card refers to:

EQ.1: **P** matrix

EQ.2: **Q** matrix

RELTOL

Relative tolerance on the sub-blocks of the matrix when doing low rank approximations. The user should try to decrease these tolerances if the results are not accurate enough. More memory will then be needed.



## \*EM\_SOLVER\_FEM

Purpose: Define some parameters for the EM\_FEM solver.

Card 1	1	2	3	4	5	6	7	8
Variable	RELTOL	MAXITE	STYPE	PRECON	USELAST	NCYCLFEM		
Type	I	I	I	I	I	I		
Default	1E-3	1000	1	1	1	5000		

**VARIABLE****DESCRIPTION**

RELTOL	Relative tolerance for the iterative solvers (PCG or GMRES). The user should try to decrease this tolerance if the results are not accurate enough. More iterations will then be needed.
MAXITER	Maximal number of iterations.
STYPE	Solver type: EQ.1: Direct solve EQ.2: Conditioned Gradient Method (PCG)
PRECON	Preconditioner type for PCG. EQ.0: No preconditioner EQ.1: Diagonal line
USELAST	This is used only for iterative solvers (PCG). EQ.-1: starts from 0 as initial solution of the linear system. EQ.1: starts from previous solution normalized by the right-hand-side change change.
NCYLBEM	Number of electromagnetism cycles between the recalculation of FEM matrices.

**Remarks:**

1. Using USELAST = 1 can save many iterations in the subsequent solves if the vector solution of the present solve is assumed to be nearly parallel to the vector solution of the previous solve, as usually happens in time-domain eddy-current problems.
2. The default values are only valid when the PCG resolution method (STYPE = 2). For the default direct solve (STYPE = 1) those values are ignored.
3. When the conductor parts are deforming or undergoing changes in their EM material properties (conductivity for example), it is important to change the default value of NCYLFEM to recalculate the FEM matrices more often.

\*EM\_SOLVER\_FEMBEM

Purpose: Define some parameters for the coupling between the EM\_FEM and EM\_BEM solvers.

Card 1	1	2	3	4	5	6	7	8
Variable	RELTOL	MAXITE	FORCON					
Type	F	I	I					
Default	1E-2	50	0					

**VARIABLE**

**DESCRIPTION**

RELTOL                    Relative tolerance for the solver. The user should try to decrease this tolerance if the results are not accurate enough. More iterations will then be needed.

MAXITER                Maximal number of iterations.

FORCON                EQ.0: the code stops with an error if no convergence  
EQ.1: the code continues to the next time step even if the RELTOL convergence criteria has not been reached..



# \*ICFD

The keyword \*ICFD covers all the different options available in the incompressible fluid solver. The keyword cards in this section are defined in alphabetical order:

- \*ICFD\_BOUNDARY\_CONJ\_HEAT
- \*ICFD\_BOUNDARY\_FLUX\_TEMP
- \*ICFD\_BOUNDARY\_FREESLIP
- \*ICFD\_BOUNDARY\_FSI
- \*ICFD\_BOUNDARY\_NONSLIP
- \*ICFD\_BOUNDARY\_PRESCRIBED\_MOVEMESH
- \*ICFD\_BOUNDARY\_PRESCRIBED\_VEL
- \*ICFD\_BOUNDARY\_PRESCRIBED\_PRE
- \*ICFD\_BOUNDARY\_PRESCRIBED\_TEMP
- \*ICFD\_CONTROL\_ADAPT
- \*ICFD\_CONTROL\_ADAPT\_SIZE
- \*ICFD\_CONTROL\_FSI
- \*ICFD\_CONTROL\_IMPOSED\_MOVE
- \*ICFD\_CONTROL\_LOAD
- \*ICFD\_CONTROL\_MESH
- \*ICFD\_CONTROL\_MESH\_MOV
- \*ICFD\_CONTROL\_OUTPUT
- \*ICFD\_CONTROL\_OUTPUT\_SUBDOM
- \*ICFD\_CONTROL\_PARTITION
- \*ICFD\_CONTROL\_SURFMESH
- \*ICFD\_CONTROL\_TAVERAGE
- \*ICFD\_CONTROL\_TIME

\*ICFD\_CONTROL\_TURB\_SYNTHESIS

\*ICFD\_CONTROL\_TURBULENCE

\*ICFD\_DATABASE\_AVERAGE

\*ICFD\_DATABASE\_DRAG

\*ICFD\_DATABASE\_FLUX

\*ICFD\_DATABASE\_HTC

\*ICFD\_DATABASE\_NODEAVG

\*ICFD\_DATABASE\_NODOUT

\*ICFD\_DATABASE\_POINTAVG

\*ICFD\_DATABASE\_POINTOUT

ICFD\_DATABASE\_RESIDUALS

\*ICFD\_DATABASE\_TEMP

\*ICFD\_DATABASE\_TIMESTEP

\*ICFD\_DATABASE\_UINDEX

\*ICFD\_DEFINE\_NONINERTIAL

\*ICFD\_DEFINE\_POINT

\*ICFD\_INITIAL

\*ICFD\_MAT

\*ICFD\_PART

\*ICFD\_PART\_VOL

\*ICFD\_SECTION

\*ICFD\_SET\_NODE

\*ICFD\_SOLVER\_SPLIT

\*ICFD\_SOLVER\_TOL\_MMOV

\*ICFD\_SOLVER\_TOL\_MOM

\*ICFD\_SOLVER\_TOL\_PRE

\*ICFD\_SOLVER\_TOL\_TEMP

# \*ICFD

# \*ICFD\_BOUNDARY\_CONJ\_HEAT

## \*ICFD\_BOUNDARY\_CONJ\_HEAT

Purpose: Specify which boundary of the fluid domain will exchange heat with the solid.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID							
Type	I							
Default	none							

### VARIABLE

### DESCRIPTION

PID

PID of the fluid surface in contact with the solid.



**\*ICFD\_BOUNDARY\_FLUX\_TEMP**

Purpose: Impose a heat flux on the boundary expressed as  $q = \nabla T$

Include as many cards as needed. This input ends at the next keyword (""\*) card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	LCID	SF	DEATH	BIRTH			
Type	I	I	F	F	F			
Default	none	none	1.	1.E+28	0.0			

**VARIABLE****DESCRIPTION**

PID	PID for a fluid surface.
LCID	Load curve ID to describe the temperature flux value versus time, see *DEFINE_CURVE.
SF	Load curve scale factor. (default = 1.0)
DEATH	Time at which the imposed motion/constraint is removed: EQ.0.0: default set to 10e28
BIRTH	Time at which the imposed pressure is activated starting from the initial abscissa value of the curve

# \*ICFD

# \*ICFD\_BOUNDARY\_FREESLIP

## \*ICFD\_BOUNDARY\_FREESLIP

Purpose: Specify the fluid boundary with free-slip boundary condition.

Include as many cards as needed. This input ends at the next keyword (""\*) card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID							
Type	I							
Default	none							

### VARIABLE

### DESCRIPTION

PID

PID of the fluid surface where a free-slip boundary condition is applied.

**\*ICFD\_BOUNDARY\_FSI**

Purpose: This keyword defines which fluid surfaces will be considered in contact with the solid surfaces for fluid-structure interaction (FSI) analysis. This keyword should not be defined if \*ICFD\_CONTROL\_FSI is not defined.

Include as many cards as needed. This input ends at the next keyword (""\*) card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID							
Type	I							
Default	none							

**VARIABLE**

**DESCRIPTION**

PID

PID of the fluid surface in contact with the solid domain.

# \*ICFD

# \*ICFD\_BOUNDARY\_NONSLIP

## \*ICFD\_BOUNDARY\_NONSLIP

Purpose: Specify the fluid boundary with a non-slip boundary condition.

Include as many cards as needed. This input ends at the next keyword (\*\*) card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID							
Type	I							
Default	none							

### VARIABLE

### DESCRIPTION

PID

PID of the fluid surface where a non-slip boundary condition is applied.

\*ICFD\_BOUNDARY\_PRESCRIBED\_MOVEMESH

Purpose: Allows the node of a fluid surface to translate in certain directions using an ALE approach. This is useful in piston type applications or can also be used in certain cases to avoid big mesh deformation.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	dofx	dofy	dofz				
Type	I	I	I	I				
Default	none	1	1	1				

VARIABLE	DESCRIPTION
PID	PID for a fluid surface.
dofx, dofy, dofz	Degrees of freedom in the X,Y and Z directions : EQ.0: degree of freedom left free (Surface nodes can translate in the chosen direction) EQ.1: prescribed degree of freedom (Surface nodes are blocked)

## \*ICFD

## \*ICFD\_BOUNDARY\_PRESCRIBED\_PRE

### \*ICFD\_BOUNDARY\_PRESCRIBED\_PRE

Purpose: Impose a fluid pressure on the boundary.

Include as many cards as needed. This input ends at the next keyword (""\*) card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	LCID	SF	DEATH	BIRTH			
Type	I	I	F	F	F			
Default	none	none	1.	1.E+28	0.0			

### VARIABLE

### DESCRIPTION

PID	PID for a fluid surface.
LCID	Load curve ID to describe the pressure value versus time, see *DEFINE_CURVE.
SF	Load curve scale factor. (default = 1.0)
DEATH	Time at which the imposed motion/constraint is removed: EQ.0.0: default set to 10E28
BIRTH	Time at which the imposed pressure is activated starting from the initial abscissa value of the curve

**\*ICFD\_BOUNDARY\_PRESCRIBED\_TEMP**

Purpose: Impose a fluid temperature on the boundary.

Include as many cards as needed. This input ends at the next keyword (""\*) card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	LCID	SF	DEATH	BIRTH			
Type	I	I	F	F	F			
Default	none	none	1.	1.E+28	0.0			

<b>VARIABLE</b>	<b>DESCRIPTION</b>
PID	PID for a fluid surface.
LCID	Load curve ID to describe the temperature value versus time; see *DEFINE_CURVE.
SF	Load curve scale factor. (default = 1.0)
DEATH	Time at which the imposed temperature is removed: EQ.0.0: default set to 10E28
BIRTH	Time at which the imposed temperature is activated starting from the initial abscissa value of the curve

**\*ICFD****\*ICFD\_BOUNDARY\_PRESCRIBED\_VEL****\*ICFD\_BOUNDARY\_PRESCRIBED\_VEL**

Purpose: Impose the fluid velocity on the boundary.

Include as many cards as needed. This input ends at the next keyword (""\*) card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	DOF	VAD	LCID	SF	VID	DEATH	BIRTH
Type	I	I	I	I	F	I	F	F
Default	none	none	1	none	1.	0	1.E+28	0.0

**Optional Card.** Velocity profiles function of X, Y, Z coordinates

Card 2	1	2	3	4	5	6	7	8
Variable	LCIDX	LCIDY	LCIDZ					
Type	I	I	I					
Default	0	0	0					

**VARIABLE****DESCRIPTION**

PID	PID for a fluid surface.
DOF	Applicable degrees-of-freedom: EQ.1: x- degree-of-freedom, EQ.2: y- degree-of-freedom, EQ.3: z- degree-of-freedom, EQ.4: Normal direction degree-of-freedom,



---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
VAD	Velocity flag: EQ.1: Linear velocity EQ.2: Angular velocity EQ.3: Parabolic velocity profile EQ.4: Activates synthetic turbulent field on part (See *ICFD_-CONTROL_TURB_SYNTHESIS)
LCID	Load curve ID used to describe motion value versus time, see *DEFINE_CURVE, *DEFINE_CURVE_FUNCTION, or *DEFINE_FUNCTION. See BIRTH below.
SF	Load curve scale factor. (default = 1.0)
VID	Point ID for angular velocity application point, see *ICFD_DEFINE_POINT.
DEATH	Time at which the imposed motion/constraint is removed: EQ.0.0: default set to 10E28
BIRTH	Time at which the imposed motion/constraint is activated starting from the initial abscissa value of the curve
LCIDX	Scaling factor function of X coordinate.
LCIDY	Scaling factor function of Y coordinate.
LCIDZ	Scaling factor function of Z coordinate.

**\*ICFD\_CONTROL\_ADAPT**

Purpose: This keyword will activate the adaptive mesh refinement feature. The solver will use an a-posteriori error estimator to compute a new mesh size bounded by the user to satisfy a maximum perceptual global error.

Card 1	1	2	3	4	5	6	7	8
Variable	MINH	MAXH	ERR	MTH	NIT			
Type	F	F	F	I	I			
Default	none	none	none	0	0			

**VARIABLE****DESCRIPTION**

MINH	Minimum mesh size allowed to the mesh generator. The resulting mesh will not have an element smaller than MINH even if the minimum size does not satisfy the maximum error.
MAXH	Maximum mesh size.
ERR	Maximum perceptual error allowed in the whole domain.
MTH	Specify if the mesh size is computed based on function error or gradient error. EQ.0: Function error. EQ.1: Gradient error.
NIT	Number of iterations before a re-meshing is forced. Default forces a re-meshing at every timestep.

**\*ICFD\_CONTROL\_ADAPT\_SIZE**

Purpose: This keyword controls the re-meshing of elements taking into account the element quality and distortion in contrast to the default algorithm which only checks for inverted elements.

Card 1	1	2	3	4	5	6	7	8
Variable	ASIZE	NIT						
Type	I	I						
Default	0	none						

**VARIABLE**

**DESCRIPTION**

ASIZE

EQ.0: only re-mesh in cases where elements invert.

EQ.1: re-mesh if elements invert or if element quality deteriorates.

NIT

Number of iterations before a re-meshing is forced.

**\*ICFD\_CONTROL\_FSI**

Purpose: This keyword modifies default values for the fluid-structure interaction coupling algorithm.

Card 1	1	2	3	4	5	6	7	8
Variable	OWC	BT	DT	IDC				
Type	I	F	F	F				
Default	0	0	1E+28	0.25				

**VARIABLE****DESCRIPTION**

OWC

Indicates the coupling direction to the solver.

EQ.0: two-way coupling. Loads and displacements are transferred across the FSI interface and the full non-linear problem is solved.

EQ.1: one-way coupling. The solid mechanics solver transfers displacements to the fluid solver.

EQ.2: one-way coupling. The fluid solver transfers stresses to the solid mechanics solver.

BT

Birth time for the FSI coupling. Before BT the fluid solver will not pass any loads to the structure but it will receive displacements from the solid mechanics solver.

DT

Death time for the FSI coupling. After DT the fluid solver will not transfer any loads to the solid mechanics solver but the fluid will continue to deform with the solid.


IDC

Interaction detection coefficient. See Remark 1.

**Remarks:**

1. One of the criteria to automatically detect the fluid and solid surfaces that will interact in FSI problems is the distance  $d$  between a fluid (solid) node and a solid (fluid) element respectively:

$$d \leq IDC \times \min(h, H)$$



**Figure 5-1.** Geometry of FSI contact.

where  $h$  is the size of the fluid mesh,  $H$  the size of the solid mechanics mesh, and IDC a detection coefficient criteria with  $IDC = 0.25$  by default. In the majority of cases, this default value is sufficient to ensure FSI interaction. However, it can happen in special cases that the fluid and solid geometries have curvatures that differ too much (example: pipe flows in conjugate heat transfer applications). In such cases, a bigger IDC value may be needed. This flag should be handled with care.

**\*ICFD\_CONTROL\_IMPOSED\_MOVE**

Purpose: This keyword allows the user to impose a velocity on a volume mesh. This can be used in order to save calculation time in certain applications such as sloshing where the modeling of the whole fluid box and the solving of the consequent FSI problem is not necessarily needed.

Include as many cards as needed. This input ends at the next keyword (“\*”) card.

Card 1	1	2	3	4	5	6	7	8
Variable	VPID	LCVX	LCVY	LCVZ				
Type	I	I	I	I				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

VPID

Volume Mesh PID

LCVX, LCVY,  
LCVZ

LCID for the velocity in the three directions (X,Y,Z).

**\*ICFD\_CONTROL\_LOAD**

Purpose: This keyword resets the body load in the ICFD solver to zero, while leaving the body load unchanged for the solid mechanics solver. It is useful in problems where the gravity acceleration may be neglected for the fluid problem, but not for the solid mechanics problem.

Card 1	1	2	3	4	5	6	7	8
Variable	ABL							
Type	I							
Default	1							

**VARIABLE**

**DESCRIPTION**

ABL

EQ.0: the body load provided in \*LOAD\_BODY is reset to zero only for the fluid analysis.

**\*ICFD\_CONTROL\_MESH**

Purpose: This keyword modifies default values for the automatic volume mesh generation. Only used in 3D cases.

Card 1	1	2	3	4	5	6	7	8
Variable	MGSF							
Type	F							
Default	1.41							

**VARIABLE****DESCRIPTION**

MGSF

Mesh Growth Scale Factor : Specifies the maximum mesh size that the volume mesher is allowed to use when generating the volume mesh based on the mesh surface element sizes defined in \*MESH\_SURFACE\_ELEMENT.

Values between 1 and 2 are allowed. Values closer to 1 will result in a finer volume mesh (1 means the volume mesh is not allowed to be coarser than the element size from the closest surface meshes) and values closer to 2 will result in a coarser volume mesh (2 means the volume can use elements as much as twice as coarse as those from the closest surface mesh).



## \*ICFD\_CONTROL\_MESH\_MOV

Purpose: With this keyword the user can choose the type of algorithm for mesh movement.

Card 1	1	2	3	4	5	6	7	8
Variable	MMSH	LIM_ITER	RELTOL	ABSTOL				
Type	I	I	F	F				
Default	2	100	1.0e-3	5.0e-4				

**VARIABLE****DESCRIPTION**

MMSH	Mesh motion selector: EQ.1: mesh moves based on the distance to moving walls. EQ.2: mesh moves by solving a linear elasticity problem using the element sizes as stiffness.(default) EQ.3: mesh uses a Laplacian smoothing with stiffness on edges and from node to opposite faces. Very robust, but costly. EQ.4: full Lagrangian: The mesh moves with the velocity of the flow. EQ.11: mesh moves using an implicit ball-vertex spring method.
LIM_ITER	Maximum number of linear solver iterations for the ball-vertex linear system.
RELTOL	Relative tolerance to use as a stopping criterion for the ball-vertex method iterative linear solver (conjugate gradient solver with diagonal scaling preconditioner).
ABSTOL	Absolute tolerance measure for the size of mesh displacement changes to use as a stopping criterion for the ball-vertex iterative linear solver.

**\*ICFD\_CONTROL\_OUTPUT**

Purpose: This keyword modifies default values for screen and file outputs related to this fluid solver only.

Card 1	1	2	3	4	5	6	7	8
Variable	MSGL	OUTL	DTOUT					
Type	I	I	F					
Default	0	0	0					

**VARIABLE****DESCRIPTION**

MSGL

Message level.

EQ.0: only time step information is output.

EQ.1: first level solver information.

EQ.2: full output information with details about linear algebra and convergence steps.

EQ.4: full output information is also copied to the messag file.

OUTL

Output the fluid results in other file formats apart from d3plot.

EQ.0: only d3plot output

EQ.2: output a file with mesh statistics and the fluid results in OpenDX format. A directory named dx will be created in the work directory where the output files will be written.

EQ.5: output a file with the automatically created fluid volume mesh in a format compatible for LSPP.

EQ.6: output a file with mesh statistics and the fluid results in Paraview format. A directory named vtk will be created in the work directory where the output files will be written.

EQ. 7: output a file with mesh statistic and the fluid results in VTU format readable by Paraview. A directory named vtk will be created in the work directory where the output files will be written.

DTOUT

Time interval to print the output when OUTL is different than 0.

\*ICFD\_CONTROL\_OUTPUT\_SUBDOM

Purpose: Defines a specific zone that should be output in the format specified by the ICFD\_CONTROL\_OUTPUT card rather than the whole domain.

**Remeshing Control.** First card specifies the shape of the output sub domain.

Card 1	1	2	3	4	5	6	7	8
Variable	SNAME							
Type	A							
Default	none							

**Box Case.** Card 2 for Sname = box

Cards 2	1	2	3	4	5	6	7	8
Variable	PMINX	PMINY	PMINZ	PMAXX	PMAXY	PMAXZ		
Type	F	F	F	F	F	F		
Default	none	none	none	none	none	none		

**Sphere Case.** Card 2 for Sname = sphere

Cards 3	1	2	3	4	5	6	7	8
Variable	RADIUS	CENTERX	CENTERY	CENTERZ				
Type	F	F	F	F				
Default	none	none	none	none				

**Cylinder Case.** Card 2 for Sname = cylinder

Cards 4	1	2	3	4	5	6	7	8
Variable	Radius	PMINX	PMINY	PMAZ	PMAXX	PMAXY	PMAZ	
Type	F	F	F	F	F	F	F	
Default	none	none	none	none	none	none	none	

<b>VARIABLE</b>	<b>DESCRIPTION</b>
SNAME	Shape name. Possibilities include 'box', 'cylinder' and 'sphere'
PMINX, Y, Z]	X, Y, Z for the point of minimum coordinates
PMAX[X, Y, Z]	X, Y, Z for the point of maximum coordinates
CENTER[X, Y, Z]	Coordinates of the sphere center in cases where Sname is Sphere
RADIUS	Radius of the sphere if SNAME is <i>sphere</i> or of the cross section disk if SNAME is <i>cylinder</i> .

\*ICFD\_CONTROL\_PARTITION

Purpose: This keyword changes the default option for the partition in MPP, thus it is only valid in MPP.

Card 1	1	2	3	4	5	6	7	8
Variable	PTECH							
Type	I							
Default	1							

**VARIABLE**

**DESCRIPTION**

PTECH

Indicates the type of partition.

EQ.1: the library Metis is used.

EQ.2: partition along the axis with higher aspect ratio.

EQ.3: partition along X axis.

EQ.4: partition along Y axis.

EQ.5: partition along Z axis.

**\*ICFD\_CONTROL\_SURFMESH**

Purpose: This keyword enables automatic surface re-meshing. The objective of the re-meshing is to improve the mesh quality on the boundaries. It should not be used on a regular basis.

Card 1	1	2	3	4	5	6	7	8
Variable	RSRF							
Type	I							
Default	0							

**VARIABLE****DESCRIPTION**

RSRF

Indicates whether or not to perform a surface re-meshing.

EQ.0: no re-meshing is applied.

EQ.1: allows the surface mesh to be re-meshed

**\*ICFD\_CONTROL\_TAVERAGE**

Purpose: This keyword controls the restarting time for computing the time average values. By default, there is no restarting and the average quantities are given starting from  $t = 0$ . This keyword can be useful in turbulent problems that admit a steady state.

Card 1	1	2	3	4	5	6	7	8
Variable	DT							
Type	F							
Default	none							

**VARIABLE**

**DESCRIPTION**

DT

Over each DT time interval, the average quantities are reset.

**\*ICFD\_CONTROL\_TIME**

Purpose: This keyword is used to change the defaults related to time parameters in the fluid problem.

Card 1	1	2	3	4	5	6	7	8
Variable	TTM	DT	CFL	LCIDSF				
Type	F	F	F	I				
Default	1.E28	0	1	none				

**VARIABLE****DESCRIPTION**

TTM	Total time of simulation for the fluid problem.
DT	Time step for the fluid problem. If different from zero, the time step will be set constant and equal to this value. If $DT = 0$ , then the time step is automatically computed based on the CFL condition.
CFL	CFL number for $DT = 0$ . In general, CFL specifies a scale factor that is applied to the time step. When $DT = 0$ , the time step is set to the maximum value satisfying the CFL condition, in which case this scale factor is equal to the <i>CFL number</i> .
LCIDSF	Load Curve ID specifying the CFL number when $DT = 0$ as a function of time, and more generally LCIDSF specifies the time step scale factor as the function of time.



\*ICFD\_CONTROL\_TURBULENCE

Purpose: This keyword enables the user to modify the default values for the turbulence model.

Card 1	1	2	3	4	5	6	7	8
Variable	TMOD							
Type	I							
Default	0							

Option TMOD = 1.

Card 2	1	2	3	4	5	6	7	8
Variable	Ce1	Ce2	$\sigma_e$	$\sigma_k$	$C_\mu$			
Type	F	F	F	F	F			
Default	1.44	1.92	1.3	1.0	0.09			

Option TMOD = 2 or TMOD = 3.

Card 3	1	2	3	4	5	6	7	8
Variable	Cs							
Type	F							
Default	0.18							

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
TMOD	Indicates what turbulence model will be used. EQ.0: Turbulence model based on a variational multiscale approach is used by default. EQ.1: RANS k- $\epsilon$ approach. EQ.2: LES Smagorinsky sub-grid scale model. EQ.3: LES Wall adapting local eddy-viscosity (WALE) model.
Ce1, Ce2, $\sigma_e$ , $\sigma_k$ , $C_\mu$	k- $\epsilon$ model constants
Cs	Smagorinsky constant is TMOD = 2 or WALE constant if TMOD = 3

**\*ICFD\_CONTROL\_TURB\_SYNTHESIS**

Purpose: This keyword enables the user impose a divergence-free turbulent field on inlets.

Card must be used jointly with VAD = 4 of keyword \*ICFD\_BOUNDARY\_PRESCRIBED\_-VEL.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	IU	IV	IW	LS			
Type	I	F	F	F	F			
Default	0	1e-3	1e-3	1e-3	$h_{min}$			

**VARIABLE****DESCRIPTION**

PID	Part ID of the surface with the turbulent velocity inlet condition.
IU, IV, IW	Intensity of field fluctuations (in %) over $x, y, z$ directions, $IU = \frac{u'}{u_{rms}}$
LS	Integral length scale of turbulence

**Remarks:**

1. If this card is not defined but a turbulent field inlet has been activated (See VAD = 4 of \*ICFD\_BOUNDARY\_PRESCRIBED\_-VEL), the default parameters will be used.

**\*ICFD\_DATABASE\_AVERAGE**

Purpose: This keyword enables the computation of time average variables at given time intervals.

Card 1	1	2	3	4	5	6	7	8
Variable	DT							
Type	F							
Default	none							

**VARIABLE**

**DESCRIPTION**

DT Over each DT time interval, an average of the different fluid variables will be calculated and then reset when moving to the next DT interval.

**Remarks:**

1. The file name for this database is icfdavg.\*.dat with the different averaged variable values copied in a ASCII format.

**\*ICFD\_DATABASE\_DRAG**

Purpose: This keyword enables the computation of drag forces over given parts of the model. If multiple keywords are given, the forces over the PID surfaces are given in separate files and are also added and output in a separate file.

**Surface Drag Cards.** Include one card for each surface on which drag is applied. This input ends at the next keyword (“\*”) card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	CPID						
Type	I	I						
Default	none	none						

**VARIABLE****DESCRIPTION**

PID	Part ID of the surface where the drag force will be computed.
CPID	Center point ID used for the calculation of the force’s moment. By default the reference frame center is used: $\mathbf{0} = (0,0,0)$ .

**Remarks:**

1. The file name for this database is icfdragi for instantaneous drag and icfdraga for the drag computed using average values of pressure and velocities.
2. The output contains “Fpx” , “Fpy” , “Fpz” refer to the three components of the pressure drag force

$$\mathbf{F}_p = \int P dA,$$

With  $P$  the pressure and  $A$  the surface area. while “Fvx” , “Fxy” , “Fvz” refer to the three components of the viscous drag force

$$\mathbf{F}_v = \int \mu \frac{\partial \mathbf{u}}{\partial y} dA.$$

With  $\frac{\partial \mathbf{u}}{\partial y}$  the shear velocity at the wall,  $\mu$  the viscosity and  $A$  the surface area.

“Mpx” , “Mpy” , “Mpz” and “Mvx” , “Mvy” , “Mvz” refer to the three components of the pressure and viscous force moments respectively.

**\*ICFD\_DATABASE\_FLUX**

Purpose: This keyword enables the computation of the flow rate and average pressure over given parts of the model. If multiple keywords are given, separate files are output.

Include as many cards as needed. This input ends at the next keyword (“\*”) card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID							
Type	I							
Default	none							

**VARIABLE****DESCRIPTION**

PID

Part ID of the surface where the flow rates will be computed.

**Remarks:**

1. The file name for this database is icfd\_flux.dat.
2. The flux database contains the flow rate through a section, called “output flux”,

$$\Phi = \sum_i (\mathbf{V}_i \cdot \mathbf{n}_i) A_i,$$

the average pressure, called “Pre-avg”,

$$P_{\text{avg}} = \frac{\sum_i P_i A_i}{\sum_i A_i},$$

and the total area, called “Areatot”.

## \*ICFD\_DATABASE\_HTC

Purpose: This keyword allows the user to choose how the bulk temperature is defined when calculating the heat transfer coefficient variable (See Remark 1).

Card 1	1	2	3	4	5	6	7	8
Variable	OUT	HTC	TB					
Type	I	I	F					
Default	0	0.	0.					

**VARIABLE****DESCRIPTION**

OUT	Determines if the solver should calculate the heat transfer coefficient. EQ.0: Off. EQ.1: On.
HTC	Determines how the bulk temperature is defined. EQ.0: Automatically calculated by the solver based on the average temperature flowing through the pipe section (See Remark 1). EQ.1: User imposed value (See Remark 2).
TB	Value of the bulk temperature if HTC = 1.

**Remarks:**

1. The heat transfer coefficient is frequently used in thermal applications to estimate the effect of the fluid cooling and it derived from a CFD calculation.
2. The heat transfer coefficient is defined as follows:

$$h = \frac{q}{T_s - T_b}$$

with  $q$  the heat flux,  $T_s$  the surface temperature and  $T_b$  the so called "bulk" temperature. For external aerodynamic applications, this bulk temperature is often defined as a constant (ambient or far field conditions, HTC = 1). However, for internal aerodynamic application, this temperature is often defined as an average

temperature flowing through the pipe section with the flow velocity being used as a weighting factor ( $HTC = 0$ ).



**\*ICFD\_DATABASE\_NODEAVG**

Purpose: This keyword enables the computation of the average quantities on surface nodes defined in \*ICFD\_DATABASE\_NODOUT.

Card 1	1	2	3	4	5	6	7	8
Variable	ON							
Type	I							
Default	0							

**VARIABLE**

**DESCRIPTION**

ON

If equal to 1, the average quantities will be computed.

**Remarks:**

1. The file name for this database is icfd\_nodeavg.dat.

**\*ICFD\_DATABASE\_NODOUT**

Purpose: This keyword enables the output of ICFD data on surface nodes. For data in the fluid volume, it is advised to use points or tracers (See \*ICFD\_DATABASE\_POINTOUT).

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV	DTOUT						
Type	I	F						
Default	0	0.						

Include as many cards as needed. This input ends at the next keyword ("\*\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	NID1	NID2	NID3	NID4	NID5	NID6	NID7	NID8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**VARIABLE****DESCRIPTION**

OUTLV	Determines if the output file should be dumped. EQ.0: No output file is generated. EQ.1: The output file is generated.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the ICFD timestep will be used.
NID..	Node IDs.

**Remarks:**

1. The file name for this database is icfd\_nodout.dat.

**\*ICFD\_DATABASE\_POINTAVG**

Purpose: This keyword enables the computation of the average quantities on point sets using the parameters defined in \*ICFD\_DATABASE\_POINTOUT.

Card 1	1	2	3	4	5	6	7	8
Variable	ON							
Type	I							
Default	0							

**VARIABLE**

**DESCRIPTION**

ON

If equal to 1, the average quantities will be computed.

**Remarks:**

1. The file name for this database is icfd\_psavg.dat.

**\*ICFD\_DATABASE\_POINTOUT**

Purpose: This keyword enables the output of ICFD data on points.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	PSID	DTOUT	PSTYPE	VX	VY	VZ		
Type	I	F	I	F	F	F		
Default	0	0.	0	0.	0.	0.		

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	PID	X	Y	Z				
Type	I	F	F	F				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

PSID	Point Set ID.
DTOUT	Time interval to print the output. If DTOUT is equal to 0.0, then the ICFD timestep will be used.
PSTYPE	Point Set type : EQ.0: Fixed points. EQ.1: Tracer points using prescribed velocity. EQ.2: Tracer points using fluid velocity. EQ.3: Tracer points using mesh velocity..
VX, VY, VZ	Constant velocities to be used when PSTYPE = 1
PID	Point ID

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
X, Y, Z	Point initial coordinates

---

**Remarks:**

1. The file name for this database is icfd\_pointout.dat.

**\*ICFD\_DATABASE\_RESIDUALS**

Purpose: This keyword allows the user to output the residuals of the various systems.

Card 1	1	2	3	4	5	6	7	8
Variable	RLVL							
Type	I							
Default	0							

**VARIABLE****DESCRIPTION**

RLVL

Residual output level :

EQ.0: No output.

EQ.1: Only outputs the number of iterations needed for solving the pressure Poisson equation.

EQ.2: Outputs the number of iterations for the momentum, pressure, mesh movement and temperature equations.

EQ.3: Also gives the residual for each iteration during the solve of the momentum, pressure, mesh movement and temperature equations.

**Remarks:**

1. The file names for the momentum, pressure, mesh movement and temperature equations are called `icfd_residuals.momX.dat`, `icfd_residuals.pres.dat`, `icfd_residuals.mmov.dat`, and `icfd_residuals.temp.dat` respectively.

**\*ICFD\_DATABASE\_TEMP**

Purpose: This keyword enables the computation of the average temperature and the heat flux over given parts of the model. If multiple keywords are given, separate files are output.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID							
Type	I							
Default	none							

**VARIABLE****DESCRIPTION**

PID	Part ID of the surface where the average temperature and heat flux will be computed.
-----	--

**Remarks:**

1. The file name for this database is icfd\_thermal.dat.
2. Two average temperature are given in the icfd\_thermal.dat file: "Temp-avg" and "Temp-sum". The average temperature is calculated using the local node area as weighting factor,

$$T_{\text{avg}} = \frac{\sum_i^N T_i A_i}{\sum_i^N A_i},$$

whereas, the sum is not weighted by area

$$T_{\text{sum}} = \frac{\sum_i^N T_i}{N}$$

If the mesh is regular, the two values will be of similar value. The icfd\_thermal.dat output file also includes the average heat flux, the total surface area, and the average heat transfer coefficients (See \*ICFD\_DATABASE\_HTC).

**\*ICFD\_DATABASE\_TIMESTEP**

Purpose: This keyword enables the output of ICFD data regarding the ICFD timestep.

**Output Options Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	OUTLV							
Type	I							
Default	0							

**VARIABLE****DESCRIPTION**

OUTLV

Determines if the output file should be dumped.

EQ.0: No output file is generated.

EQ.1: The output file is generated.

**Remarks:**

1. The file name for this database is icfd\_tsout.dat.
2. Outputs the run's ICFD timestep versus the timestep calculated using the ICFD CFL condition as criteria (autotimestep). This can be useful in cases using a fixed timestep where big mesh deformations and/or big fluid velocity changes occur in order to track how that fixed timestep value compares to the reference autotimestep.



## \*ICFD\_DATABASE\_UINDEX

Purpose: This keyword allows the user to have the solver calculate the uniformity index (See [Remark 1](#)).

Card 1	1	2	3	4	5	6	7	8
Variable	OUT							
Type	I							
Default	0							

**VARIABLE****DESCRIPTION**

OUT

Determines if the solver should calculate the heat transfer coefficient.

EQ.0: Off.

EQ.1: On.

**Remarks:**

1. **Uniformity Index.** The uniformity index is a post treatment quantity which measures how uniform the flow is through a given section. It is especially useful in internal aerodynamics cases. It is expressed as :

$$\gamma = 1 - \frac{1}{2nA} \sum_{i=1}^n \left[ \frac{\sqrt{(u_i - \bar{u})^2}}{\bar{u}} A_i \right]$$

with  $A_i$ , the local cell area,  $A$  the total section area,  $u_i$  the local velocity,  $\bar{u}$  the average velocity through the section, and  $n$  the number of cells.

Values close to 0 means that the flow is very unevenly distributed. This can be used to identify bends, corners or turbulent effects. Values close to 1 imply smooth or equally distributed flow through the surface.

**\*ICFD\_DEFINE\_POINT**

Purpose: This keyword defines a point in space that could be used for multiple purposes.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	POID	X	Y	Z				
Type	I	F	F	F				
Default	none	none	none	none				

**VARIABLE****DESCRIPTION**

POID	Point ID.
X	x coordinate for the point.
Y	y coordinate for the point.
Z	z coordinate for the point.

\*ICFD\_DEFINE\_NONINERTIAL

Purpose: This keyword defines a non-inertial reference frame in order to avoid heavy mesh distortions and attendant remeshing associated with large-scale rotations. This is used to model, for example, spinning cylinders, wind turbines, and turbo machinery.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	W1	W2	W3	R	PTID	L	LCID	RELV
Type	F	F	F	F	I	F	I	I
Default	none	none	none	none	none	none	none	0

VARIABLE	DESCRIPTION
W1, W2, W3	Rotational Velocity along the X,Y,Z axes
R	Radius of the rotating reference frame
PTID	Starting point ID for the reference frame (See *ICFD_DEFINE_POINT)
L	Length of the rotating reference frame
LCID	Load curve for scaling factor of w




Figure 5-2. Non Inertial Reference Frame Example

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
RELV	Velocities computed and displayed:  EQ.0: Relative velocity, only the non-rotating components of the velocity are used and displayed.  EQ.1: Absolute velocity . All the components of the velocity are used. Useful in cases where several or at least one non-inertial reference frame is combined with an inertial "classical" reference frame.

**\*ICFD\_INITIAL**

Purpose: Simple initialization of velocity and temperature within a volume.

Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	Vx	Vy	Vz	T	P		
Type	I	F	F	F	F	F		
Default	none	none	none	none	none	none		

**VARIABLE****DESCRIPTION**

PID	Part ID for the volume elements or the surface elements where the values are initialized (see *ICFD_PART_VOL and *ICFD_PART). PID = 0 to assign the initial condition to all nodes at once.
Vx	x coordinate for the velocity.
Vy	y coordinate for the velocity.
Vz	z coordinate for the velocity.
T	Initial temperature.
P	Initial Pressure.

**\*ICFD\_MAT**

Purpose: Specify physical properties for the fluid material.

**Fluid Material Card Sets:**

The Material Fluid Parameters Card is required. If a second card is given, it must be a Thermal Fluid Parameters Card. If the fluid thermal properties are not needed, the second card can be a blank card. If a third card is given, it must be a Non-Newtonian Fluid Parameters Card. If a fourth card is given, it must be to define the porous media properties. The fifth and sixth cards need only to be defined if the porous media is anisotropic.

**Material Fluid Parameters Card.**

Card 1	1	2	3	4	5	6	7	8
Variable	MID	FLG	R0	VIS	ST	THD		
Type	I	I	F	F	F	F		
Default	none	1	0	0	0	0		

**Thermal Fluid Parameters Card.** Only to be defined if the thermal problem is solved.

Card 2	1	2	3	4	5	6	7	8
Variable	HC	TC	BETA					
Type	F	F	F					
Default	0	0	0					

**Non-Newtonian Fluid Parameters Card.** Only to be defined if the fluid is non-newtonian.

Card 3	1	2	3	4	5	6	7	8
Variable	NNID	K	N					
Type	I	F	F					
Default	0	0	0					

**Porous Media Parameters Card.** Only to be defined if the domain is a porous media.

Card 4	1	2	3	4	5	6	7	8
Variable	PMMID	POR	PER/THIC	FF	LCID			
Type	I	F	F	F	I			
Default	0	0.	0.	0.	none			

**Permeability Vector Card in local reference frame.** Only to be defined if the porous media is anisotropic.


Card 5	1	2	3	4	5	6	7	8
Variable	KX'	KY'	KZ'					
Type	F	F	F					
Default	0	0.	0.					

**Projection of local Vectors in global reference frame.** Only to be defined if the porous media is anisotropic.

Card 6	1	2	3	4	5	6	7	8
Variable	1-X	1-Y	1-Z	2-X	2-Y	2-Z		
Type	F	F	F	F	F	F		
Default	0	0.	0.	0.	0.	0.		

<b>VARIABLE</b>	<b>DESCRIPTION</b>
MID	Material ID.
FLG	Flag to choose between fully incompressible, slightly compressible, or barotropic flows. EQ.0 : Vacuum (free surface problems only) EQ.1 : Fully incompressible fluid.
RO	Flow density.
VIS	Dynamic viscosity.
ST	Surface tension coefficient.
THD	Thermal diffusion used in the solution of the thermal problem. (Does not need to be defined if HC and TC exist).
HC	Heat capacity.
TC	Thermal conductivity.
BETA	Thermal expansion coefficient used in the Boussinesq approximation for buoyancy.
NNID	Non Newtonian flows model ID. EQ.1 : Power Law.
K	Power Law input parameter. Measure of the average velocity of the fluid (consistency index).
N	Measure of the deviation of the fluid from Newtonian.





**Figure 5-3.** Anisotropic porous media vectors definition (PMMID = 4). The vectors  $\mathbf{X}$  and  $\mathbf{Y}$  are the global axes;  $\mathbf{x}'$  and  $\mathbf{y}'$  define system for the primed coordinate  $(x', y', z')$ .

VARIABLE	DESCRIPTION
PMMID	Porous media model ID EQ.1 : Ergun Correlation EQ.2 : Darcy-Forchheimer model EQ.3 : Permeability defined through Pressure-Velocity Data EQ.4 : Anisotropic porous media model (See <a href="#">Figure 5-3</a> ).
POR	Porosity $\varepsilon$ .
PER/THIC	Permeability $\kappa$ if PMMID = 1 or 2. Probe Thickness $\Delta x$ if PMMID = 3.
FF	Forchheimer factor. To Be defined if PMMID = 2.
LCID	Pressure function of Velocity Load Curve ID. To be defined if PMMID = 3.
KX'/KY'/KZ'	Permeability vector in local reference frame $(x', y', z')$ . To be defined in PMMID = 4.
1-X/1-Y/1-Z	Projection of local permeability vector $\mathbf{x}'$ in global reference frame $(x, y, z)$ . To be defined if PMMID = 4.
2-X/2-Y/2-Z	Projection of local permeability vector $\mathbf{y}'$ in global reference frame $(x, y, z)$ . To be defined if PMMID = 4.

**\*ICFD\_PART\_{OPTION}**

Available options include

**TITLE**

Purpose: Define parts for this incompressible flow solver.

The TITLE option allows the user to define an additional optional line with a HEADING in order to associate a name to the part.

Card 1	1	2	3	4	5	6	7	8
Variable	HEADING							
Type	A							
Default	none							

**Part Material Card.** Include as many cards as needed. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	PID	SECID	MID					
Type	I	I	I					
Default	none	none	none					

**VARIABLE****DESCRIPTION**

PID	Part identifier for fluid surfaces.
SECID	Section identifier defined with the *ICFD_SECTION card.
MID	Material identifier defined with the *ICFD_MAT card.

**\*ICFD\_PART\_VOL\_{OPTION}**

Available options include

**TITLE**

Purpose: This keyword assigns material properties to the nodes enclosed by surface ICFD parts.

The TITLE option allows the user to define an additional optional line with a HEADING in order to associate a name to the part.

Variable	1	2	3	4	5	6	7	8
Type	A							
Default	none							

Card 1	1	2	3	4	5	6	7	8
Variable	PID	SECID	MID					
Type	I	I	I					
Default	none	none	none					

Provide as many cards as necessary. This input ends at the next keyword ("\*") card

Card 2	1	2	3	4	5	6	7	8
Variable	SPID1	SPID2	SPID3	SPID4	SPID5	SPID6	SPID7	SPID8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**VARIABLE**

**DESCRIPTION**


PID

Part identifier for fluid volumes.

SECID

Section identifier defined by the \*ICFD\_SECTION card.

VARIABLE	DESCRIPTION
MID	Material identifier.
SPID1, ...	Part IDs for the surface elements that define the volume mesh.



```

$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$
$$$$ *ICFD_PART_VOL
$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$
$
$ PART ID 5 is defined by the surfaces that enclose it.
$
*ICFD_PART_VOL
$
$.>...1.>...2.>...3.>...4.>...5.>...6.>...7.>...8
$   pid   secid   mid
$     5     1     1
$.>...1.>...2.>...3.>...4.>...5.>...6.>...7.>...8
$   pid1   pid2   pid3   pid4   pid5   pid6   pid7   pid8
$     1     2     3     4

```

**\*ICFD\_SECTION**

Purpose: Define a section for the incompressible flow solver.

Card 1	1	2	3	4	5	6	7	8
Variable	SID							
Type	I							
Default	none							

**VARIABLE**

**DESCRIPTION**

SID                      Section identifier.

**\*ICFD\_SET\_NODE\_LIST**

Purpose: Only used in cases where the mesh is specified by the user (See \*MESH\_VOLUME\_ELEMENT). Defines a set of nodes associated with a part ID on which boundary conditions can be applied.

Card 1	1	2	3	4	5	6	7	8
Variable	SID	PID						
Type	I	I						
Default	none	none						

**Node List Card.** Provide as many cards as necessary. This input ends at the next keyword ("\*") card

Card 2	1	2	3	4	5	6	7	8
Variable	NID1	NID2	NID3	NID4	NID5	NID6	NID7	NID8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**VARIABLE****DESCRIPTION**

SID	Set ID
PID	Associated Part ID.
NID1, ...	Node IDs

**Remarks:**

1. The convention is the similar to the one used by the keyword \*SET\_NODE\_LIST and serves a similar purpose.

\*ICFD\_SOLVER\_SPLIT

Purpose: This keyword provides an option to trigger an iterative procedure on the fluid system. This procedure aims to bring more precision to the final pressure and velocity values but is often very time consuming. It must therefore be used with caution. It is intended only for special cases. For stability purposes, this method is automatically used for the first ICFD time step.

Card 1	1	2	3	4	5	6	7	8
Variable	NIT	TOL						
Type	I	F						
Default	1	10 <sup>-3</sup>						

<b>VARIABLE</b>	<b>DESCRIPTION</b>
NIT	Maximum Number of iterations of the system for each fluid time step. If TOL criteria is not reached after NIT iterations, the run will proceed.
TOL	Tolerance Criteria for the pressure residual during the fluid system solve.

**\*ICFD\_SOLVER\_TOL\_MMOV**

Purpose: This keyword allows the user to change the default tolerance values for the mesh movement algorithm. *Care should be taken when deviating from the default values.*

Card 1	1	2	3	4	5	6	7	8
Variable	ATOL	RTOL		MAXIT				
Type	F	F		I				
Default	1e-8	1e-8		1000				

**VARIABLE****DESCRIPTION**

ATOL	Absolute convergence criteria. Convergence is achieved when $\text{Residual}_{i+1} - \text{Residual}_i \leq \text{ATOL}$ . If a negative integer is entered, then that value will be used as a load curve ID for ATOL.
RTOL	Relative convergence criteria. Convergence is achieved when $(\text{Residual}_{i+1} - \text{Residual}_i) / \text{Residual}_{\text{initial}} \leq \text{RTOL}$ . If a negative integer is entered, then that value will be used as a load curve ID for RTOL.
MAXIT	Maximum number of iterations allowed to achieve convergence. If a negative integer is entered, then that value will be used as a load curve ID for MAXIT.



## \*ICFD\_SOLVER\_TOL\_MOM

Purpose: This keyword allows the user to change the default tolerance values for the momentum equation solve. *Care should be taken when deviating from the default values.*

Card 1	1	2	3	4	5	6	7	8
Variable	ATOL	RTOL		MAXIT				
Type	F	F		I				
Default	10 <sup>-8</sup>	10 <sup>-8</sup>		1000				

**VARIABLE****DESCRIPTION**

ATOL	Absolute convergence criteria. Convergence is achieved when $\text{Residual}_{i+1} - \text{Residual}_i \leq \text{ATOL}$ . If a negative integer is entered, then that value will be used as a load curve ID for ATOL.
RTOL	Relative convergence criteria. Convergence is achieved when $(\text{Residual}_{i+1} - \text{Residual}_i) / \text{Residual}_{\text{initial}} \leq \text{RTOL}$ . If a negative integer is entered, then that value will be used as a load curve ID for RTOL.
MAXIT	Maximum number of iterations allowed to achieve convergence. If a negative integer is entered, then that value will be used as a load curve ID for MAXIT.

**\*ICFD\_SOLVER\_TOL\_PRE**

Purpose: This keyword allows the user to change the default tolerance values for the Poisson equation for pressure. *Care should be taken when deviating from the default values.*

Card 1	1	2	3	4	5	6	7	8
Variable	ATOL	RTOL		MAXIT				
Type	F	F		I				
Default	10 <sup>-8</sup>	10 <sup>-8</sup>		1000				

**VARIABLE****DESCRIPTION**

ATOL	Absolute convergence criteria. Convergence is achieved when $\text{Residual}_{i+1} - \text{Residual}_i \leq \text{ATOL}$ . If a negative integer is entered, then that value will be used as a load curve ID for ATOL.
RTOL	Relative convergence criteria. Convergence is achieved when $(\text{Residual}_{i+1} - \text{Residual}_i) / \text{Residual}_{\text{initial}} \leq \text{RTOL}$ . If a negative integer is entered, then that value will be used as a load curve ID for RTOL.
MAXIT	Maximum number of iterations allowed to achieve convergence. If a negative integer is entered, then that value will be used as a load curve ID for MAXIT.

## \*ICFD\_SOLVER\_TOL\_TEMP

Purpose: This keyword allows the user to change the default tolerance values for the heat equation. To be handled with great care.

Card 1	1	2	3	4	5	6	7	8
Variable	ATOL	RTOL		MAXIT				
Type	F	F		I				
Default	1e-8	1e-8		1000				

**VARIABLE****DESCRIPTION**

ATOL	Absolute convergence criteria. Convergence is achieved when $Residual_{i+1} - Residual_i \leq ATOL$ . If a negative integer is entered, then that value will be used as a load curve ID for ATOL.
RTOL	Relative convergence criteria. Convergence is achieved when $(Residual_{i+1} - Residual_i) / Residual_{initial} \leq RTOL$ . If a negative integer is entered, then that value will be used as a load curve ID for RTOL.
MAXIT	Maximum number of iterations allowed to achieve convergence. If a negative integer is entered, then that value will be used as a load curve ID for MAXIT.



---

# \*MESH

The keyword \*MESH is used to create a mesh that will be used in the analysis. So far only tetrahedral (or triangular in 2-d) elements can be generated. The keyword cards in this section are defined in alphabetical order:

- \*MESH\_BL
- \*MESH\_BL\_SYM
- \*MESH\_EMBEDSHELL
- \*MESH\_INTERF
- \*MESH\_NODE
- \*MESH\_SIZE\_
- \*MESH\_SIZE\_SHAPE
- \*MESH\_SURFACE\_ELEMENT
- \*MESH\_SURFACE\_NODE
- \*MESH\_VOLUME
- \*MESH\_VOLUME\_ELEMENT
- \*MESH\_VOLUME\_NODE
- \*MESH\_VOLUME\_PART

An additional option “\_TITLE” may be appended to all \*MESH keywords. If this option is used, then an 80 character string is read as a title from the first card of that keyword's input. At present, LS-DYNA does not make use of the title. Inclusion of titles gives greater clarity to input decks.

**\*MESH\_BL**

Purpose: This keyword is used to define a boundary-layer mesh as a refinement on volume-mesh. The boundary layer mesh is constructed by subdividing elements near the surface.

**Boundary Layer Cards.** Define as many cards as are necessary. The next "\*" card terminates the input.

Card 1	1	2	3	4	5	6	7	8
Variable	PID	NELTH						
Type	I	I						
Default	none	none						

**VARIABLE****DESCRIPTION**

PID

Part identifier for the surface element.

NELTH

Number of elements normal to the surface (in the boundary layer). For every additional NELTH, the automatic volume mesher will divide the elements closest to the surface by two so that the smallest element in the boundary layer mesh will have an aspect ratio of  $2^{\text{NELTH}+1}$ .

\*MESH\_BL\_SYM

Purpose: Specify the part IDs that will have symmetry conditions for the boundary layer. On these surfaces, the boundary layer mesh follows the surface tangent.

**Boundary Layer with Symmetry Condition Cards.** Define as many cards as necessary. The next "\*" card terminates the input.

Card 1	1	2	3	4	5	6	7	8
Variable	PID1	PID2	PID3	PID4	PID5	PID6	PID7	PID8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**VARIABLE**

**DESCRIPTION**

PID1, ...

Part identifiers for the surface element. This is the surface with symmetry.

**\*MESH\_EMBEDSHELL**

Purpose: Define surfaces that the mesher will embed inside the volume mesh. These surfaces will have no thickness and will conform to the rest of the volume mesh having matching nodes on the interface.

Card 1	1	2	3	4	5	6	7	8
Variable	VOLID							
Type	I							
Default	none							

Define as many cards as are necessary based on the number of PIDs (the next "\*" card terminates the input.)

Card 2	1	2	3	4	5	6	7	8
Variable	PID1	PID2	PID3	PID4	PID5	PID6	PID7	PID8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**VARIABLE****DESCRIPTION**

VOLID	ID assigned to the new volume in the keyword *MESH_VOLUME. The surface mesh size will be applied to this volume.
PID <sub>n</sub>	Part IDs for the surface elements that will be embedded in the volume mesh.



**\*MESH\_INTERF**

Purpose: Define the surfaces that will be used by the mesher to specify fluid interfaces in multi-fluid simulations.

Card 1	1	2	3	4	5	6	7	8
Variable	VOLID							
Type	I							
Default	none							

Define as many cards as are necessary based on the number of PIDs. This input ends at the next keyword ("\*") card.

Card 2	1	2	3	4	5	6	7	8
Variable	PID1	PID2	PID3	PID4	PID5	PID6	PID7	PID8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**VARIABLE****DESCRIPTION**

VOLID ID assigned to the new volume in the keyword \*MESH\_VOLUME. The interface meshes will be applied to this volume.

PID<sub>*n*</sub> Part IDs for the surface elements.

**\*MESH\_NODE**

Purpose: Define a fluid node and its coordinates. These nodes are used in the mesh generation process by the \*MESH\_SURFACE\_ELEMENT keyword, or as user defined volume nodes by the \*MESH\_VOLUME\_ELEMENT keyword.

**Node Cards.** Include one additional card for each node. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8	9	10
Variable	NID	X		Y		Z				
Type	I	F		F		F				
Default	none	0		0		0				

**VARIABLE****DESCRIPTION**

NID	Node ID. A unique number with respect to the other surface nodes.
X	<i>x</i> coordinate.
Y	<i>y</i> coordinate.
Z	<i>z</i> coordinate.

**Remarks:**

1. The data card format for the \*MESH\_NODE keyword is identical to \*NODE.
2. The \*MESH\_NODE keyword supersedes \*MESH\_SURFACE\_NODE, which was for surfaces nodes as well as \*MESH\_VOLUME\_NODE for, which was for volume nodes in user defined.

**\*MESH\_SIZE**

Purpose: Define the surfaces that will be used by the mesher to specify a local mesh size inside the volume. If no internal mesh is used to specify the size, the mesher will use a linear interpolation of the surface sizes that define the volume enclosure.

Card 1	1	2	3	4	5	6	7	8
Variable	VOLID							
Type	I							
Default	none							

Define as many cards as are necessary based on the number of PIDs (the next "\*" card terminates the input.).

Card 2	1	2	3	4	5	6	7	8
Variable	PID1	PID2	PID3	PID4	PID5	PID6	PID7	PID8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**VARIABLE****DESCRIPTION**

VOLID	ID assigned to the new volume in the keyword *MESH_VOLUME. The mesh sizing will be applied to this volume.
PID $n$	Part IDs for the surface elements that are used to define the mesh size next to the surface mesh.

**\*MESH\_SIZE\_SHAPE**

Purpose: Defines a local mesh size in specific zones corresponding to given geometrical shapes (box, sphere, cylinder). The solver will automatically apply the conditions specified during the generation of the volume mesh. This zone does not need to be entirely defined in the volume mesh.

**Remeshing Control Card sets:**

Add any number of pairs of Remeshing Control Cards paired with a Box Case Card, a Sphere Case Card, or a Cylinder Case Card.

**Remeshing Control.** First card specifies whether to maintain this mesh sizing criterion through a remesh operation.

Card 1	1	2	3	4	5	6	7	8
Variable	SNAME	FORCE						
Type	A	I						
Default	none	0						

**Box Case.** Card 2 for SNAME = box

Cards 2	1	2	3	4	5	6	7	8
Variable	MSIZE	PMINX	PMINY	PMINZ	PMAXX	PMAXY	PMAXZ	
Type	F	F	F	F	F	F	F	
Default	none	none	none	none	none	none	none	

**Sphere Case.** Card 2 for SNAME = sphere

Cards 3	1	2	3	4	5	6	7	8
Variable	MSIZE	RADIUS	CENTERX	CENTERY	CENTERZ			
Type	F	F	F	F	F			
Default	none	none	none	none	none			

**Cylinder Case.** Card 2 for SNAME = cylinder

Cards 4	1	2	3	4	5	6	7	8
Variable	MSIZE	RADIUS	PMINX	PMINY	PMINZ	PMAXX	PMAXY	PMAXZ
Type	F	F	F	F	F	F	F	F
Default	none	none	none	none	none	none	none	none

<b>VARIABLE</b>	<b>DESCRIPTION</b>
SNAME	Shape name. Possibilities include "box", "cylinder" and "sphere"
FORCE	Force to keep the mesh size criteria even after a remeshing is done. EQ.0: Off, mesh size shape will be lost if a remeshing occurs EQ.1: On.
MSIZE	Mesh size that needs to be applied in the zone of the shape defined by SNAME
PMIN[X, Y, Z]	X, Y, Z for the point of minimum coordinates
PMAX[X, Y, Z]	X, Y, Z for the point of maximum coordinates
CENTER[X, Y, Z]	Coordinates of the sphere center in cases where SNAME is Sphere
RADIUS	Radius of the sphere if SNAME is Sphere or of the cross section disk if SNAME is Cylinder.

**\*MESH\_SURFACE\_ELEMENT**

Purpose: Specify a set of surface elements (quadrilateral or triangular in 3-d and linear segments in 2-d) that will be used by the mesher to construct a volume mesh. These surface elements may be used to define the enclosed volume to be meshed, or alternatively they could be used to apply different mesh sizes inside the volume (see card \*MESH\_SIZE).

**Surface Element Card.** Define as many cards as necessary. The next "\*" card terminates the input.

Card 1	1	2	3	4	5	6	7	8	9	10
Variable	EID	PID	N1	N2	N3	N4				
Type	I	I	I	I	I	I				
Default	none	none	none	none	none	none				

**VARIABLE****DESCRIPTION**

EID	Element ID. A unique number with respect to all *MESH_SURFACE_ELEMENTS cards.
PID	Mesh surface part ID. A unique identifier for the surface to which this mesh surface element belongs.
N1	Nodal point 1.
N2	Nodal point 2.
N3	Nodal point 3.
N4	Nodal point 4.

**Remarks:**

1. The convention is the same used by the keyword \*ELEMENT\_SHELL. In the case of a triangular face  $N3 = N4$ . In 2-d  $N2 = N3 = N4$ . Note that the accepted card format is 6i8 (not 6i10)

**\*MESH\_SURFACE\_NODE**

Purpose: Define a node and its coordinates. These nodes will be used in the mesh generation process by the \*MESH\_SURFACE\_ELEMENT keyword.

\*MESH\_NODE supersedes this card; so please use \*MESH\_NODE instead of this card.

**Surface Node Cards.** Include one card for each node. Include as many cards a necessary. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8	9	10
Variable	NID	X		Y		Z				
Type	I	F		F		F				
Default	none	0		0		0				

**VARIABLE****DESCRIPTION**

NID	Node ID. This NID must be unique within the set of surface nodes.
X	<i>x</i> coordinate.
Y	<i>y</i> coordinate.
Z	<i>z</i> coordinate.

**\*MESH\_VOLUME**

Purpose: This keyword defines the volume space that will be meshed. The boundaries of the volume are the surfaces defined by \*MESH\_SURFACE\_ELEMENT. The surfaces listed have to be non-overlapping, and should not leave any gaps or open spaces between the surface boundaries. On the boundary between two neighbor surfaces, nodes have to be in common (no duplicate nodes) and should match exactly on the interface. They are defined by the keyword \*MESH\_SURFACE\_NODE. This card will be ignored if the volume mesh is specified by the user and not generated automatically.

Card 1	1	2	3	4	5	6	7	8
Variable	VOLID							
Type	I							
Default	none							

Define as many cards as are necessary based on the number of PIDs (the next "\*" card terminates the input.)

Card 2	1	2	3	4	5	6	7	8
Variable	PID1	PID2	PID3	PID4	PID5	PID6	PID7	PID8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**VARIABLE****DESCRIPTION**

VOLID

ID assigned to the new volume.

PID<sub>n</sub>

Part IDs for the surface elements that are used to define the volume.



**\*MESH\_VOLUME\_ELEMENT**

Purpose: Specify a set of volume elements for the fluid volume mesh in cases where the volume mesh is specified by the user and not generated automatically. The Nodal point are specified in the \*MESH\_VOLUME\_NODE keyword. Only tetrahedral elements are supported (triangles in 2D).

**Volume Element Card.** Define as many cards as necessary. The next "\*" card terminates the input.

Card 1	1	2	3	4	5	6	7	8	9	10
Variable	EID	PID	N1	N2	N3	N4				
Type	I	I	I	I	I	I				
Default	none	none	none	none	none	none				

**VARIABLE****DESCRIPTION**

EID	Element ID. A unique number with respect to all *MESH_VOLUME_ELEMENTS cards.
PID	Part ID. A unique part identification number.
N1	Nodal point 1.
N2	Nodal point 2.
N3	Nodal point 3.
N4	Nodal point 4.

**Remarks:**

1. The convention is the same used by the keyword \*ELEMENT\_SHELL.

**\*MESH\_VOLUME\_NODE**

Purpose: Define a node and its coordinates. This keyword is only used in cases where the fluid volume mesh is provided by the user and is not automatically generated. It serves the same purpose as the \*NODE keyword for solid mechanics. Only tetrahedral elements are supported.

\*MESH\_NODE supersedes this card; so please use \*MESH\_NODE instead of this card.

**Volume Node Cards.** Include as many cards in the following format as desired. This input ends at the next keyword ("\*") card.

Card 1	1	2	3	4	5	6	7	8	9	10
Variable	NID	X	Y	Z						
Type	I	F	F	F						
Default	none	0	0	0						

**VARIABLE****DESCRIPTION**

NID	Node ID. A unique number with respect to the other volume nodes.
X	<i>x</i> coordinate.
Y	<i>y</i> coordinate.
Z	<i>z</i> coordinate.

**\*MESH\_VOLUME\_PART**

Purpose: Associate a volume part number created by a \*MESH\_VOLUME card with the part number of a part card from a selected solver (designated by the SOLVER field).

**Mesh Volume Part Card.** Include as many cards in the following format as desired. This input ends at the next keyword (“\*”) card.

Card 1	1	2	3	4	5	6	7	8
Variable	VOLPRT	SOLPRT	SOLVER					
Type	I	I	A					
Default								

**VARIABLE**

**DESCRIPTION**

- VOLPRT Part ID of a volume part created by a \*MESH\_VOLUME card.
- SOLPRT Part ID of a part created using SOLVER’s part card.
- SOLVER Name of a solver using a mesh created with \*MESH cards.



# **\*STOCHASTIC**

The keyword **\*STOCHASTIC** is used to describe the particles and numerical details for solving a set of stochastic PDEs. Currently, there are two types of stochastic PDE models in the code: a model of embedded particles in TBX explosives, and a spray model. The cards for using these models are:

**\*STOCHASTIC\_SPRAY\_PARTICLES**

**\*STOCHASTIC\_TBX\_PARTICLES**

An additional option “\_TITLE” may be appended to all **\*STOCHASTIC** keywords. If this option is used, then an 80 character string is read as a title from the first card of that keyword's input. At present, LS-DYNA does not make use of the title. Inclusion of titles gives greater clarity to input decks.

**\*STOCHASTIC\_SPRAY\_PARTICLES**

Purpose: Specify particle and other model details for spray modeling using stochastic PDEs that approximate such processes. A pair of cards is required to specify the characteristics of each nozzle (cards 3 and 4 describe the first nozzle).

Card 1	1	2	3	4	5	6	7	8
Variable	INJDIST	IBRKUP	ICOLLDE	IEVAP	IPULSE	LIMPR	IDFUEL	
Type	I	I	I	I	I	I	I	
Default	1	none	none	none	none	none	1	

Card 2	1	2	3	4	5	6	7	8
Variable	RHOP	TIP	PMASS	PRTRTE	STRINJ	DURINJ		
Type	F	F	F	F	F	F		

**Nozzle card 1:** Provide as many pairs of nozzle cards 1 and 2 as necessary. This input ends at the next keyword ("\*") card (following a nozzle card 2).

Card 3	1	2	3	4	5	6	7	8
Variable	XORIG	YORIG	ZORIG	SMR	VELINJ	DRNOZ	DTHNOZ	
Type	F	F	F	F	F	F	F	

**Nozzle card 2:** Provide as many pairs of nozzle cards 1 and 2 as necessary. This input ends at the next keyword ("\*") card.

Card 4	1	2	3	4	5	6	7	8
Variable	TILTXY	TILTXZ	CONE	DCONE	ANOZ	AMPO		
Type	F	F	F	F	F	F		

<b>VARIABLE</b>	<b>DESCRIPTION</b>
INJDIST	Spray particle size distribution: EQ.1: uniform EQ.2: Rosin-Rammler (default) EQ.3: Chi-squared degree of 2 EQ.4: Chi-squared degree of 6
IBRKUP	Type of particle breakup model: EQ.0: off (no breakup) EQ.1: TAB EQ.2: KHRT
ICOLLDE	Turn collision modeling on or off
IEVAP	Turn evaporation on or off
IPULSE	Type of injection: EQ.0: continuous injection EQ.1: sine wave EQ.2: square wave
LIMPRT	Upper limit on the number of parent particles modeled in this spray. This is not used with the continuous injection case (IPULSE = 0).
IDFUEL	Selected spray liquid fuels: EQ.1: (Default), H <sub>2</sub> O EQ.2: Benzene, C <sub>6</sub> H <sub>6</sub> EQ.3: Diesel # 2, C <sub>12</sub> H <sub>26</sub> EQ.4: Diesel # 2, C <sub>13</sub> H <sub>13</sub> EQ.5: Ethanol, C <sub>2</sub> H <sub>5</sub> OH EQ.6: Gasoline, C <sub>8</sub> H <sub>18</sub> EQ.7: Jet-A, C <sub>12</sub> H <sub>23</sub> EQ.8: Kerosene, C <sub>12</sub> H <sub>23</sub> EQ.9: Methanol, CH <sub>3</sub> OH EQ.10: N-dodecane, C <sub>12</sub> H <sub>26</sub>

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
RHOP	Particle density
TIP	Initial particle temperature.
PMASS	Total particle mass
PRTRTE	Number of particles injected per second for continuous injection.
STRINJ	Start of injection(s)
DURINJ	Duration of injection(s)
XORIG	X-coordinate of center of a nozzle's exit plane
YORIG	Y-coordinate of center of a nozzle's exit plane
ZORIG	Z-coordinate of center of a nozzle's exit plane
SMR	Sauter mean radius
VELINJ	Injection velocity
DRNOZ	Nozzle radius
DTHNOZ	Azimuthal angle (in degrees measured counterclockwise) of the injector nozzle from the $j = 1$ plane.
TILTXY	Rotation angle (in degrees) of the injector in the x-y plane, where 0.0 points towards the 3 o'clock position ( $j = 1$ line), and the angle increases counterclockwise from there.
TILTXZ	Inclination angle (in degrees) of the injection in the x-z plane, where 0.0 points straight down, $x > 0.0$ points in the positive x direction, and $x < 0.0$ points in the negative x direction.
CONE	Spray mean cone angle (in degrees) for hollow cone spray; spray cone angle (in degrees) for solid cone spray.
DCONE	Injection liquid jet thickness in degrees.
ANOZ	Area of injector
AMP0	Initial amplitude of droplet oscillation at injector



**\*STOCHASTIC\_TBX\_PARTICLES**

Purpose: Specify particle and other model details for stochastic PDEs that model embedded particles in TBX explosives. Note that the components listed on the corresponding \*CHEMISTRY\_COMPOSITION card are in terms of molar concentrations of the species (in units of moles/[length]<sup>3</sup>, where “[length]” is the user’s length unit).

For further information on the theory of the TBX model that has been implemented, a document on this topic can be found at this URL:

[http://www.lstc.com/applications/cese\\_cfd/documentation](http://www.lstc.com/applications/cese_cfd/documentation)

Card 1	1	2	3	4	5	6	7	8
Variable	PCOMB	NPRTCL	MXCNT	PMASS	SMR	RHOP	TICP	T_IGNIT
Type	I	I	I	F	F	F	F	F
Default	0	none	none	none	none	none	none	none

Card 2	1	2	3	4	5	6	7	8
Variable	INITDST	AZIMTH	ALTITD	CPS/CVS	HVAP	EMISS	BOLTZ	
Type	I	F	F	F	F	F	F	
Default	1	none	none	none	none	none	none	
Remarks						1	1	

Card 3	1	2	3	4	5	6	7	8
Variable	XORIG	YORIG	ZORIG	XVEL	YVEL	ZVEL	FRADIUS	
Type	F	F	F	F	F	F	F	
Default	none	none	none	0.0	0.0	0.0	none	

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
PCOMB	Particle combustion model EQ.0: no burning EQ.1: K-model
NPRTCL	Initial total number of parent particles (discrete particles for calculation)
MXCNT	Maximum allowed number of parent particles (during the simulation)
PMASS	Total particle mass
SMR	Sort mean particle radius
RHOP	Particle density
TICP	Initial particle temperature
T_IGNIT	Particle ignition temperature
INITDST	Initial particle distribution EQ.1: spatially uniform EQ.2: Rosin-Rammler EQ.3: Chi-squared
AZIMTH	Angle in degrees from $x$ -axis in $x$ - $y$ plane of reference frame of TBX explosive ( $0 < AZMITH < 360$ )
ALTITD	Angle in degrees from $z$ -axis of reference frame of TBX explosive ( $0 < ALTITD < 180$ )
CPS/CVS	Heat coefficient
HVAP	Latent heat of vaporization
EMISS	Particle emissivity
BOLTZ	Boltzmann coefficient
XORIG	$x$ -coordinate of the origin of the initial reference frame of the TBX explosive

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
YORIG	<i>y</i> -coordinate of the origin of the initial reference frame of the TBX explosive
ZORIG	<i>z</i> -coordinate of the origin of the initial reference frame of the TBX explosive
XVEL	<i>x</i> -component of the initial particle velocity the TBX explosive
YVEL	<i>y</i> -component of the initial particle velocity the TBX explosive
ZVEL	<i>z</i> -component of the initial particle velocity the TBX explosive
FRADIUS	Radius of the explosive area.

**Remarks:**

1. If radiation heat transfer is being modeled, then EMISS and BOLTZ are required.



---

# \*LSO

These cards provide a general data output mechanism, causing the creation of a sequence of LSDA files. This facility is intended to allow several different time sequences of data to be output in the same simulation. In addition, any number of domains (and any number of variables on those domains) may be specified within each time sequence. The keyword cards in this section are defined in alphabetical order:

\*LSO\_DOMAIN

\*LSO\_ID\_SET (*not available in the single-precision version of LS-DYNA*)

\*LSO\_POINT\_SET

\*LSO\_TIME\_SEQUENCE

\*LSO\_VARIABLE\_GROUP

Note that only the mechanics solver is available in the single-precision version of LS-DYNA, and therefore, only LSO mechanics variables are available for output. These mechanics variables are listed by domain type in a separate document. This document (LSO\_VARIABLES.TXT) is created by running the command: LS-DYNA print\_lso\_doc.

An additional option “\_TITLE” may be appended to all \*LSO keywords. If this option is used, then an 80 character string is read as a title from the first card of that keyword's input. At present, LS-DYNA does not make use of the title. Inclusion of titles gives greater clarity to input decks.

**\*LSO\_DOMAIN**

Purpose: This command provides a way to specify variables on a subset of the domain for a given solver. This domain can be a subset of the mesh used by that solver, a set of output points created with \*LSO\_POINT\_SET, or a set of objects created with \*LSO\_ID\_SET. The frequency and duration of the output for any given domain is determined by each \*LSO\_-TIME\_SEQUENCE card that references this \*LSO\_DOMAIN card. Note that for the single-precision version of LS-DYNA, the only allowed value of SOLVER\_NAME = MECH.

Card 1	1	2	3	4	5	6	7	8
Variable	DOMAIN_TYPE							
Type	A							

Card 2	1	2	3	4	5	6	7	8
Variable	SOLVER_NAME							
Type	A							

**Special Domains Card.** Card 3 when DOMAIN\_TYPE is one of ROGO, CIRCUIT, THIST\_POINT or TRACER\_POINT.

Card 3	1	2	3	4	5	6	7	8
Variable	OUTID	REFID		REDUCT				
Type	I	I		I				
Default	none	none		none				

**Miscellaneous Domain Card.** Card 3 when DOMAIN\_TYPE is one of NODE, PART, SEGMENT, SURFACE\_NODE, SURFACE\_ELEMENT, VOLUME\_ELEMENT, SURFACE\_PART, VOLUME\_PART.

Card 4	1	2	3	4	5	6	7	8
Variable	OUTID	REFID	OVERRIDE	REDUCT				
Type	I	I	I	I				
Default	none	0	0	none				

**Variable Name Card.** Provide as many cards as necessary. This input ends at the next keyword ("\*\*") card

Card 5	1	2	3	4	5	6	7	8
Variable	VARIABLE_NAME							
Type	A							

**VARIABLE****DESCRIPTION**

DOMAIN_ TYPE	The type of domain for which LSO output may be generated.
SOLVER_ NAME	Selects the solver from which data is output on this domain. Accepted entries so far are 'MECH', 'EM', 'CESE', and 'ICFD'.
OUTID	LSO domain ID associated with this domain, and used by *LSO_-TIME_SEQUENCE cards.
REFID	Support set ID. This can be a set defined by a *SET card, a *LSO_-ID_SET, card, or a *LSO_POINT_SET card. Unless OVERRIDE is specified, this set must be of the same type as DOMAIN_TYPE.

<b>VARIABLE</b>	<b>DESCRIPTION</b>
OVERRIDE	<p>If non-zero, then REFID is interpreted as:</p> <p>EQ.1: a PART set for SOLVER_NAME</p> <p>EQ.2: a PART set of volume parts created with a *LSO_ID_SET card (volume parts are defined with *MESH_VOLUME cards).</p> <p>EQ.3: a PART set of surface parts created with a *LSO_ID_SET card (surface parts are defined with *MESH_SURFACE_ELEMENT cards).</p> <p>EQ.4: a set of segment sets created with a *LSO_ID_SET card.</p>
REDUCT	<p>A function that operates on the entire domain and returns a single value for scalar variables, three values for vector variables, or 6 values for symmetric tensor variables. For REDUCT='range', the number of returned values doubles. The following are the supported functions:</p> <p>EQ.BLANK: no reduction (default)</p> <p>EQ.'none': Same as above</p> <p>EQ.'avg': the average by component</p> <p>EQ.'average': Same as above</p> <p>EQ.'min': the minimum by component</p> <p>EQ.'minimum': Same as above</p> <p>EQ.'max': the maximum by component</p> <p>EQ.'maximum': Same as above</p> <p>EQ.'sum': the sum by component</p> <p>EQ.'range': the minimum by component followed by the maximum by component</p>
VARIABLE_NAME	<p>Either the name of a single output variable or a variable group. See remarks.</p>

**Remarks:**

1. Supported choices for VARIABLE\_NAME are listed by DOMAIN\_TYPE for each SOLVER\_NAME in a separate document. This document (LSO\_VARIABLES.TXT) is created by running the command: LS-DYNA print Iso\_doc. The following table



shows a sample of the point output variables available when DOMAIN\_TYPE = THIST\_POINT:

*Selected Point Output Variables*

	<b>EM</b>	<b>ICFD</b>	<b>CESE</b>
<b>VECTORS</b>	magneticField_point electricField_point vecpotField_point currentDensity2_point	velocity_point	velocity_point
<b>SCALARS</b>	ScalarPotential_point	pressure_point temperature_point density_point lset_point	pressure_point temperature_point density_point

**\*LSO\_ID\_SET**

Purpose: Provides a way to create a set of existing sets (segment sets), or to define a set that is not available with other set-related keyword cards. These are then used in other \*LSO cards to specify LSO output. This card is not available in the single precision version of LS-DYNA.

Card 1	1	2	3	4	5	6	7	8
Variable	SETID	TYPE	SOLVER					
Type	I	A	A					
Default	none	none	MECH					

**Referenced IDs.** Provide as many cards as necessary. This input ends at the next keyword ("\*") card

Card	1	2	3	4	5	6	7	8
Variable	ID1	ID2	ID3	ID4	ID5	ID6	ID7	ID8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**VARIABLE****DESCRIPTION**

SETID

Identifier for this ID set.

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
TYPE	The kind of IDs in this set: EQ.'SEG_SETS': Each ID is a segment set connected with SOLVER. EQ.'CIRCUIT': Each ID is a circuit ID (from *EM cards) EQ.'SURF_PARTS': Each ID is a surface part number (See *MESH_SURFACE_ELEMENT) EQ.'VOL_PARTS': Each ID is a volume part number (See *MESH_VOLUME) EQ.'SURF_ELES': Each ID is a surface element number (See *MESH_SURFACE_ELEMENT)
SOLVER	Name of the solver (MECH, ICFD, CESE, EM, ...)
ID1, ...	IDs of the TYPE kind.

**\*LSO\_POINT\_SET**

Purpose: Define a list of points used to sample variables in time. Of the different sampling methods, the most common one is to specify points for time history output.

Card 1	1	2	3	4	5	6	7	8
Variable	SETID	USE						
Type	I	I						
Default	none	1						
Remarks		1						

**Point Cards.** Provide as many cards as necessary. This input ends at the next keyword ("\*") card

Card	1	2	3	4	5	6	7	8
Variable	X	Y	Z					
Type	F	F	F					
Default	none	none	none					

**VARIABLE****DESCRIPTION**

SETID	Identifier for this point set. Used by *LSO_DOMAIN
USE	Points in this set are used as: EQ.1: Fixed time history points (default) EQ.2: Positions of tracer particles
X, Y, Z	Coordinates of a point. As many points as desired can be specified.

**Remarks:**

1. For  $USE = 1$ , with the ICFD and CESE solvers, the fixed points have to remain inside the fluid mesh or a zero result is returned, while for the EM solver, the points can be defined inside the conductors or in the air. In the latter case, the fields will be computed using a Biot-Savart type integration. For  $USE = 2$ , a massless tracer particle is tracked for the ICFD and CESE solvers using their local velocity field to integrate the position of each particle in time.

**\*LSO\_TIME\_SEQUENCE**

Purpose: This command provides users with maximum flexibility in specifying exactly what they want to have appear in the output LSO binary database. Each instance of the \*LSO\_TIME\_SEQUENCE command creates a new time sequence with an independent output frequency and duration. Furthermore, while the default domain for each output variable will be the entire mesh on which that variable is defined, at all selected snapshot times, the \*LSO\_DOMAIN keyword commands can be used to specify that output will only occur on a portion of SOLVER\_NAME's mesh, and for a limited time interval, or that it will occur at a set of points (see \*LSO\_POINT\_SET), or over a set of object IDs (see \*LSO\_ID\_SET). Note that for the single-precision version of LS-DYNA, the only allowed value of SOLVER\_NAME = MECH.

Card 1	1	2	3	4	5	6	7	8
Variable	SOLVER_NAME							
Type	A							

Card 2	1	2	3	4	5	6	7	8
Variable	DT	LCDT	LCOPT	NPLTC	TBEG	TEND		
Type	F	I	I	I	F	F		
Default	0.0	0	1	0	0.0	0.0		
Remarks	1	1	1	1				

**Domain IDs.** Provide as many cards as necessary. This input ends at the next keyword ("\*\*") card, or when a global variable name card appears

Card 3	1	2	3	4	5	6	7	8
Variable	DOMID1	DOMID2	DOMID3	DOMID4	DOMID5	DOMID6	DOMID7	DOMID8
Type	I	I	I	I	I	I	I	I
Default	none	none	none	none	none	none	none	none

**Global variable names.** Provide as many cards as necessary. This input ends at the next keyword ("\*\*") card

Card 4	1	2	3	4	5	6	7	8
Variable	GLOBAL_VAR							
Type	A							

<u>VARIABLE</u>	<u>DESCRIPTION</u>
SOLVER_ NAME	Selects the solver from which data is output in this time sequence. Accepted entries so far are 'MECH', 'EM', 'CESE' and 'ICFD'
DT	Time interval between outputs.
LCDT	Optional load curve ID specifying the time interval between dumps.
LCOPT	Flag to govern behavior of plot frequency load curve: <ul style="list-style-type: none"> <li>EQ.1: At the time each plot is generated, the load curve value is added to the current time to determine the next plot time (this is the default behavior).</li> <li>EQ.2: At the time each plot is generated, the next plot time T is computed so that T = the current time plus the load curve value at the time T.</li> <li>EQ.3: A plot is generated for each ordinate point in the load curve definition. The actual value of the load curve is ignored.</li> </ul>

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
NPLTC	DT = ENDTIM/NPLTC overrides DT specified in the first field.
TBEG	The problem time at which to begin writing output to this time sequence
TEND	The problem time at which to terminate writing output to this time sequence
DOMID1, ...	Output set ID defining the domain over which variable output is to be performed in this time sequence. Each DOMID refers to the domain identifier in an *LSO_DOMAIN keyword card.
GLOBAL_VAR	The name of a global output variable computed by SOLVER_NAME. This variable must have a single value (scalar, vector, or tensor), and therefore does not depend upon any DOMID. Any number of such variables may be specified with a given time sequence. These variables are listed as having "global" domain for SOLVER_NAME in a separate document. This document (LSO_VARIABLES.TXT) is created by running the command: LS-DYNA print_lso_doc.

**Remarks:**

1. If LCDT is nonzero, then it is used and DT and NPLTC are ignored. If LCDT is zero and NPLTC is non-zero, then NPLTC determines the snapshot time increment. If LCDT and NPLTC are both zero, then the minimum non-zero time increment specified by DT is used to determine the snapshot times.



**\*LSO\_VARIABLE\_GROUP**

Purpose: To provide a means of defining a shorthand name for a group of variables. That is, wherever the given group name is used, it is replaced by the list of variables given in this command. Note that for the single-precision version of LS-DYNA, the only allowed value of SOLVER\_NAME = MECH.

Card 1	1	2	3	4	5	6	7	8
Variable	SOLVER_NAME							
Type	A							

Card 2	1	2	3	4	5	6	7	8
Variable	DOMAIN_TYPE							
Type	A							

Card 3	1	2	3	4	5	6	7	8
Variable	GROUP_NAME							
Type	A							

**List Of Variables In Group.** Provide as many cards as necessary. This input ends at the next keyword ("\*") card

Card 4	1	2	3	4	5	6	7	8
Variable	VAR_NAME							
Type	A							

<b>VARIABLE</b>	<b>DESCRIPTION</b>
SOLVER_NAME	Selects the solver for which data is output in a time sequence.

---

<b>VARIABLE</b>	<b>DESCRIPTION</b>
DOMAIN_TYPE	Name of the type of domain on which each VAR_NAME is defined.
GROUP_NAME	Name of (or alias for) the group of names given by the listed VAR_NAMES
VAR_NAME	The name of an output variable computed by SOLVER_NAME

**Remarks:**

1. Valid VAR\_NAMES depend both upon the SOLVER\_NAME and the DOMAIN\_TYPE. These variables are listed by DOMAIN\_TYPE for each SOLVER\_NAME in a separate document. This document (LSO\_VARIABLES.TXT) is created by running the command: LS-DYNA print\_lso\_doc.

